

XGB Analogue

User's Manual

Analogue input

XBF-AD04A

Analogue output

XBF-DV04A

XBF-DC04A

Temperature input



XBF-RD04A

XBF-TC04S

Analogue input/output

XBF-AH04A

Built-in PID



Safety Instructions

- Read this manual carefully before installing, wiring, operating, servicing or inspecting this equipment.
- Keep this manual within easy reach for quick reference.

Safety Instruction

Before using the product ...

For your safety and effective operation, please read the safety instructions thoroughly before using the product.

- ▶ Safety Instructions should always be observed in order to prevent accident or risk with the safe and proper use the product.
- ▶ Instructions are separated into “Warning” and “Caution”, and the meaning of the terms is as follows;



Warning

This symbol indicates the possibility of serious injury or death if some applicable instruction is violated



Caution

This symbol indicates the possibility of slight injury or damage to products if some applicable instruction is violated

- ▶ The marks displayed on the product and in the user’s manual have the following meanings.



Be careful! Danger may be expected.



Be careful! Electric shock may occur.

- ▶ The user’s manual even after read shall be kept available and accessible to any user of the product.

Safety Instruction

Safety Instructions when designing



Warning

- ▶ **Please, install protection circuit on the exterior of PLC to protect the whole control system from any error in external power or PLC module.** Any abnormal output or operation may cause serious problem in safety of the whole system.
 - Install applicable protection unit on the exterior of PLC to protect the system from physical damage such as emergent stop switch, protection circuit, the upper/lowest limit switch, forward/reverse operation interlock circuit, etc.
 - If any system error (watch-dog timer error, module installation error, etc.) is detected during CPU operation in PLC, the whole output is designed to be turned off and stopped for system safety. However, in case CPU error if caused on output device itself such as relay or TR can not be detected, the output may be kept on, which may cause serious problems. Thus, you are recommended to install an addition circuit to monitor the output status.
- ▶ **Never connect the overload than rated to the output module nor allow the output circuit to have a short circuit,** which may cause a fire.
- ▶ **Never let the external power of the output circuit be designed to be On earlier than PLC power,** which may cause abnormal output or operation.
- ▶ **In case of data exchange between computer or other external equipment and PLC through communication or any operation of PLC (e.g. operation mode change), please install interlock in the sequence program to protect the system from any error.** If not, it may cause abnormal output or operation.

Safety Instruction

Safety Instructions when designing

Caution

- ▶ **I/O signal or communication line shall be wired at least 100mm away from a high-voltage cable or power line.** If not, it may cause abnormal output or operation.

Safety Instructions when designing

Caution

- ▶ **Use PLC only in the environment specified in PLC manual or general standard of data sheet.** If not, electric shock, fire, abnormal operation of the product or flames may be caused.
- ▶ **Before installing the module, be sure PLC power is off.** If not, electric shock or damage on the product may be caused.
- ▶ **Be sure that each module of PLC is correctly secured.** If the product is installed loosely or incorrectly, abnormal operation, error or dropping may be caused.
- ▶ **Be sure that I/O or extension connector is correctly secured.** If not, electric shock, fire or abnormal operation may be caused.
- ▶ **If lots of vibration is expected in the installation environment, don't let PLC directly vibrated.** Electric shock, fire or abnormal operation may be caused.
- ▶ **Don't let any metallic foreign materials inside the product,** which may cause electric shock, fire or abnormal operation.

Safety Instruction

Safety Instructions when wiring

Warning

- ▶ **Prior to wiring, be sure that power of PLC and external power is turned off.** If not, electric shock or damage on the product may be caused.
- ▶ **Before PLC system is powered on, be sure that all the covers of the terminal are securely closed.** If not, electric shock may be caused

Caution

- ▶ **Let the wiring installed correctly after checking the voltage rated of each product and the arrangement of terminals.** If not, fire, electric shock or abnormal operation may be caused.
- ▶ **Secure the screws of terminals tightly with specified torque when wiring.** If the screws of terminals get loose, short circuit, fire or abnormal operation may be caused.
- *
 - ▶ **Surely use the ground wire of Class 3 for FG terminals, which is exclusively used for PLC.** If the terminals not grounded correctly, abnormal operation may be caused.
 - ▶ **Don't let any foreign materials such as wiring waste inside the module while wiring,** which may cause fire, damage on the product or abnormal operation.

Safety Instruction

Safety Instructions for test-operation or repair

Warning

- ▶ **Don't touch the terminal when powered.** Electric shock or abnormal operation may occur.
- ▶ **Prior to cleaning or tightening the terminal screws, let all the external power off including PLC power.** If not, electric shock or abnormal operation may occur.
- ▶ **Don't let the battery recharged, disassembled, heated, short or soldered.** Heat, explosion or ignition may cause injuries or fire.

Caution

- ▶ **Don't remove PCB from the module case nor remodel the module.** Fire, electric shock or abnormal operation may occur.
- ▶ **Prior to installing or disassembling the module, let all the external power off including PLC power.** If not, electric shock or abnormal operation may occur.
- ▶ **Keep any wireless installations or cell phone at least 30cm away from PLC.** If not, abnormal operation may be caused.

Safety Instructions for waste disposal

Caution

- ▶ **Product or battery waste shall be processed as industrial waste.** The waste may discharge toxic materials or explode itself.

About The User's Manual

Congratulations on purchasing PLC from IMO Precision Controls, Ltd.

Before use, be sure to read carefully and understand the PLC functions, performance, installation and programming in order to use correctly. It is important to also provide the End User / Maintenance Administrator with a copy of this The User's Manual.

The User's Manual describes the product functionality and provides basic instruction for installation, wiring and programming. For additional information you may connect our website(<http://www.imopc.com/>) and download other manuals as PDF files.

Relevant User's Manual

Title	Description	No. of User Manual
XG5000 User's Manual (XEC)	It describes how to use XG5000 software especially about online functions such as programming, printing, monitoring and debugging by using XGB (IEC language)	XG5000.pdf
XEC Series Instruction & Programming	It describes how to use the instructions for programming using XGB (IEC language) series.	XGB Programming Instructions.pdf
XGB Hardware User's Manual (IEC language)	It describes how to use the specification of power/input/output/expansion modules, system configuration and built-in High-speed counter for XGB main unit.	XGB (IEC) User Manual.pdf
XGB Analogue User's Manual	It describes how to use the specification of analogue input/analogue output/temperature input module, system configuration and built-in PID control for XGB main unit.	XGB Analogue.pdf
XGB Cnet I/F User's Manual	It describes how to use built-in communication function for XGB main unit and external Cnet I/F module.	XGB Cnet.pdf
XGB Fast Ethernet I/F User's Manual	It describes how to use XGB FEnet I/F module.	XGB FEnet.pdf

Table of Contents

Chapter 1 General 1-1

- 1.1 Analogue Product List.....1-1
- 1.2 Specification of Analogue Module.....1-2

Chapter 2 Analogue Input Module 2-1

- 2.1 Setting Sequence before Operation.....2-1
- 2.2 Specifications2-2
- 2.3 Name of part and function2-4
- 2.4 Characteristic of I/O conversion2-5
- 2.5 Conversion Characteristic according to Input Range2-6
- 2.6 Accuracy2-9
- 2.7 Functions of Analogue Input Module2-10
- 2.8 Wiring2-13
- 2.9 Operation Parameter Setting2-17
- 2.10 Special Module Monitoring Functions2-20
- 2.11 Register U devices2-25
- 2.12 Configuration and Function of Internal Memory2-28
- 2.13 Example Program2-34
- 2.14 Troubleshooting2-40

Chapter 3 Analogue Output Module 3-1

- 3.1 Setting Sequence before Operation3-1
- 3.2 Specification3-2
- 3.3 Designations and Functions3-4
- 3.4 Characteristic of I/O Conversion3-5
- 3.5 Characteristic of Input/Output3-6
- 3.6 Accuracy3-7
- 3.7 Functions of Analogue Output Module3-8
- 3.8 Wiring3-9
- 3.9 Operation Parameter Setting3-10
- 3.10 Special Module Monitoring Function3-12
- 3.11 Register U devices3-15
- 3.12 Internal memory3-19
- 3.13 Example Program3-24
- 3.14 Troubleshooting3-27

Chapter 4 RTD Input Module4-1

4.1 Setting Sequence before Operation	4-1
4.2 Specification	4-2
4.3 Part Names and Functions	4-4
4.4 Temperature Conversion Characteristic	4-5
4.5 Conversion Speed	4-6
4.6 Accuracy	4-6
4.7 Temperature Display	4-6
4.8 Scaling Function	4-7
4.9 Disconnection Detection Function	4-8
4.10 Wiring	4-9
4.11 Filtering Function	4-11
4.12 Operation Parameter Setting	4-12
4.13 Special Module Monitoring	4-15
4.14 Register U devices	4-18
4.15 Configuration and Function of Internal Memory	4-21
4.16 Example Program	4-25
4.17 Trouble Shooting	4-28

Chapter 5 Thermocouple Input Module.....5-1

5.1 General.....	5-1
5.2 Specification	5-3
5.3 Function	5-11
5.4 Installation and Wiring.....	5-16
5.5 Operation Setting and Monitor	5-18
5.6 Configuration and Function of Internal Memory	5-32
5.7 Example Program	5-47
5.8 Troubleshooting	5-52

Chapter 6 Analogue Combo Module.....6-1

6.1 Pre-operation Setting Procedure	6-1
6.2 Specification	6-2
6.3 Major Components.....	6-5
6.4 Conversion Characteristics by I/O Range.....	6-6
6.5 Precision	6-10
6.6 Functions of Analogue Combo Module.....	6-12

6.7 Wiring	6-18
6.8 Operation Parameter Setting	6-22
6.9 Special Module Monitor Function.....	6-24
6.10 Auto-registration of U-Device (Special Module Variable)	6-28
6.11 Constitution and Function of Internal Memory	6-33
6.12 Example Program	6-40
6.13 Troubleshooting	6-46

Chapter 7 PID Function (Built-in function).....	7-1
--	------------

7.1 General	7-1
7.2 PID Control	7-3
7.3 PID Instructions	7-27
7.4 PID Auto-tuning	7-33
7.5 Example Programs	7-42
7.6 Error/Warning Codes	7-54

Appendix	App.1-3
-----------------------	----------------

Appendix 1 Standard Resistor of Pt RTD	App.1-1
Appendix 2 Thermo Electromotive Force and Compensating Cable	App.2-1
Appendix 3 Dimension	App.3-1

Chapter 1 General

Here is a description of all analogue modules and built-in PID function of XGB series.

1.1 Analogue Product List

Classification	Name	No. of channel	Range	Resolution	Characteristic
Voltage/Current input	XBF-AD04A	4	0 ~ 10V	2.5 mV	1.Range selection by external switch and parameter setting 2. External DC24V used
			0 ~ 20mA 4mA ~ 20mA	5.0 μ A	
Voltage output	XBF-DV04A	4	0 ~ 10V	2.5 mV	1. External DC24V used 2.Designates output in case of Error and CPU STOP
Current output	XBF-DC04A	4	0 ~ 20mA 4mA ~ 20mA	5.0 μ A	
RTD input	XBF-RD04A	4	PT100 JPT100	0.1 $^{\circ}$ C	1. External DC24V used 2. Filter function
	XBF-RD01A	1			
Thermocouple Input module	XBF-TC04S	4	K / J / T / R	Note1)	1. External DC24V used 2. filter process, average process
Analogue combo (voltage/current I/O)	XBF-AH04A	2 (input) 2 (output)	4~20mA 0~20mA	5.0 μ A	1.Range selection by external switch and parameter setting 2.Filter function, averaging function 3.Specifies output when error or CPU STOP 4. Uses external DC24V
			1~5V 0~5V	1.25 mV	
			0~10V	2.5 mV	

Note1) for more detail, refer to Ch.5.2.6 accuracy/resolution.

Note2) To use analogue combo module, the following version of basic unit is necessary

Basic unit	Version
XGB S type	V2.4
XGB H type	V1.7
XGB IEC type	V1.0

1.2 Specification of Analogue Module

Here describes about specification of analogue module of XGB series.

1.2.1 Analogue input

Item			XBF-AD04A	
Analogue input range	Type		Voltage	Current
	Range		DC 0 ~ 10V (Input resistance: 1 MΩ min.)	DC 4 ~ 20mA DC 0 ~ 20mA (Input resistance: 250 Ω)
Digital output	Type		12 bit binary data	
	Range	Unsigned value	0 ~ 4000	
		Signed value	-2000 ~ 2000	
		Precise value	0 ~ 1000	400 ~ 2000/0 ~ 2000
		Percentile value	0 ~ 1000	
Max. resolution		2.5mV(1/4000)	5μA(1/4000)	
Accuracy		± 0.5% or less		
Max. conversion speed		1.5ms/channel		
Absolute max. input		DC ±15V	DC +25mA	
No. of output channel		4 channels		
Insulation method		Photo-coupler insulation between input terminal and PLC power (No insulation between channels)		
Connection Terminal		11 point terminal block		
I/O points occupied		Fixed type: 64 points		
Max. number of equipment		7 (when using XBM-DxxxS "S" type) 10 (when using XB(E)C-DxxxH "H" type)		
Consumption current	Inner (DC 5V)	120mA		
	External (DC 24V)	62mA		
Weight		64g		
Additional function		Filter-processing, average-processing (time, count)		

1.2.2 Analogue output

Item			XBF-DV04A	XBF-DC04A
Analogue output	Type		Voltage	Current
	Range		DC 0 ~ 10V (Load resistance: 2kΩ or more)	DC 4 ~ 20mA DC 0 ~ 20mA (Load resistance: 510Ω or less)
Digital input	Type		12 bit binary data	
	Range	Unsigned value	0 ~ 4000	0 ~ 4000
		Signed value	-2000 ~ 2000	-2000 ~ 2000
		Precise value	0 ~ 1000	400 ~ 2000/0 ~ 2000
		Percentile value	0 ~ 1000	0 ~ 1000
Max. resolution			2.5mV(1/4000)	5μA(1/4000)
Accuracy			± 0.5% or less	
Max. conversion speed			1 ms/channel	
Absolute max. output			DC ±15V	DC +25mA
No. of output channel			4 channels	
Insulation method			Photo-coupler insulation between output terminal and PLC power (no insulation between channel)	
Connection Terminal			11 point terminal block	
I/O points occupied			64 points	
Max. number of equipment			7 (when using XBM-DxxxS “S” type) 10 (when using XB(E)C-DxxxH “H” type)	
Consumption current	Inner (DC 5V)		110mA	110mA
	External (DC 24V)		70mA	120mA
Weight			64g	70g
Additional function			Designates output in case of error and CPU STOP	

1.2.3 RTD input

Item		XBF-RD04A
No. of input channel		4 channels
Input sensor type	PT100	JIS C1604-1997
	JPT100	JIS C1604-1981 , KS C1603-1991
Input temp. range	PT100	-200 ~ 600℃
	JPT100	-200 ~ 600℃
Digital output	PT100	-2000 ~ 6000
	JPT100	-2000 ~ 6000
	Scaling display	0 ~ 4000
Accuracy	Normal temp. (25℃)	± 0.3% or less
	Full temp. (0~55℃)	± 0.5% or less
Conversion speed		40ms / channel
Insulation method	Between channels	No insulation
	terminal – PLC power	Insulation (Photo-Coupler)
Terminal block		15 point terminal
I/O points occupied		64 points
Max. number of equipment		7 (when using XBM-DxxxS "S" type) 10 (when using XB(E)C-DxxxH "H" type)
Sensor wiring method		3 line
Additional function	Filter function	Digital filter (160 ~ 64000ms)
	Alarm function	Disconnection detection
Consumption current	Inner DC5V	100mA
	External DC24V	100mA
Weight		63g

1.2.4 Thermocouple input

Items			Specification
Number of input channel			4 channels
Type of input sensor			Thermocouple K / J / T / R type JIS C1602-1995
Range of input temperature	K		-200.0℃ ~ 1300.0℃
	J		-200.0℃ ~ 1200.0℃
	T		-200.0℃ ~ 400.0℃
	R		0.0℃ ~ 1700.0℃
Digital output	Temp. display		Displaying down to one decimal place – note1) K, J, T type: 0.1℃, R type: 0.5℃
	Scaling display (user-defined scaling)		Unsigned scaling (0 ~ 65535) Signed scaling (-32768 ~ 32767)
Accuracy	Ambient temperature(25℃)		Within ± 0.2% – note 2)
	Temp. coefficient (range of operating temp)		± 100 ppm/℃
Conversion velocity			50ms / channel
Insulation	Insulation method	Terminal – inner circuit	Photo-coupler insulation
		Terminal – operating power	DC/DC converter insulation
		Between channels	Photo-moss relay insulation
	Insulation pressure		400 V AC, 50/60 Hz, 1min, leakage current 10mA or below
	Insulation resistance		500 V DC, 10 MΩ or above
Standard contact point compensation	Auto compensation by RJC sensing (Thermistor)		
	Compensation amount		±1.0℃
Warming-up time			20 min or above
Terminal block			11 point terminal
I/O occupied points			64 points
Max. number of equipment			7 (when using XBM-DxxxS “S”type) 10 (when using XB(E)C-DxxxH “H”type)
Additional function	Filter process		Digital filter (200 ~ 64,000ms)
	Average process	Time average (400~64,000ms)	
		Count average (2~64,000 times)	
		Moving average (2~100)	
	Alarm		Disconnection detection
	Max./Min. display		Display Max./Min.
	Scaling function		Signed scaling / Unsigned scaling
Consumption current	Inner DC5V		100mA
	External DC24V		100mA
Weight			63g

Note1), Note2) For more detail specification, refer to 5.2.6 accuracy/resolution.

1.2.5 Analogue combo

(1) Input performance specification

Items			Input performance specifications	
No. of input channel			2 channels	
Analogue input range	Type		Voltage	Current
	Range		DC 1 ~ 5V	DC 4 ~ 20mA
			DC 0 ~ 5V	DC 0 ~ 20mA
			DC 0 ~ 10V	(input resistor 250 Ω)
			(input resistor: 1 MΩ or above)	
Input range can be set through external voltage/current selector switch after setting at user program or I/O parameter per input channel				
Digital output	Type		12bit binary data	
	Range	Unsigned value	0 ~ 4000	
		Signed value	-2000 ~ 2000	
		Precise value	100 ~ 500 (DC 1 ~ 5V) 0 ~ 500 (DC 0 ~ 5V) 0 ~ 1000 (DC 0 ~ 10V)	400 ~ 2000 (DC 4 ~ 20mA) 0 ~ 2000 (DC 0 ~ 20mA)
		Percentile value	0 ~ 1000	
Max. resolution		1/4000		
		1.25mV (DC 1~5V, 0~5V) 2.5mV (DC 0~10V)	5μA (DC4~20mA, 0~20mA)	
Precision		±0.5% or less		
Max. conversion speed		1ms/channel		
Absolute max. input		DC ±15V	DC ±25mA	
Additional function	Filter function		Digital filter (4 ~ 64,000ms)	
	Averaging function	Time averaging (4~16,000ms)		
		Cyclic averaging (2~64,000cycle)		
		Moving averaging (2~100samples)		
	Alarm function		Disconnection detection (DC 1~5V, DC4~20mA)	

(2) Output performance specification

Items			Output performance specification	
No. of output channel			2 channels	
Analogue output range	Type		Voltage	Current
	Range		DC 1 ~ 5V	DC 4 ~ 20mA
			DC 0 ~ 5V	DC 0 ~ 20mA
			DC 0 ~ 10V	(Load resistor 510 Ω or less)
			(Load resistor: 2kΩ or above)	
		Input range can be set through external voltage/current selector switch after setting at user program or I/O parameter per input channel		
Digital input	Type		12 bit binary data	
	Range	Unsigned value	0 ~ 4000	
		Signed value	-2000 ~ 2000	
		Precise value	100 ~ 500 (DC 1 ~ 5V) 0 ~ 500 (DC 0 ~ 5V) 0 ~ 1000 (DC 0 ~ 10V)	400 ~ 2000 (DC 4 ~ 20mA) 0 ~ 2000 (DC 0 ~ 20mA)
		Percentile value	0 ~ 1000	
Max. resolution		1/4000		
		1.25mV (DC 1~5V, 0~5V)	5μA (DC4~20mA, 0~20mA)	
		2.5mV (DC 0~10V)		
Precision		±0.5% or less		
Max. conversion speed		1ms/channel		
Absolute max. output		DC ±15V	DC 25mA	
Additional function		Function setting channel output status (Can select one among Previous, Minimum, median, maximum)		


(3) I/O common performance specification

Items		I/O common performance specification
Insulation method		Photo coupler insulation between I/O terminal and PLC power (not insulated between channels)
I/O terminal block		11 points terminal block
No. of I/O occupation point		Fixed type: 64 points
Max. number of equipment		7 (when using XBM-DxxxS "S" type) 10 (when using XB(E)C-DxxxH "H" type)
Consumption current	Internal (DC 5V)	120mA
	External (DC 24V)	130mA
Weight		73g

Chapter 2 Analogue Input Module

2.1 Setting Sequence before operation

Before using the analogue input module, follow steps below.



2.2 Specifications

2.2.1 General specifications

General specifications are as follows.

No.	Items	Specification				Related standards
1	Operating temp.	0 ~ 55 °C				
2	Storage temp.	-25 ~ +70 °C				
3	Operating humidity	5~95%RH (Non-condensing)				
4	Storage humidity	5~95%RH (Non-condensing)				
5	Vibration	For discontinuous vibration			-	IEC61131-2
		Frequency	Acceleration	Amplitude	Number	
		10 ≤ f < 57Hz	-	0.075mm	Each 10 times in X,Y,Z directions	
		57 ≤ f ≤ 150Hz	9.8m/s ² (1G)	-		
		For continuous vibration				
		Frequency	Acceleration	Amplitude		
		10 ≤ f < 57Hz	-	0.035mm		
		57 ≤ f ≤ 150Hz	4.9m/s ² (0.5G)	-		
6	Shocks	<ul style="list-style-type: none">Max. impact acceleration : 147 m/s²(15G)Authorized time : 11msPulse wave : Sign half-wave pulse (Each 3 times in X,Y,Z directions)				IEC61131-2
7	Noise	Square wave impulse noise	±1,500 V			IMO standard
		Electrostatic discharging	Voltage : 4kV(contact discharging)			IEC61131-2 IEC61000-4-2
		Radiated electromagnetic field noise	27 ~ 500 MHz, 10V/m			IEC61131-2, IEC61000-4-3
		Fast Transient /burst noise	Class	Power module	Digital/ Analogue I/O communication interface	IEC61131-2 IEC61000-4-4
			Voltage	2kV	1kV	
8	Ambient conditions	No corrosive gas or dust				
9	Operating height	2000m or less				
10	Pollution degree	2 or less				
11	Cooling type	Natural air cooling				

2.2.2 Performance specifications

Performance specifications are as follows.


Items			XBF-AD04A	
Analogue input range	Type		Voltage	Current
	Range		DC 0 ~ 10V (Input resistance: 1 MΩ min.)	DC 4 ~ 20mA DC 0 ~ 20mA (Input resistance 250 Ω)
Digital output	Type		12 bit binary data	
	Range	Signed value	0 ~ 4000	
		Unsigned value	-2000 ~ 2000	
		Precise value	0 ~ 1000	400 ~ 2000/0 ~ 2000
		Percentile value	0 ~ 1000	
Max. resolution		2.5mV(1/4000)	5μA(1/4000)	
Accuracy		±0.5% or less		
Max. conversion speed		1.5ms/channel		
Absolute max. output		DC ±15V	DC ±25mA	
No. of output channel		4 channels		
Insulation method		Photo-coupler insulation between input terminal and PLC power (No insulation between channels)		
Connection terminal		11 point terminal block		
I/O points occupied		Fixed type: 64 points		
Consumption current	Inner (DC 5V)		120mA	
	External (DC 24V)		62mA	
Weight		64g		
Additional function		Filter-processing, average-processing (time, count)		

Notes

- 1) When A/D conversion module is released from the factory, Offset/Gain value is as adjusted for respective analogue input ranges, which is unavailable for user to change.
- 2) Offset Value: Analogue input value where digital output value is 0 when digital output format is set to Unsigned Value.
- 3) Gain Value: Analogue input value where digital output value is 16000 when digital output format is set to Unsigned Value.

2.3 Name of part and function


Respective designations of the parts are as described below.



No.	Description
<input type="checkbox"/>	RUN LED <ul style="list-style-type: none"> Displays the operation status of XBF-AD04A <ul style="list-style-type: none"> On: Operation normal Flickering: Error occurs (page 12-30) Off: Module error
<input type="checkbox"/>	Terminal block <ul style="list-style-type: none"> Analogue input terminal, whose respective channels can be connected with external devices.
<input type="checkbox"/>	Voltage/Current selection switch <ul style="list-style-type: none"> Switch for voltage and current selection of analogue input

2.4 Characteristic of I/O conversion

Characteristics of I/O conversion are the inclination connected in a straight line between Offset and Gain values when converting analogue signal (voltage or current input) from PLC's external device to digital value. I/O conversion characteristics of A/D conversion modules are as described below.




2.5 Conversion Characteristic according to Input Range

Voltage input range can be set through user program or special module package for respective channels. Output formats of digital data are as specified below;

- A. Unsigned Value
- B. Signed Value
- C. Precise Value
- D. Percentile Value


2.5.1 If the range is DC 0 ~ 10V



Digital output value for voltage input characteristic is as specified below.
(Resolution (based on 1/4000): 2.5 mV)

Digital output range	Analogue input voltage (V)					
	0	2.5	5	7.5	10	10.11
Unsigned value (0 ~ 4047)	0	1000	2000	3000	4000	4047
Signed value (-2000 ~ 2047)	-2000	-1000	0	1000	2000	2047
Precise value (0 ~ 1011)	0	250	500	750	1000	1011
Percentile value (0 ~ 1011)	0	250	500	750	1000	1011


2.5.2 If the range is DC 0 ~ 20mA ▪



- Digital output value for current input characteristic is as specified below.
(Resolution (based on 1/4000): 5 μ A)

Digital output range	Analogue input current (mA)					
	0	5	10	15	20	20.23
Unsigned value (0 ~ 4047)	0	1000	2000	3000	4000	4047
Signed value (-2000 ~ 2047)	-2000	-1000	0	1000	2000	2047
Precise value (0 ~ 2023)	0	500	1000	1500	2000	2023
Percentile value (0 ~ 1011)	0	250	500	750	1000	1011

2.5.3 If range is DC4 ~ 20mA ▪



▪ Digital output value for current input characteristic is as specified below.
(Resolution (Based on 1/4000): 5 μ A)

Digital Output range	Analogue input current (mA)						
	0	4	8	12	16	20	20.23
Unsigned value (-48 ~ 4047)	-48	0	1000	2000	3000	4000	4047
Signed value (-2048 ~ 2047)	-2048	-2000	-1000	0	1000	2000	2047
Precise value (381 ~ 2023)	381	400	800	1200	1600	2000	2023
Percentile value (-12 ~ 1011)	-12	0	250	500	750	1000	1011


Notes

- 1) If analogue input value exceeding digital output range is input, the digital output value will be kept to be the max. or the min. value applicable to the output range specified. For example, if the digital output range is set to unsigned value (0 ~ 4000) and the digital output value exceeding 4047 or analogue value exceeding -0 is input, the digital output value will be fixed as 0~4047.
- 2) Voltage and current input shall not exceed ± 15 V and ± 25 mA respectively. Rising heat may cause defects.

2.6 Accuracy

Accuracy of digital output value does not change even if input range is changed. Figure below shows the range of the accuracy with analogue input range of 0 ~ 10 V and digital output type of unsigned value selected.

Accuracy of XBF-AD04A is $\pm 0.5\%$.



- (1) Accuracy when using 5V input

$$4000 \times 0.5\% = 20$$

Therefore the range of the accuracy will become $(2000-20) \sim (2000+20) = 1980 \sim 2020$ when using 5V input.

- (2) Accuracy when using 10V input

$$4000 \times 0.5\% = 20$$


Therefore the range of the accuracy will become $(4000-20) \sim (4000+20) = 3980 \sim 4020$ when using 10V input.

2.7 Functions of Analogue Input Module

Functions of XBF-AD04A conversion module are as described below.

Function	Description
Channel Run/Stop setting	(1) Specify Run/Stop of the channel to execute A/D conversion. (2) If the unused channel is set to Stop, whole Run time can be reduced.
Input voltage/Current range setting	(1) Specify analogue input range to be used. (2) Select range in parameter setting after select Voltage/Current switch.
Output data format setting	(1) Specify digital output type. (2) 4 output data formats are provided in this module.
A/D conversion methods	(1) Sampling processing Sampling process will be performed if A/D conversion type is not specified. (2) Filter processing Used to delay the sudden change of input value. (3) Average processing Outputs average A/D conversion value based on frequency or time.

There are three A/D conversion methods, sampling processing, filter processing and average processing.



(1) Sampling processing

It collects analogue input sign through general A/D conversion processing at a specific interval so to convert to digital. The time required for A/D conversion of analogue input sign till saved on the memory depends on the number of channels used.

$$(\text{Processing time}) = (\text{Number of channels used}) \times (\text{Conversion speed})$$

(Ex.) If the number of channels used is 3, its process time will be

$$3 \times 1.5 \text{ ms} = 4.5 \text{ ms}$$

Sampling is to calculate the sampling value of continuous analogue sign at a specific interval.

Chapter 2 Analogue Input Module

(2) Filter processing

Filter process function is used to obtain stable digital output value by filtering (delaying) noise or sudden change of input value. Filter constant can be specified for respective channels through user program or I/O parameters setting.

- Setting range: 1 ~ 99 (%)

$$F[n] = (1 - \alpha) \times A[n] + \alpha \times F[n - 1]$$

$F[n]$: Present filter output value
 $A[n]$: Present A/D converted value
 $F[n-1]$: Previous filter output value
 α : Filter constant (0.01 ~ 0.99: previous value added)

- If filter setting value is not specified within 1 ~ 99, RUN LED blinks at an interval of 1 second. In order to set RUN LED to On status, reset the filter setting value within 1 ~ 99 and then convert PLC CPU from STOP to RUN. Be sure to use request flag of error clear (UXY.11.0) to clear the error through modification during RUN.

- Analogue input range: DC 0 ~ 10 V, Digital output range: 0 ~ 4000
- If analogue input value changes 0 V → 10 V (0 → 4000), filter output value based on α value is as specified below.

α value	Filter output value				α value
	0 scan	1 scan	2 scan	3 scan	
*1) 0.01	0	3600	3960	3997	1% inclined toward previous value
*2) 0.66	0	1360	2257	2850	50% inclined toward previous value
*3) 0.99	0	40	80	119	99% inclined toward previous value

*1) 4000 output after about 4 scans

*2) 4000 output after about 18 scans

*3) 4000 output after about 950 scans(1.19 s for 1 channel Run)

- If filter process function is not used, present A/D converted value will be output as it is. The filter process function takes value-added data between 'Present A/D converted value' and 'Previous A/D converted value'. And the value-added data can be decided with filter constant. If output data shakes too much, set a big filter constant value.

(3) Average processing

This process is used to execute A/D conversion of the channel designated for specified frequency or for specified time and save the average of the accumulated sum on memory. Average processing option and time/frequency value can be defined through user program or I/O parameters setting for respective channels.

(a) What is the average process used for

This process is used for A/D conversion of abnormal analogue input signal such as noise to a value near to normal analogue input signal.

(b) Average processing type

Average processing type is of time average and count average.

1) Time average processing

- Setting range: 4 ~ 16000 (ms)
- Average processing count within specified time is decided based on the number of channels used.

$$\text{Average processing count} = \frac{\text{Setting time}}{(\text{Number of Channels used}) \times (\text{Conversion Speed})}$$

Chapter 2 Analogue Input Module

Ex.1) Channels used: 1, setting time: 16000 ms

$$\text{Average processing count} = \frac{16000 \text{ ms}}{1 \times 1.5 \text{ ms}} = 10667 \text{ times}$$

Ex.2) Channels used: 4, setting time: 4 ms

$$\text{Average processing count} = \frac{4 \text{ ms}}{4 \times 1.5 \text{ ms}} = 1 \text{ times}$$

If setting value of time average is not specified within 4 ~ 16000, RUN LED blinks at an interval of 1 second. In order to set RUN LED to On status, reset the setting value of time average within 4 ~ 16000 and then convert PLC CPU from STOP to RUN. Be sure to use request flag of error clear (UXY.11.0) to clear the error through modification during RUN.

- Time average is processed after converted to average of the times inside the A/D conversion module. In this case, a remainder may be produced when setting time is divided by (number of channels used X conversion speed), which will be disregarded. Thus, the average processing frequency will be the quotient of [(setting time) ÷ (number of channels used x conversion speed)].

Ex.) If the number of channels used is 5, and setting time is 151 ms

$$151 \text{ ms} \div (4 \times 1.5 \text{ ms}) = 26 \text{ times} \dots\dots \text{Remainder of } 2 \rightarrow 26 \text{ times}$$

2) Count average process

- Setting range: 2 ~ 64000 (times)
- The time required for average value to be saved on memory when frequency average used depends on the number of channels used.

Process time = setting frequency X number of channels used X conversion speed

If setting value of count average is not specified within 2 ~ 64000, RUN LED blinks at an interval of 1 second. In order to set RUN LED to On status, reset the setting value of frequency average within 2 ~ 64000 and then convert PLC CPU from STOP to RUN. Be sure to use request flag of error clear (UXY.11.0) to clear the error through modification during RUN.

Ex.) If the number of channels used is 4, and average processing frequency is 50

$$50 \times 4 \times (1.5 \text{ ms}) = 300 \text{ ms}$$

2.8 Wiring


2.8.1 Precaution for wiring

- (1) Don't let AC power line near to A/D conversion module's external input sign line. With an enough distance kept away between, it will be free from surge or inductive noise.
- (2) Cable shall be selected in due consideration of ambient temperature and allowable current, whose size is not less than the max. cable standard of AWG22 (0.3mm²).
- (3) Don't let the cable too close to hot device and material or in direct contact with oil for long, which will cause damage or abnormal operation due to short-circuit.
- (4) Check the polarity when wiring the terminal.
- (5) Wiring with high-voltage line or power line may produce inductive hindrance causing abnormal operation or defect.

2.8.2 Wiring examples

- (1) Example of voltage wiring

- In case of voltage/current input, wiring is same. Adjust the voltage/current setting switch according to the case.




- (a) Input resistance of current input circuit is 250 Ω (typ.).
- (b) Input resistance of voltage input circuit is 1 M Ω (min.).
- (c) Enable the necessary channel only.
- (d) Analogue input module doesn't support power for input device. Use the external power supplier.

Chapter 2 Analogue Input Module

(2) Wiring example of 2-Wire sensor/transmitter (current input)

- In case of voltage/current input, wiring is same. Adjust the voltage/current setting switch according to the case.




- (a) Input resistance of current input circuit is $250\ \Omega$ (typ.).
- (b) Input resistance of voltage input circuit is $1\ \text{M}\Omega$ (min.).
- (c) Enable the necessary channel only.
- (d) Analogue input module doesn't support power for input device. Use the external power supplier.

Chapter 2 Analogue Input Module

(3) Wiring example of 4-Wire sensor/transmitter (Voltage/Current input)

- In case of voltage/current input, wiring is same. Adjust the voltage/current setting switch according to the case.




- (a) Input resistance of current input circuit is 250 Ω (typ.).
- (b) Input resistance of voltage input circuit is 1 M Ω (min.).
- (c) Enable the necessary channel only.
- (d) Analogue input module doesn't support power for input device. Use the external power supplier.

Chapter 2 Analogue Input Module

(4) Relationship between voltage input accuracy and wiring length

In voltage input, the wiring (cable) length between transmitter or sensor and module has an effect on digital-converted values of the module as specified below;



Where,

R_c : Resistance value due to line resistance of cable

R_s : Internal resistance value of transmitter or sensor

R_i : Internal resistance value ($1M\Omega$) of voltage input module

V_{in} : Voltage allowed to analogue input module

% V_i : Tolerance of converted value (%) due to source and cable length in voltage input

$$V_{in} = \frac{R_i \times V_s}{[R_s + (2 \times R_c) + R_i]}$$

$$\% V_i = \left(1 - \frac{V_{in}}{V_s}\right) \times 100 \%$$

2.9 Operation Parameter Setting

A/D conversion module's operation parameters can be specified through XG5000's [I/O parameters].

(1) Settings

For the user's convenience of A/D conversion module, XG5000 provides GUI (Graphical User Interface) for parameters setting of A/D conversion module. Setting items available through [I/O parameters] on the XG5000 project window are as described below in the table.


Item	Details
[I/O parameter]	<p>(1) Specify the following setting items necessary for the module operation.</p> <ul style="list-style-type: none">- Channel Enable/Disable setting- Setting ranges of input voltage/current- Output data format setting- Filter processing Enable/Disable setting- Filter constant setting- Average processing Enable/Disable setting- Average processing method setting- Average value setting <p>(2) The data specified by user through S/W package will be saved on A/D conversion module when [Special Module Parameters] are downloaded. In other words, the point of time when [Special Module Parameters] are saved on A/D conversion module has nothing to do with PLC CPU's status RUN or STOP.</p>

(2) I/O Parameter setting

(a) Run XG5000 to create a project.


(Refer to XG5000 program manual for details on how to create the project)

(b) Double-click [I/O parameters] on the project window.




(c) On the 'I/O parameters setting' screen, find and click the slot of the base A/D conversion module is installed on. 8-channel voltage type of A/D conversion module is installed on Base No.0, Slot No.4 in this description.


Chapter 2 Analogue Input Module




(d) Click the arrow button on the screen above to display the screen where an applicable module can be selected. Search for the applicable module to select.



(e) After the module selected, click [Details].



(f) A screen will be displayed for you to specify parameters for respective channels as shown below. Click a desired item to display parameters to set for respective items.



2.10 Special Module Monitoring Functions

Functions of Special Module Monitoring are as described below.


(1) Monitor/Test

Through applicable XG5000 menu of [Monitor] -> [Special Module Monitoring], A/D converted value can be monitored and the operation of A/D conversion module can be tested.

(2) Monitoring the max./min. value

The max./min. value of the channel can be monitored during Run. However, the max./min. value displayed here is based on the present value shown on the screen. Accordingly, when [Monitoring/Test] screen is closed, the max./min. value will not be saved.

- The parameters specified for the test of A/D conversion module on the “Special Module Monitoring” screen of [Special Module Monitoring] will be deleted the moment the “Special Module Monitoring” screen is closed. In other words, the parameters of A/D conversion module specified on the “Special Module Monitoring” screen will not be saved in [I/O parameters] located




- Test function of [Special Module Monitoring] is provided for user to check the normal operation of A/D conversion module even without sequence programming. If A/D conversion module is to be used for other purposes than a test, use parameters setting function in [I/O parameters].

2.10.1 How to use special module monitoring

Monitoring special module will be based on XBF-AD04A.


(1) Start of [Special Module Monitoring]

Go through [OnLine] -> [Connect] and [Monitor] -> [Special Module Monitoring] to start. If the status is not [OnLine], [Special Module Monitoring] menu will not be active.




(2) How to use [Special Module Monitoring]

- (a) With XG5000 connected to PLC CPU (on-line status), click [Monitor] -> [Special Module Monitoring] to display 'Special Module Select' screen as in Fig. 5.1 showing base/slot information in addition to special module type. The module installed on the present PLC system will be displayed on the list dialog box.




- (b) Select Special module and click [Module information] to display the information as below.

Chapter 2 Analogue Input Module



- (c) Click [Monitor] on the “Special Module” screen in [Special Module List] to display [Special Module Monitoring] screen as below, where 4 options are available such as [Reset max./min. value], [start Monitoring], [Test] and [Close]. A/D conversion module’s output value and max./ min. value are displayed on the monitoring screen at the top of the screen, and parameters items of respective modules are displayed for individual setting on the test screen at the bottom of the screen.



- (d) [Start Monitoring]: Click [Start Monitoring] to display A/D converted value of the presently operated channel. Below screen is the monitoring screen displayed when the whole channels are in Stop status. In the present value field at the screen bottom, presently specified parameters of A/D conversion module are displayed

Chapter 2 Analogue Input Module

Special Module Monitor

XBF-AD04A (Volt/Current, 4-CH)

Item	Max/Min value	Current value
CH0 A/D value	0 / 0	0
CH1 A/D value	0 / 0	0
CH2 A/D value	0 / 0	0
CH3 A/D value	0 / 0	0

Item	Setting Value	Current Value
Channel	CH 0	
Channel status	Disable	Disable
Input range	0~10V	0~10V
Output type	0~4000	0~4000
Filter process	Disable	Disable
Filter constant	1	1
Average setting	Disable	Disable
Average processing	Count-Avr	Count-Avr
Average value	2	2

Reset max/min value Stop Monitoring Test Close

Execution screen of [Start Monitoring]

- (e) [Test]: [Test] is used to change the presently specified parameters of A/D conversion module. Click the setting value at the bottom field of the screen to change parameters. Below screen will be displayed after [Test] is executed with channel 0's input voltage range changed to 0~20 mA in the state of input not wired.

Special Module Monitor

XBF-AD04A (Volt/Current, 4-CH)

Item	Max/Min value	Current value
CH0 A/D value	0 / 0	0
CH1 A/D value	0 / 0	0
CH2 A/D value	0 / 0	0
CH3 A/D value	0 / 0	0

Item	Setting Value	Current Value
Channel	CH 0	
Channel status	Disable	Disable
Input range	0~20mA	0~10V
Output type	0~4000	0~4000
Filter process	Enable	Enable
Filter constant	1	1
Average setting	Disable	Disable
Average processing	Count-Avr	Count-Avr
Average value	2	2

Reset max/min value Stop Monitoring Test Close

Execution screen of [Test]

- (f) [Reset max/min value]: The max/min value field at the upper screen shows the max. value and the min. value of A/D converted value. Click [Reset max/min value] to initialize the max./min. value. Below screen is after [Reset max/min value] button is clicked in the screen of Special Module Monitor, where channel 0's A/D converted value can be checked as reset.

Special Module Monitor

XBF-AD04A (Volt/Current, 4-CH)

Item	Max/Min value	Current value
CH0 A/D value	0 / 0	0
CH1 A/D value	0 / 0	0
CH2 A/D value	0 / 0	0
CH3 A/D value	0 / 0	0

Item	Setting Value	Current Value
Channel	CH 0	
Channel status	Disable	Disable
Input range	0~20mA	0~10V
Output type	0~4000	0~4000
Filter process	Enable	Enable
Filter constant	1	1
Average setting	Disable	Disable
Average processing	Count-Avr	Count-Avr
Average value	2	2

Reset max/min value Stop Monitoring Test Close

Execution screen of [Reset max/min value]


- (g) [Close]: [Close] is used to escape from the monitoring/test screen. When the monitoring/test screen is closed, the max. value, the min. value and the present value will not be saved any more.

2.11 Register U devices


Register the variables for each module referring to the special module information that is set in the I/O parameter. The user can modify the variables and comments.

(1) Procedure


(a) Select the special module type in the [I/O Parameter Setting] window.



(b) Double click 'Variable/Comment' from the project window.




(c) Select [Edit] – [Register U Device].



Chapter 2 Analogue Input Module

(d) Click 'Yes'.



(e) As shown below, the variables are registered.

View Variable					View Device					View Flag				
	Variable	Type	Device	Comment										
1	Start_Condition	BIT	M0000											
2	_01_ERR	BIT	U01.00.0	Analog Input Module: Module Error										
3	_01_RDV	BIT	U01.00.F	Analog Input Module: Module Ready										
4	_01_CH0_ACT	BIT	U01.01.0	Analog Input Module: CH0 Active										
5	_01_CH1_ACT	BIT	U01.01.1	Analog Input Module: CH1 Active										
6	_01_CH2_ACT	BIT	U01.01.2	Analog Input Module: CH2 Active										
7	_01_CH3_ACT	BIT	U01.01.3	Analog Input Module: CH3 Active										
8	_01_CH0_IDO	BIT	U01.10.0	Analog Input Module: CH0 Input Disconnection Flag										
9	_01_CH1_IDO	BIT	U01.10.1	Analog Input Module: CH1 Input Disconnection Flag										
10	_01_CH2_IDO	BIT	U01.10.2	Analog Input Module: CH2 Input Disconnection Flag										
11	_01_CH3_IDO	BIT	U01.10.3	Analog Input Module: CH3 Input Disconnection Flag										
12	_01_ERR_CLR	BIT	U01.11.2	Analog Input Module: Error Clear Request										
13	_02_CH0_ERR	BIT	U02.00.0	Analog Output Module: CH0 Error										
14	_02_CH1_ERR	BIT	U02.00.1	Analog Output Module: CH1 Error										
15	_02_CH2_ERR	BIT	U02.00.2	Analog Output Module: CH2 Error										
16	_02_CH3_ERR	BIT	U02.00.3	Analog Output Module: CH3 Error										
17	_02_RDV	BIT	U02.00.F	Analog Output Module: Module Ready										
18	_02_CH0_ACT	BIT	U02.01.0	Analog Output Module: CH0 Active										
19	_02_CH1_ACT	BIT	U02.01.1	Analog Output Module: CH1 Active										
20	_02_CH2_ACT	BIT	U02.01.2	Analog Output Module: CH2 Active										
21	_02_CH3_ACT	BIT	U02.01.3	Analog Output Module: CH3 Active										
22	_02_CH0_OUTEN	BIT	U02.02.0	Analog Output Module: CH0 Output Status Setting										
23	_02_CH1_OUTEN	BIT	U02.02.1	Analog Output Module: CH1 Output Status Setting										
24	_02_CH2_OUTEN	BIT	U02.02.2	Analog Output Module: CH2 Output Status Setting										

(f) For IEC type, as shown below, the variables are registered.

Global Variable					Direct Variable Comment					Flag				
	Variable Kind	Variable	Type	Address	Initial Value	Retain	Used	Comment						
1	VAR_GLOBAL	_01_ADO_ACT	BOOL	\$XUD.1.16		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH0 Active						
2	VAR_GLOBAL	_01_ADO_DATA	WORD	\$XUD.1.4		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH0 Data						
3	VAR_GLOBAL	_01_ADO_ERR	BOOL	\$XUD.1.24		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH0 Error						
4	VAR_GLOBAL	_01_ADO_IDO	BOOL	\$XUD.1.20		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH0 Disconnection						
5	VAR_GLOBAL	_01_ADI_ACT	BOOL	\$XUD.1.17		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH1 Active						
6	VAR_GLOBAL	_01_ADI_DATA	WORD	\$XUD.1.5		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH1 Data						
7	VAR_GLOBAL	_01_ADI_ERR	BOOL	\$XUD.1.25		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH1 Error						
8	VAR_GLOBAL	_01_ADI_IDO	BOOL	\$XUD.1.21		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Input CH1 Disconnection						
9	VAR_GLOBAL	_01_AAO_ACT	BOOL	\$XUD.1.18		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH0 Active						
10	VAR_GLOBAL	_01_AAO_DATA	WORD	\$XUD.1.7		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH0 DATA						
11	VAR_GLOBAL	_01_AAO_ERR	BOOL	\$XUD.1.26		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH0 Error						
12	VAR_GLOBAL	_01_AAO_OUTEN	BOOL	\$XUD.1.96		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH0 Status Setti						
13	VAR_GLOBAL	_01_AAI_ACT	BOOL	\$XUD.1.19		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH1 Active						
14	VAR_GLOBAL	_01_AAI_DATA	WORD	\$XUD.1.8		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH1 DATA						
15	VAR_GLOBAL	_01_AAI_ERR	BOOL	\$XUD.1.27		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH1 Error						
16	VAR_GLOBAL	_01_AAI_OUTEN	BOOL	\$XUD.1.97		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Output CH1 Status Setti						
17	VAR_GLOBAL	_01_ERR	BOOL	\$XUD.1.0		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Module Error						
18	VAR_GLOBAL	_01_RDV	BOOL	\$XUD.1.15		<input type="checkbox"/>	<input type="checkbox"/>	Analog IO Module: Module Ready						

(2) Save variables

(a) The contents of 'View Variable' can be saved as a text file.

(b) Select [Edit] -> [Export to File].


(c) The contents of 'View variable' are saved as a text file.

Chapter 2 Analogue Input Module


(3) View variables

The example of XGB 'S' type and 'H' type is as follows.


(a) The example program of XG5000 is as shown below.



(b) Select [View] -> [Variables]. The devices are changed into variables.




(c) Select [View] -> [Devices/Variables]. Devices and variables are both displayed.




Chapter 2 Analogue Input Module

(d) Select [View] -> [Device/Comments]. Devices and comments are both displayed.



(e) In case of IEC, you can see variables with diverse option at 'View' menu like (b)~(d). The following is example selecting 'View Variable/Comment' at IEC type.



2.12 Configuration and Function of Internal Memory


A/D conversion module has the internal memory to transmit/receive data to/from PLC CPU.

2.12.1 I/O area of A/D converted data


I/O area of A/D converted data is as displayed in table.

Device assigned ("S" or "H" type)	Device assigned (IEC type)	Details	R/W	Sign direction
UXY.00.0 UXY.00.F	%UX0.x.0 %UX0.x.15	Module ERROR flag Module READY flag	R	A/D → CPU
UXY.01.0 UXY.01.1 UXY.01.2 UXY.01.3	%UX0.x.16 %UX0.x.17 %UX0.x.18 %UX0.x.19	CH0 Run flag CH1 Run flag CH2 Run flag CH3 Run flag	R	A/D → CPU
UXY.02	%UW0.x.2	Ch0 digital output value	R	A/D → CPU
UXY.03	%UW0.x.3	Ch1 digital output value	R	
UXY.04	%UW0.x.4	Ch2 digital output value	R	
UXY.05	%UW0.x.5	Ch3 digital output value	R	
UXY.11.0	%UX0.x.176	Flag to request error clear	W	CPU → A/D

- In the device assigned, X stands for the Base No. and Y for the Slot No. on which module is installed.
- In order to read 'CH1 digital output value' of A/D conversion module installed on Base No.0, Slot No.4, it shall be displayed as U04.03. (in case of IEC type, %UW0.4.3)




- In order to read 'Flag to detect CH4 disconnection' of A/D conversion module installed on Base No.0, Slot No.5, it shall be displayed as U05.10.4.



Chapter 2 Analogue Input Module


(1) Module Ready/Error flag (U0x.00, x: slot number)

- (a) U0x.00.F: It will be ON when PLC CPU is powered or reset with A/D conversion ready to process A/D conversion.
 (b) U0x.00.0: It is a flag to display the error status of A/D conversion module.




(2) Run channel flag (UXY.01, X: Base No., Y: Slot No.)

The area where Run information of respective channels is saved
 * XGB series base number is 0




(3) Digital output value (UXY.02 ~ UXY.09, X: Base No., Y: Slot No.)

- (a) A/D converted-digital output value will be output to buffer memory addresses UXY.02 ~ UXY.05 (%UW0.x.2 ~ %UW0.x.5) for respective channels.
 (b) Digital output value will be saved in 16-bit binary.
 ※ XGB PLC's base number is 0.




Chapter 2 Analogue Input Module


- (4) Flag to request error clear (() means the case of IEC type, x: slot number)
- (a) If a parameters setting error occurs, address No.22's error code will not be automatically erased even if parameters are changed correctly. At this time, turn the 'error clear request' bit ON to delete address No.22's error code and the error displayed in XG5000's [System Monitor]. In addition, RUN LED which blinks will be back to On status.
- (b) The 'flag to request error clear' shall be used surely together with UXY.00.0 attached thereon for guaranteed Normal operation.
- ※ XGB PLC base number is 0



Flag to request error clear (UXY.11.0)
 Bit ON (1): Error clear request, Bit Off (0): Error clear standing-by



[How to use the flag to request error clear ("S" type or "H" type)]



[How to use the flag to request error clear (IEC type)]

2.12.2 Operation parameters setting area

Setting area of A/D conversion module's Run parameters is as described in Table.

Memory address		Details	R/W	Remark
Hex.	Dec.			
0 _H	0	Channel enable/disable setting	R/W	PUT
1 _H	1	Setting ranges of input voltage/current	R/W	PUT
2 _H	2	Output data format setting	R/W	PUT
3 _H	3	Filter processing enable/disable setting	R/W	PUT
4 _H	4	CH0 filter constant	R/W	PUT
5 _H	5	CH1 filter constant		
6 _H	6	CH2 filter constant		
7 _H	7	CH3 filter constant		
C _H	12	Average processing enable/disable setting	R/W	PUT
D _H	13	Average processing method setting	R/W	
E _H	14	CH0 average value	R/W	
F _H	15	CH1 average value		
10 _H	16	CH2 average value		
11 _H	17	CH3 average value		
16 _H	22	Error code	R/W	GET

※ R/W is to denote Read/Write if available from PLC program.

(1) Setting operation channels

If the channel to use is not specified, all the channels will be set to Prohibited.

bit15 bit14 bit13 bit12 bit11 bit10 bit9 bit8 bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0															
Address 0															
—	—	—	—	—	—	—	—	—	—	—	—	CH. 3	CH. 2	CH. 1	CH. 0

Setting channel to use (bit)
Bit On (1): Run, Bit Off (0): Stop

(2) Setting input range

The range of analogue voltage input is DC 0~10V, the range of analogue current input is DC 4~20mA.


bit15 bit14 bit13 bit12 bit11 bit10 bit9 bit8 bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0															
Address 1															
—	—	—	—	—	—	—	—	—	CH.3	CH.2	CH.1	CH.0			

Setting input range (bit)
→ 00: 0 ~ 10V(4 ~ 20mA)
→ 01: 0 ~ 20mA
→ 11: 4 ~ 20mA

Chapter 2 Analogue Input Module

(3) Setting output data type


- (a) The range of digital output data for analogue input can be specified for respective channels.
 (b) If the output data range is not specified, the range of all the channels will be set to 0 ~ 4000.



Setting output data type (bit)
 → 00: 0 ~ 4000
 → 01: -2000 ~ 2000
 → 10: 0 ~ 1000(400 ~ 2000/0 ~ 2000)
 → 11: 0 ~ 1000

(4) Setting filter process


If the filter process is not specified, the filter process of all channels will not be executed.



Setting filter process (bit)
 Bit On (1): used, bit Off (0): not used


(5) Setting filter constant

When using the filter process, specify the filter constant.



(6) Setting average process

If the average process is not specified, the average process of all channels will not be executed.




Setting average process (bit)
 Bit On (1): used, Bit Off (0): not used

Chapter 2 Analogue Input Module

(7) Setting average process method


This area is used to specify average processing method, where 'count average' and 'time average' are available.



(8) Error code (address 22)

(a) It saves the error code detected from A/D conversion module.

(b) Error type and details is as below.



Error code (Dec.)	Details	Remark
0	Normal operation	RUN LED flickering
50#	Exceeding of filter constant setting range	Flickering RUN LED per 1 second
60#	Exceeding of time average setting range	
70#	Exceeding of Frequency average setting range	
80#	Setting error of analogue input range	

※ # of the error codes stands for the channel with error found.


(c) If 2 or more errors occur, the module will not save other error codes than the first error code found.

(d) If an error found is corrected, use the 'flag to request error clear', or let power OFF → ON in order to stop LED blinking and to delete the error code.

2.13 Example Program

2.13.1 Program to sort A/D converted value in size

(1) System configuration



System information	Assigns Information - Fixed Location	Comment
Base 0: XGB-M08A		Main Base(8 Slots)
CPU: XGB-XBMS		Standard CPU Module(I/O: Maximum 1,024 Points)
Slot 0: Internal Cnet	[P0000 ~ P003F]	Internal Cnet Module, RS-232C/RS-485
Slot 1: XBF_AD04A	[P0040 ~ P007F]	DC 24V Input, Transistor Output, 32 Contacts
Slot 2: Empty slot	[P0080 ~ P011F]	A/D Voltage Input Type(4 Channels)
Slot 3: Empty slot	[P0120 ~ P015F]	
Slot 4: Empty slot	[P0160 ~ P019F]	
Slot 5: Empty slot	[P0200 ~ P023F]	
Slot 6: Empty slot	[P0240 ~ P027F]	
Slot 7: Empty slot	[P0280 ~ P031F]	

(2) Initial setting

No.	Item	Details	Internal memory address	The value to write in internal memory
1	Channel	Ch0, Ch1, Ch2	0	h0007
2	Input voltage range	0 ~ 10 V	1	h0000
3	Output data range	0 ~ 4000	2	h0000
4	Filter process	Ch0	3	h0001
5	Ch0 filter constant	50	4	50
6	Average process	Ch1, Ch2	12	h0006
6	Average process method	Frequency average: Ch1 Time average: Ch2	13	h0100
7	Average value	Frequency average value: 100 (times)	15	100
		Time average value: 200 (ms)	16	200




(3) Program

- If Ch 0's digital value is less than 3000, Contact No. 0 (P00080) of relay output module installed on Slot No.2 will be On.
- If CH 1's digital value is greater than 3200, Contact No.2 (P00082) of relay output module installed on Slot No.2 will be On.
- If CH 2's digital value is greater than or equal to 3000 and less than or equal to 3200, Contact No.4 (P00086) of relay output module installed on Slot No.2 will be On.
- If CH 2's digital value is equal to 3200, Contact No.5 (P00085) of relay output module installed on Slot No.2 will be On.


Chapter 2 Analogue Input Module

(4) Program

(a) Program example using [I/O Parameters]




[Program in case of "S" type or "H" type]




[Program in case of IEC type]


(b) Program example of PUT/GET instruction used



[Program in case of "S" type or "H" type]

Chapter 2 Analogue Input Module






[Program in case of IEC type]

2.14 Troubleshooting


2.14.1 RUN LED flickers




Error code (Dec.)	Error Details	Action
50#	Filter constant setting range exceeded	Change filter constant setting value within 1 ~ 99.
60#	Time average setting range exceeded	Change time average setting value within 4 ~ 16000.
70#	Frequency average setting range exceeded	Change frequency average setting value within 2 ~ 64000.

□ # indicates channel number.

2.14.2 RUN LED is off



2.14.3 A/D conversion value is not normal



2.14.4 Status check of A/D conversion module through XG5000 system monitor

Module type, module information, OS version and module status of A/D conversion module can be checked through XG5000 system monitoring function.


1) Execution sequence

Two routes are available for the execution.

- (1) [Monitor] -> [System Monitoring] -> And on the module screen, click the right mouse button to display [Module Information].
- (2) [Monitor] -> [System Monitoring] -> And Double-click the module screen.

2) Module information


- (1) Module type: shows the information of the module presently installed.
- (2) Module information: shows the OS version information of A/D conversion module.
- (3) O/S version: shows the OS prepared date of A/D conversion module.
- (4) Module status: shows the present error code. (Refer to 7.1 for detailed error codes)



Chapter 3 Analogue Output Module

3.1 Setting Sequence before Operation

Before using the analogue output module, follow steps below.



3.2 Specification

3.2.1 General specifications

Here is the general specification of the analogue output modules.

No.	Items	Specification				Reference	
1	Ambient Temp.	0 ~ 55 °C				-	
2	Storage Temp.	-25 ~ +70 °C					
3	Ambient humidity	5 ~ 95%RH (Non-condensing)					
4	Storage humidity	5 ~ 95%RH (Non-condensing)					
5	Vibration	Occasional vibration			-		IEC61131-2
		Frequency	Acceleration	Pulse width	Times		
		10 ≤ f < 57Hz	–	0.075mm	10 times each direction (X,Y and Z)		
		57 ≤ f ≤ 150Hz	9.8m/s ² (1G)	–			
		Continuous vibration					
		Frequency	Acceleration	Pulse width			
		10 ≤ f < 57Hz	–	0.035mm			
		57 ≤ f ≤ 150Hz	4.9m/s ² (0.5G)	–			
6	Shocks	• Peak acceleration : 147 m/s ² (15G) • Duration : 11ms • Pulse wave type : Half-sine (3 times each direction per each axis)					
7	Impulse noise	Square wave impulse noise	±1,500 V			IMO standard	
		Electrostatic discharge	Voltage: 4kV (Contact discharge)			IEC61131-2 IEC61000-4-2	
		Radiated electromagnetic field noise	27 ~ 500 MHz, 10V/m			IEC61131-2, IEC61000-4-3	
		Fast transient /Burst noise	Classifi- cation	Power supply	Digital/Analogue Input/Output, Communication Interface		IEC61131-2 IEC61000-4-4
			Voltage	2kV	1kV		
8	Operation ambience	Free from corrosive gases and excessive dust				-	
9	Altitude	Less than 2,000m					
10	Pollution degree	Less than 2					
11	Cooling method	Air-cooling					

3.2.2 Performance specifications

Here describes performance specification of analogue output module.


Item		Specification		
		XBF-DV04A	XBF-DC04A	
Analog ue output	Type	Voltage	Current	
	Range	DC 0 ~ 10V (Load resistance: 2kΩ or more)	DC 4 ~ 20mA DC 0 ~ 20mA (Load resistance: 510Ω or less)	
Digital input	Type		12-bit binary data	
	Range	Signed value	0 ~ 4000	0 ~ 4000
		Unsigned value	-2000 ~ 2000	-2000 ~ 2000
		Precise value	0 ~ 1000	400 ~ 2000/0 ~ 2000
		Percentile value	0 ~ 1000	0 ~ 1000
Maximum resolution		2.5mV (1/4000)	5μA (1/4000)	
Accuracy		±0.5% or less		
Maximum conversion speed		1ms/channel		
Absolute maximum output		DC ±15V	DC +25mA	
Number of maximum channel		4 channels		
Insulation method		Photo-coupler insulation between input terminal and PLC power (no insulation between channels)		
Terminal connected		11-point terminal block		
I/O points occupied		Fixed type: 64 points		
Current consump tion	Internal (DC 5V)	110mA	110mA	
	External (DC 21.6 ~26.4V)	70mA	120mA	
Weight		64g	70g	

Remark

Offset and gain about analogue output range have been set at the factory and the user can change them.

3.3 Designations and Functions


Here describes designation and functions.



No.	Description
①	RUN LED It displays the operation status of D/A conversion module - On: Normal operation status - Flickering: Error occurred - Off: Power off or abnormal status of the module
②	Analogue output terminal (Voltage, Current) It is an output terminal to connect an analogue output (Voltage, Current) of each channel to external machinery and tools.
③	External power input terminal It is an external DC 24V input terminal that supplies power for an analogue output (voltage, current).


3.4 Characteristic of I/O Conversion

Characteristic of I/O conversion converts a digital input into an analogue output (voltage, current) and displays a straight line with the gradient as shown below. The range of digital input is shown with Unsigned Value, Signed Value, Precise Value, and Percentile Value such as the graph below.



3.5 Characteristic of Input/Output

The range of a voltage output is DC 0 ~ 10V and a current output is DC 4 ~ 20mA / DC 0 ~ 20mA.



Digital input value toward analogue voltage output is shown below.

Resolution: 2.5mV (1/4000), Accuracy: within $\pm 0.5\%$

The range of digital input	Analogue voltage output						
	under 0V	0V	2.5V	5V	7.5V	10V	over 10V
Unsigned value (-48 ~ 4047)	under 0	0	1000	2000	3000	4000	over 4000
Signed value (-2048 ~ 2047)	under -2000	-2000	-1000	0	1000	2000	over 2000
Precise value (-12 ~ 1011)	under 0	0	250	500	750	1000	over 1000
Percentile value (-12 ~ 1011)	under 0	0	250	500	750	1000	over 1000


Digital input value toward analogue current output is shown below.

Resolution: 5 μ A (1/4000), Accuracy: within $\pm 0.5\%$

The range of digital input	Analogue current output						
	under 4mA	4mA	8mA	12mA	16mA	20mA	over 20mA
Unsigned value (-48 ~ 4047)	under 0	0	1000	2000	3000	4000	over 4000
Signed value (-2048 ~ 2047)	under -2000	-2000	-1000	0	1000	2000	over 2000
Precise value (381 ~ 2018, -24 ~ 2023)	under 400	400	800	1200	1600	2000	over 2000
	under 0	0	500	1000	1500	2000	over 2000
Percentile value (-12 ~ 1011)	under 0	0	250	500	750	1000	over 1000

3.6 Accuracy

Though the range of input is changed, the accuracy for the analogue output values doesn't change. The range of accuracy is displayed at the ambient temperature of $25 \pm 5^\circ\text{C}$ if you select unsigned value as your range of the digital input. The accuracy is satisfied $\pm 0.5\%$.



(1) Accuracy in case of 5V output

$$4000 \times 0.5\% = 20$$

So in case of 5V output, accuracy range is $(5V - 20 \times 0.0025V) \sim (5V + 20 \times 0.0025V) = 4.95V \sim 5.05V$.

(2) Accuracy in case of 10V

$$4000 \times 0.5\% = 20$$

So in case of 10V output, accuracy range is $(4000 - 20) \sim (4000 + 20) = 3980 \sim 4020$.

3.7 Functions of Analogue Output Module

Here describes functions of XBF-DV04A/DC04A module.

Function	Details
Operation channel	1) It sets up Run/Stop of a channel that will operate an analogue output. 2) You can save the time of whole operation by stopping unused channels.
The range of output	1) It sets up the range of an analogue output. 2) Analogue voltage output module offers one range of output (DC 0 ~ 10V) and analogue current output module offers two (DC 4 ~ 20mA, DC 0 ~ 20mA).
The range of input data	1) It sets up the range of a digital input. 2) It offers four ranges of a digital input.
The status of channel output	1) It sets up the output status of a channel when it switches Run to Stop. 2) It offers four types of output status.


3.8 Wiring

3.8.1 Precautions for wiring


- (1) Use separate cable of an A.C. power line and an external output signal of an analogue output module to prevent a surge or inductive noise from the A.C. side.
- (2) Select the cable with consideration of an ambient temperature and a permitted current limit. It is recommended over AWG22 (0.3mm²).
- (3) Don't let the cable at close range to hot devices or materials. And don't bring it into contact with oil for a long time. These are the factors of a short circuit occurs unusual operation or damages devices.
- (4) Check the polarity before external power is supplied to the terminal.
- (5) It may produce inductive hindrance that is a cause of unusual operations or defects if you wire the cable with a high-voltage line or a power line.

3.8.2 Wiring example

(1) Wiring example for analogue voltage output module



(2) Wiring example for analogue current output module



※1: Use a 2-core twisted shielded wire.

3.9 Operation Parameter Setting

You can specify operation parameters of the analogue output module through [I/O parameters] menu in XG5000.

(1) Setting items

For the user's convenience, XG5000 provides GUI (Graphical User Interface) for parameters setting of analogue voltage/current output module.


Followings are available through [I/O parameters] on the XG5000 project window.

Item	Details
[I/O Parameters]	<p>(1) It specifies the following items for the module operation.</p> <ul style="list-style-type: none">- Channel Enable/Disable- Analogue output range- Input type- Channel output type <p>(2) After the parameters that user specified in XG5000 are downloaded, they will be saved to a flash memory in the CPU unit..</p>


(2) How to use [I/O Parameters] menu

(a) Run XG5000 to create a project. (Refer to XG5000 program manual for details on how to create the project)

(b) Double-click [I/O Parameters] on the project window.




(c) Click the slot of the base that contains analogue output module in the [I/O Parameter Setting] window. In the example, the analog output module is contained in the slot 1.




Chapter 3 Analogue Output Module


(d) Click the arrow button then you can see the menu to choose the applicable module. Select the applicable module.



(e) Double-click the applicable slot that is selected for the parameters setting or click [Details].



(f) A screen will be displayed for you to specify parameters for respective channels as shown below. Click a desired item to display parameters to set for respective items.



3.10 Special Module Monitoring Function

You can start to test the analogue output module connecting by [Online] → [Connect] and then click [Monitor] → [Special Module Monitoring] menu in XG5000.

Remark


- 1) If the program is not displayed normally because of insufficient system resource, you may start XG5000 again after close the program and other applications.
- 2) I/O parameters those are specified in the state of [Special Module Monitoring] menu are temporarily set up for the test. They will be disappeared when the [Special Module Monitoring] is finished.
- 3) Testing of [Special Module Monitoring] is the way to test the analogue output module. It can test the module without a sequence program.

3.10.1 How to use special module monitoring

Special module monitoring function is described below based on the analogue voltage output module (XGF-DV04A).


(1) Start of [Special Module Monitoring]

Go through [Online] → [Connect] and [Monitor] → [Special module Monitoring] to start. If the status is not online, [Special Module Monitoring] menu will not be activated.




(2) How to use [Special Module Monitoring]

- (a) Connecting XG5000 with PLC basic unit, [Special Module List] window will show base/slot information and types of special module by click [Monitor] → [Special Module Monitoring]. Special Module List will display the modules that are installed in PLC now.




Chapter 3 Analogue Output Module

- (b) Select a special module then click [Module Info.] button to display the information as described below.




- (c) Click [Monitor] button in the [Special Module List] window to display the [Special Module Monitor] window as below




Chapter 3 Analogue Output Module

(d) [Start Monitoring] button will show you digital input data of the operating channel.



(e) [Test] is used to change the parameters of the voltage output module. You can change the parameters when you click the values at the bottom of the screen. It is only available when XGB CPU unit's status is in [Stop Monitoring].



(f) [Close] is used to escape from the monitoring/test screen.


Chapter 3 Analogue Output Module

3.11 Register U devices (special module variable)


Register the variables for each module referring to the special module information that is set in the I/O parameter. The user can modify the variables and comments.

(1) Registration sequence

- (a) Select a special module type in [I/O Parameter Setting] window.




- (b) Double-click [Variable/Comment] from the project window.



- (c) Select [Edit] → [Register U Device].

In case of IEC, select [Edit] → [Register special module variable]




Chapter 3 Analogue Output Module

(d) Click 'Yes'.



(e) As shown below, the variables are registered.




Chapter 3 Analogue Output Module

(2) Save variables


- (a) The contents of 'View Variables' can be saved as a text file
- (b) Click [Edit] → [Export to File].
- (c) The contents of 'View Variable' are saved as a text file.

(3) View variables in a program


- (a) The example of XG5000 is shown below.



- (b) Select [View] → [Variables]. The devices are changed into variables.



- (c) Select [View] → [Devices/Variables]. Device and variable both are displayed.



Chapter 3 Analogue Output Module

(d) Select [View] → [Devices/Comments]. Device and comment both are displayed.

U01.00.F	MOV	h000F	U01.02
Analog Output Module: Ready			Analog Output Module: Output Status Setting
U01.01.0	MOV	0	U01.02
Analog Output Module: CH0 Active			Analog Output Module: Output Status Setting
U01.01.1	MOV	1500	U01.03
Analog Output Module: CH1 Active			Analog Output Module: CH0 Input
U01.01.2	MOV	2500	U01.05
Analog Output Module: CH2 Active			Analog Output Module: CH2 Input
U01.01.3	MOV	4000	U01.06
Analog Output Module: CH3 Active			Analog Output Module: CH3 Input
			END

3.12 Internal memory

Describes configuration and function of internal memory

3.12.1 Data I/O area


Describes data I/O area of analogue output module

Address ('s', 'h' type)	Address (IEC type)	Description	Details	Remarks
U0x.00	%UW0.x.0	Module Ready / Error	F(15) Bit On(1): Module Ready 0~3 Bit On(1): Channel Error	Read available
U0x.01	%UW0.x.1	CH operation information	Bit On(1): Channel Run Bit Off(0): Channel Stop	
U0x.02	%UW0.x.2	Output setting	Bit On(1): Output Allow Bit Off(0): Output Forbid	Read/Write available
U0x.03	%UW0.x.3	CH0 digital input value	12-bit binary data	
U0x.04	%UW0.x.4	CH1 digital input value		
U0x.05	%UW0.x.5	CH2 digital input value		
U0x.06	%UW0.x.6	CH3 digital input value		

□ In the device assignment, x stands for a slot number that the module is installed


(1) Module Ready/Channel Error information () means deice name of IEC type)

- (a) U0x.00.F (%UX0.x.15): It will be ON when XGB CPU unit is powered or reset with the condition that an analogue output module has prepared to convert.
- (b) U0x.00.0 ~ U0x.00.3 (%UW0.x.0~%UW0.x.3): It is the flags those display error status of each channel in the analogue output module.




(2) Channel operation information

- (a) This area is used to display the channel being used.



(3) Output setting

- (a) Each channel can be specified enable/disable the analogue output.
- (b) If the output is not specified, output of all the channels will be disabled.



(4) Digital input

- (a) Digital input value can be selected and used within the range of -48~4047, -2048~2047, -12~1011 (381~2018/-24~2023), and -12~1011 based on input type.
- (b) If the digital input value is not specified, it will be set to 0.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0	
U0x.03	Digital input Data of CH0																(%UW0.x.3)
U0x.04	Digital input Data of CH1																(%UW0.x.4)
U0x.05	Digital input Data of CH2																(%UW0.x.5)
U0x.06	Digital input Data of CH3																(%UW0.x.6)

Address (‘S’, ‘H’ type)	Address (IEC type)	Details
U0x.03	%UW0.x.3	Digital input value of CH0
U0x.04	%UW0.x.4	Digital input value of CH1
U0x.05	%UW0.x.5	Digital input value of CH2
U0x.06	%UW0.x.6	Digital input value of CH3

3.12.2 Setting area of operation parameters

XBF-DV04A

Address (Dec)	Description	Details	Remarks
0	Set up the run channel	Bit On(1): Run Bit Off(0): Stop	Read/Write available
1	Set up the output voltage range	Bit (00): 0 ~ 10V	
2	Set up the input data type	Bit (00): 0 ~ 4000 Bit (01): -2000 ~ 2000 Bit (10): 0 ~ 1000 Bit (11): 0 ~ 1000	
3	Set up the output type of CH0	0: outputs the previous value 1: outputs the min. value of output range 2: outputs the mid. value of output range 3: outputs the max. value of output range	
4	Set up the output type of CH1		
5	Set up the output type of CH2		
6	Set up the output type of CH3		
11	CH0 setting error	Error code	Read available
12	CH1 setting error		
13	CH2 setting error		
14	CH3 setting error		

XBF-DC04A

Address (Dec)	Description	Details	Remarks
0	Set up the run channel	Bit On(1): Run Bit Off(0): Stop	Read/Write available
1	Set up the output voltage range	Bit (00): 4 ~ 20mA Bit (01): 0 ~ 20mA	
2	Set up the input data type	Bit (00): 0 ~ 4000 Bit (01): -2000 ~ 2000 Bit (10): 400 ~ 2000/0 ~ 2000 Bit (11): 0 ~ 1000	
3	Set up the output type of CH0	0: outputs the previous value 1: outputs the min. value of output range 2: outputs the mid. value of output range 3: outputs the max. value of output range	
4	Set up the output type of CH1		
5	Set up the output type of CH2		
6	Set up the output type of CH3		
11	CH0 setting error	Error code	Read available
12	CH1 setting error		
13	CH2 setting error		
14	CH3 setting error		

(1) Setting up the run channel

If the run channel is not specified, all the channels will be set to Stop.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "0"	-	-	-	-	-	-	-	-	-	-	-	-	C H 3	C H 2	C H 1	C H 0

↓
Run channel (bit)
→ 1: Run
→ 0: Stop

Chapter 3 Analogue Output Module

(2) Setting up the output voltage/current range

The range of analogue output voltage is DC 0 ~ 10V and analogue output current is DC 4 ~ 20mA, DC 0 ~ 20mA.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "1"	-	-	-	-	-	-	-	-	CH 3	CH 2	CH 1	CH 0				

↓
Output range (bit)
→ 00: 0 ~ 10V(4 ~ 20mA)
→ 01: 0 ~ 20mA

(3) Setting up the input data type

(a) Input type can be specified for respective channels.

(b) If input data type is not specified, all the channels will be set to the range of 0 ~ 4000.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "2"	-	-	-	-	-	-	-	-	CH 3	CH 2	CH 1	CH 0				

↓
Input data type (bit)
→ 00: 0 ~ 4000
→ 01: -2000 ~ 2000
→ 10: 0 ~ 1000(400 ~ 2000/0 ~ 2000)
→ 11: 0 ~ 1000

(4) Setting up the output type

(a) It defines an analogue output status when XGB CPU unit is stopped.

(b) The range is 0 ~3 and used devices are regarded as Words.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "3" ~ Address "6"	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Value


Address	Details
3	Set up the output type of CH0
4	Set up the output type of CH1
5	Set up the output type of CH2
6	Set up the output type of CH3

↓
Input data type (bit)
→ 00: Previous value
→ 01: Min. value
→ 10: Mid. value
→ 11: Max. value

Chapter 3 Analogue Output Module

(5) Error code

It displays error codes of each channel.




Address	Details
11	CH0 error
12	CH1 error
13	CH2 error
14	CH3 error

Error code (Dec)	Details	LED status
-	Offset/Gain setting error	Blinks every 2 sec.
31#	Exceed the range of parameter	Blinks every 1sec.
41#	Exceed the range of digital input	


※ # stands for the channel with error found.

Chapter 3 Analogue Output Module

(2) Program example with PUT/GET instruction.




(3) Program example using parameter in case of IEC type




Chapter 3 Analogue Output Module

4) Program example using PUT/GET instruction in case of IEC type



3.14 Troubleshooting


3.14.1 RUN LED flickers




Error Code (Dec.)	Error Details	Action
31#	Parameter range excess error	Adjust parameter setting range
41#	Digital input value range excess error	Adjust digital input value range

□ # indicates channel number.

3.14.2 RUN LED is off



3.14.3 Analogue output value is not normal.



3.14.4 Status check of D/A conversion module through XG5000 system monitor

Module type, module information, O/S version and module status of D/A conversion module can be checked through XG5000 system monitoring function.

(1) Execution sequence

Two routes are available for the execution.

- (a) [Monitor] -> [System Monitoring] -> And on the module screen, click the right mouse button to display [Module Information].
- (b) [Monitor] -> [System Monitoring] -> And Double-click the module screen.


(2) Module information

- (a) Module type: shows the information of the module presently installed.
- (b) Module information: shows the O/S version information of A/D conversion module.
- (c) O/S version: shows the O/S prepared date of A/D conversion module.
- (d) Module status: shows the present error code. (Refer to 3.23 for detailed error codes)

Chapter 4 RTD Input Module

4.1 Setting Sequence before Operation

Before using the RTD input module, follow steps below.



4.2 Specification

4.2.1 General Specifications

Here are the general specifications of the RTD input module.

No.	Items	Specification				Reference	
1	Ambient Temp.	0 ~ 55 °C				-	
2	Storage Temp.	-25 ~ +70 °C					
3	Ambient humidity	5 ~ 95%RH (Non-condensing)					
4	Storage humidity	5 ~ 95%RH (Non-condensing)					
5	Vibration	Occasional vibration			-		IEC61131-2
		Frequency	Acceleration	Pulse width	Times		
		10 ≤ f < 57Hz	—	0.075mm	10 times each direction (X,Y and Z)		
		57 ≤ f ≤ 150Hz	9.8m/s ² (1G)	—			
		Continuous vibration					
		Frequency	Acceleration	Pulse width			
		10 ≤ f < 57Hz	—	0.035mm			
		57 ≤ f ≤ 150Hz	4.9m/s ² (0.5G)	—			
6	Shocks	• Peak acceleration : 147 m/s ² (15G) • Duration : 11ms • Pulse wave type : Half-sine (3 times each direction per each axis)					
7	Impulse noise	Square wave impulse noise	±1,500 V			IMO standard	
		Electrostatic discharge	Voltage: 4kV (Contact discharge)			IEC61131-2 IEC61000-4-2	
		Radiated electromagnetic field noise	27 ~ 500 MHz, 10V/m			IEC61131-2, IEC61000-4-3	
		Fast transient /Burst noise	Classifi- cation	Power supply	Digital/Analogue Input/Output, Communication Interface		IEC61131-2 IEC61000-4-4
			Voltage	2kV	1kV		
8	Operation ambience	Free from corrosive gases and excessive dust				-	
9	Altitude	Less than 2,000m					
10	Pollution degree	Less than 2					
11	Cooling method	Air-cooling					


4.2.2 Performance specifications

Here describes general specifications of RTD input module.

Item		Specifications	
		XBF-RD04A	XBF-RD01A
No. of input channel		4 channels	One channel
Input sensor type	PT100	JIS C1604-1997	
	JPT100	JIS C1604-1981 , KS C1603-1991	
Temperature input range	PT100	-200 ~ 600℃	
	JPT100	-200 ~ 600℃	
Digital output	PT100	-2000 ~ 6000	
	JPT100	-2000 ~ 6000	
	Scaling display	0 ~ 4000	
Accuracy	Normal temp.(25℃)	Within ±0.3%	
	Full temp.(0~55℃)	Within ±0.5%	
Conversion speed		40ms / channel	
Insulation	Channel to Channel	Non-insulation	
	Terminal to PLC Power	Insulation (Photo-Coupler)	
Terminal block		15-point terminal block	
I/O points occupied		Fixed type: 64 points	
Wiring method		3-wire	
Max. number of equipment		7 (when using XBM-DxxxS "S" type) 10 (when using XB(E)C-DxxxH "H" type)	
Function	Filtering	Digital filter (160 ~ 64000ms)	
	Alarm	Disconnection detection	
Current consumption	Inner DC5V	100mA	
	external DC24V	100mA	
Weight		63g	

4.3 Part Names and Functions

Here describes part names and functions.




No.	Name	Descriptions
①	RUN LED	<ul style="list-style-type: none"> ▶ Displays the hardware operation status of XBF-RD04A On: Normal Flickering: Error (0.2s flickering) Off: power disconnected, hardware error
②	ALM LED	<ul style="list-style-type: none"> ▶ Displays the disconnection status of XBF-RD04A (Alarm indication LED) Flickering: Disconnection is detected (1sec flickering) Off: normal operation
③	Terminal block	<ul style="list-style-type: none"> ▶ Terminal block for connecting external RTD temperature sensor
④	External power supply terminal	<ul style="list-style-type: none"> ▶ Terminal for supplying external DC24V
⑤	Connector for extension	<ul style="list-style-type: none"> ▶ Connection connector for connecting extension module

4.4 Temperature Conversion Characteristic


Since RTD sensor has non-linear characteristic, RTD input module linearizes the relationship between input and output in each section.

The graph below is an example to describe the linearization process and is different with graph about sensor temperature input.

(1) PT100: JIS1604-1997



(2) JPT100: JIS C1604-1981, KS C1603-1991



Remark

Non-linear characteristics: The resistance-temperature characteristics for RTD sensor are presented with table (JIS C1604-1997). This characteristics table displays resistance value of the sensor to temperature, namely, the change of the resistance value per increment of 1°C. When the temperature is changed by 1°C, the change of resistance is not in constant width but in different width per section, which is called the non-linear characteristics.

4.5 Conversion Speed

The conversion speed of XGF-RD4A is 40 ms per channel and each channel is converted sequentially, that is, one channel is converted and then the next channel is converted. (Run/stop can be specified independently for each channel.)
The conversion speed includes the time to convert input temperature (resistance value) to digital value and to save the converted digital data into the internal memory.

∴ Processing time = 40ms X Number of the using channels

[Example] 3 channels are used: Processing time = 40ms X 3 = 120ms

4.6 Accuracy

The accuracy of RTD module is described below.

- When the ambient temperature is $25 \pm 5^{\circ}\text{C}$: within $\pm 0.3\%$ of available input range
- When the ambient temperature is 0 to 55°C : within $\pm 0.5\%$ of available input range

Example) PT100 is used and the ambient temperature is normal.

To measure 100°C , the conversion data output range:

$$100^{\circ}\text{C} - [\{ 600 - (-200) \} \times 0.3 \%] \sim 100^{\circ}\text{C} + [\{ 600 - (-200) \} \times 0.3 \%]$$

Namely, $97.6 \sim 102.4 [^{\circ}\text{C}]$

4.7 Temperature Display

(1) The input temperature is converted to digital value down to the one decimal place.

Ex.) If the detected temperature is 123.4°C , its converted value to be saved to the internal memory will be 1234.

(2) Temperature can be converted to Celsius or Fahrenheit scale temperature value as desired.

Ex) If Pt100 sensor is used, the temperature of 100.0°C can be converted to 2120 when Fahrenheit scale is used.

- Conversion $^{\circ}\text{C}$ to $^{\circ}\text{F}$, $F = \frac{9}{5}C + 32$
- Conversion $^{\circ}\text{F}$ to $^{\circ}\text{C}$, $C = \frac{5}{9}(F - 32)$

(3) Maximum temperature input range is higher/lower within 10°C than regular temperature input range. However, the precision will not be guaranteed for any temperature out of regular temperature input range.

Maximum temperature input ranges of sensor are as follows;

- PT100 : $-210.0 \sim 610.0^{\circ}\text{C}$
- JPT100 : $-210.0 \sim 610.0^{\circ}\text{C}$

4.8 Scaling Function


It is used to scale and output the range specified by the user other than temperature range.

- Scaling expression =
$$\frac{(\text{Temperature} \times 10 + 2000)}{2}$$

Ex.) When scaling is allowed and sensor input is 200 °C with PT100 sensor, scaling value is as follows.


$$\text{Scaling value} = \frac{(200 \times 10 + 2000)}{2} = 2000$$

The figure below displays the relation between temperature input and scaling value.



4.9 Disconnection Detection Function

- (1) As a module used to measure the temperature with the RTD temperature sensor directly connected, it detects and displays disconnection of the sensor connected. If any disconnection occurs in the sensor used and extended lead wire, LED (ALM) will flicker in a cycle of 1 second and produce an error code.
- (2) Disconnection can be detected per channel, however, only for the channel specified to run. LED (ALM) is used in common for all the channels. It will flicker if one or more channels are disconnected.
- (3) The figure below shows the temperature sensor's appearance of the 3-wired RTD.
(The appearance depends on sensor type)




- * A disconnection: if disconnected between terminal A and terminal board of the module in the sensor figure.
 - * B disconnection: if disconnected between terminal B (two for 3-wired sensor) and terminal board of the module in the sensor figure, or if A and B lines are all disconnected.
- (4) The basic connection between RTD module and RTD Sensor is based on 3-wired RTD sensor. If 2-wired or 4-wired sensor is used, the connection between the sensor and the module shall be kept as 3-wired. Disconnection will be detected on the basis of 3-wired wiring.
 - (5) In case of disconnection, status of ALD LED and operation of disconnection flag are as follows.
- For disconnection flag, refer to 12.3.14 internal memory.

Connection status	Channel status	ALM LED status	Disconnection flag
Normal	Run	Off	Off
	Stop	Off	Off
A line disconnected or B line disconnected	Run	Flicker (1s)	On
	Stop	Off	Off
Any sensor is not connected	Run	Flicker (1s)	On
	Stop	Off	Off


4.10 Wiring

- 3 types of sensor-connecting methods are available (2, 3 and 4-wired).
- The standard wiring method for XGF-RD4A module is 3-wired wiring.
- Use an identical type of wire (thickness, length, etc.) for each 3 wire when extended lead wire is used.
- The resistance of each conductor is to be less than 10Ω . (If larger than this, it will cause an error.)
- Resistance difference of each conductor is to be less than 1Ω . (If larger than this, it will cause an error.)
- Length of wire is to be as short as possible and it is recommended to connect the wire directly to the terminal block of module without connection terminal unit. If a connection terminal is to be used, compensating wire shall be connected as shown below.


4.10.1 If 2-wired sensor is used (connection terminal unit is used)



4.10.2 If 3-wired sensor is used (connection terminal unit is used)




4.10.3 If 4-wired sensor is used (connection terminal unit is used)



4.11 Filtering Function

Based on the filter value (time-constant) which defines the temperature-converted value of the specified channel, it performs and outputs calculation as below.

$$\text{Filtered temperature} = \frac{(\text{Previously filtered temp.} \times \text{Filter value}_{ms}) + (\text{Presently input temp.} \times 40_{ms} \times \text{Channels used})}{\text{Filter value}_{ms} + (40_{ms} \times \text{Channels used})}$$



- Filtering constant setting range = 160 ~ 64000 [ms]

4.12 Operation Parameter Setting

Operation parameters of RTD module can be specified through [I/O parameters] of XG5000.


4.12.1 Setting items

For the user's convenience, XG5000 provides GUI (Graphical User Interface) for parameters setting of RTD module. Setting items available through [I/O parameters] of the XG5000 project window are described below.


Item	Details
[I/O Parameter]	<p>(1) Specify the following setting items necessary for the module operation.</p> <ul style="list-style-type: none"> - Channel Run/Stop - Sensor type - Filter setting - Scaling setting <p>(2) The data specified by user through S/W package will be saved on the flash memory of RTD module when [I/O Parameters] are downloaded.</p>

4.12.2 How to use [I/O Parameter]

- (1) Run XG5000 to create a project. (Refer to XG5000 programming manual for details on how to create the project)
- (2) Double-click [I/O Parameter] on the project window.




- (3) If [I/O Parameter Setting] screen appears, click Module part at relevant slot and select relevant module.
- (4) On the 'I/O parameters setting' screen, find and click the slot of the base where RTD module is installed on.




Chapter 4 RTD Input Module


- (5) Click the arrow button on the screen to display the screen where an applicable module can be selected. Search for the applicable module to select.



- (6) After the module selected, click [Details] or double-click relevant slot.




- (7) A screen will be displayed to specify parameters for respective channels as shown below. Click a desired item to display parameters to set for respective items.



- (8) The initial values of respective items are as follows.

(a) Channel status setting screen



(b) Input sensor type setting screen

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor type	PT100	PT100	PT100	PT100
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Scaling	Disable	Disable	Disable	Disable

(c) Temp. unit setting screen

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor type	PT100	PT100	PT100	PT100
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Scaling	Disable	Disable	Disable	Disable

(d) Scaling setting screen

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor type	PT100	PT100	PT100	PT100
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Scaling	Disable	Disable	Disable	Disable

(9) If necessary setting is complete, press OK.

(10) Check the check box on the parameter menu to select and change setting of a channel then the setting value of all the channels will be identical to changed setting value. The figure below shows an example with this function that channel status is changed to 'Enable' of all the channels.

Parameter	CH 0	CH 1	CH 2	CH 3
<input checked="" type="checkbox"/> Channel status	Enable	Enable	Enable	Enable
<input type="checkbox"/> Sensor type	PT100	PT100	PT100	PT100
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Scaling	Disable	Disable	Disable	Disable

4.13 Special Module Monitoring

Run Special Module Monitoring by selecting [On-Line] -> [Connect] and [Monitor] -> [Special Module Monitoring]. If the status is not [On-Line], [Special Module Monitoring] menu will not be activated.


Remark

- 1) If the program is not displayed normally because of insufficient system resource, you may start XG5000 again after close the program and other applications.
- 2) I/O parameters those are specified in the state of [Special Module Monitoring] menu are temporarily set up for the test. They will be disappeared when the [Special Module Monitoring] is finished.
- 3) Testing of [Special Module Monitoring] is the way to test the analogue output module. It can test the module without a sequence program.

4.13.1 How to use special module monitoring

- (1) Start of [Special Module Monitoring]


Go through [Online] → [Connect] and [Monitor] → [Special module Monitoring] to start. If the status is not online, [Special Module Monitoring] menu will not be activated.




Chapter 4 RTD Input Module

(2) How to use [Special Module Monitoring]


(a) [Special Module List] window will show base/slot information and types of special module by click [Monitor] → [Special Module Monitoring]. In this list box, the modules that are now installed in PLC system will be displayed.



(b) Select a special module then click [Module Info.] button to display the information as described below.




(c) Select a special module then click [Start Monitoring] button to display the information as described below.




Chapter 4 RTD Input Module

(d) [Start Monitoring]: [Start Monitoring] button will show you digital input data of the operating channel. The figure below is monitoring screen when all channels are Run status.



[Start Monitoring] execution screen

(e) [Test]: [Test] is used to change the parameters of the RTD input module. You can change the parameters when you click the values at the bottom of the screen. It is only available when XGB CPU unit's status is in [Stop].



[Test] execution screen

(g) [Close]: [Close] is used to escape from the monitoring/test screen. When the monitoring/test screen is closed, the max. value, the min. value and the present value will not be saved any more.

Remark


[Test] function is only available when XGB CPU unit's status is in [Stop].

4.14 Register U devices (Special module variable)


Register the variables for each module referring to the special module information that is set in the I/O parameter. The user can modify the variables and comments.

(1) Procedure

(a) Select the special module type in the [I/O Parameter Setting] window.




(b) Double click 'Variable/Comment' from the project window. .




(c) Select [Edit] – [Register U Device].

In case of IEC, select [Edit] – [Register special module variable]




Chapter 4 RTD Input Module

(d) Click 'Yes'.



(e) As shown below, the variables are registered.




(2) Save variables

- The contents of 'View Variable' can be saved as a text file.
- Select [Edit] -> [Export to File].
- The contents of 'View variable' are saved as a text file.


Chapter 4 RTD Input Module

(3) View variables


(a) The example program of XG5000 is as shown below.




(b) Select [View] -> [Variables]. The devices are changed into variables.



(c) Select [View] -> [Devices/Variables]. Devices and variables are both displayed.



(d) Select [View] -> [Device/Comments]. Devices and comments are both displayed.



4.15 Configuration and Function of Internal Memory

Here describes configuration and function of internal memory.

4.15.1 Data I/O area of RTD input module


Data I/O area of RTD input module is as shown below.

Area (‘S’, ‘H’ type)	Area (IEC type)	Details	Content	R/W
U0x.00.0 U0x.00.F	%UX0.x.0 %UX0.x.15	Module ERROR flag Module READY flag	0 Bit On(1): module error F(15) Bit On(1): module normal	R
U0x.01.0 U0x.01.1 U0x.01.2 U0x.01.3	%UX0.x.16 %UX0.x.17 %UX0.x.18 %UX0.x.19	CH0 Run flag CH1 Run flag CH2 Run flag CH3 Run flag	Bit On(1): channel run Bit Off(0): channel stop	R
U0x.01.4 U0x.01.5 U0x.01.6 U0x.01.7	%UX0.x.20 %UX0.x.21 %UX0.x.22 %UX0.x.23	CH0 Disconnection flag CH1 Disconnection flag CH2 Disconnection flag CH3 Disconnection flag	Bit On(1): Disconnection Bit Off(0): Normal	R
U0x.04	%UW0.x.4	CH0 digital output value	Temperature value ×10	R
U0x.05	%UW0.x.5	CH1 digital output value		R
U0x.06	%UW0.x.6	CH2 digital output value		R
U0x.07	%UW0.x.7	CH3 digital output value		R
U0x.08	%UW0.x.8	CH0 scaling value	0 ~ 4000	R
U0x.09	%UW0.x.9	CH1 scaling value		R
U0x.10	%UW0.x.10	CH2 scaling value		R
U0x.11	%UW0.x.11	CH3 scaling value		R

□ In the device assigned, x stands for the slot no. on which module is installed.

(1) Module ready/channel error information () means device name of IEC type)


- (a) U0x.00.F (%UX0.x.15): It will be ON when PLC CPU is powered or reset with A/D conversion ready to process A/D conversion.
- (b) U0x.00.0 ~ U0x.00.3 (%UW0.x.0~%UW0.x.3): It is a flag to display the error status of A/D conversion module.



Chapter 4 RTD Input Module

(2) Channel run/stop information

(a) It displays which channel is being used.



(3) Temperature value

It displays current temperature value. Its form is temperature value ×10.

	bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
U0x.04	CH0 temperature conversion value																(%UW0.x.4)
U0x.05	CH1 temperature conversion value																(%UW0.x.5)
U0x.06	CH2 temperature conversion value																(%UW0.x.6)
U0x.07	CH3 temperature conversion value																(%UW0.x.7)


4.15.2 Operation parameter setting area

Operation parameter setting areas of RTD input module are as follows.

Memory address		Details	R/W	Remark
Hex.	Dec.			
0 _H	0	Channel enable/disable setting	R/W	PUT
1 _H	1	CH0 sensor type setting	R/W	PUT
2 _H	2	CH1 sensor type setting	R/W	PUT
3 _H	3	CH2 sensor type setting	R/W	PUT
4 _H	4	CH3 sensor type setting	R/W	PUT
5 _H	5	Temperature display unit setting	R/W	PUT
6 _H	6	CH0 filter constant setting	R/W	PUT
7 _H	7	CH1 filter constant setting	R/W	PUT
8 _H	8	CH2 filter constant setting	R/W	PUT
9 _H	9	CH3 filter constant setting	R/W	PUT
A _H - 11 _H	10~17	Not used	-	-
12 _H	18	Scaling setting	R/W	PUT
13 _H - 43 _H	19~67	Not used	-	-
44 _H	68	CH0 disconnection information (code)	R/W	GET
45 _H	69	CH1 disconnection information (code)	R/W	GET
46 _H	70	CH2 disconnection information (code)	R/W	GET
47 _H	71	CH3 disconnection information (code)	R/W	GET

(1) Run channel setting

If Run channel is not specified, all channels will be stop status.



(2) Sensor type setting

If it is not specified manually, all channels will be specified as Pt100.

bit15 bit14 bit13 bit12 bit11 bit10 bit9 bit8 bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0	
Address 1	Ch0 sensor type setting
Address 2	Ch1 sensor type setting
Address 3	Ch2 sensor type setting
Address 4	Ch3 sensor type setting

Word	Description
0	Specified as PT100
1	Specified as JPT100

Chapter 4 RTD Input Module

(3) Setting temperature display unit

Unit of temperature conversion value can be specified as Celsius/ Fahrenheit.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Address 5												C	C	C	C
												H	H	H	H
												3	2	1	0

Bit	Description
0	Celsius
1	Fahrenheit

(4) Setting filter constant

If filter constant is not specified or specified as "0", relevant channel is not filtered.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Address 6															
Setting Ch0 filter constant (1~99)															
Address 7															
Setting Ch1 filter constant (1~99)															
Address 8															
Setting Ch2 filter constant (1~99)															
Address 9															
Setting Ch3 filter constant (1~99)															

(5) Setting scaling

It specifies whether scaling function is used or not.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Address 10												C	C	C	C
												H	H	H	H
												3	2	1	0

Bit	Description
0	Scaling function is not used
1	Scaling function is used

(6) Disconnection information




It outputs disconnection information of each channel.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Address 68															
Channel 0 disconnection information (0: normal, 1: sensor A disconnection, 2: sensor B disconnection)															
Address 69															
Channel 1 disconnection information (0: normal, 1: sensor A disconnection, 2: sensor B disconnection)															
Address 70															
Channel 2 disconnection information (0: normal, 1: sensor A disconnection, 2: sensor B disconnection)															
Address 71															
Channel 3 disconnection information (0: normal, 1: sensor A disconnection, 2: sensor B disconnection)															

4.16 Example Program

- Here describes how to specify the operation condition of RTD input module.
- RTD input module is installed on slot 2.
- Initial setting condition is that with one input, initial setting value is saved in internal memory of module.
- The following program is an example to read temperature value and disconnection information.

(1) Program example using [I/O Parameter Setting]




Chapter 4 RTD Input Module

(2) Program example using PUT/GET command




(3) Program example using parameter in case of IEC




Chapter 4 RTD Input Module

(4) Program example using PUT/GET function block inn case of IEC




4.17 Trouble Shooting


4.17.1 RUN LED flickers




4.17.2 RUN LED is off



4.17.3 ALM (Alarm) LED flickers



4.17.4 Temperature conversion value is not normal.



4.17.5 Stats check of RTD input module through XG5000 system monitor

Module type, module information, O/S version and module status of RTD input module can be checked through XG5000 system monitoring function.

(1) Execution sequence

Two routes are available for the execution.

- (a) [Monitor] -> [System Monitoring] -> And on the module screen, click the right mouse button to display [Module Information].
- (b) [Monitor] -> [System Monitoring] -> And Double-click the module screen.

(2) Module information

- (a) Module type: shows the information of the module presently installed.
- (b) Module information: shows the O/S version information of module.
- (c) O/S version: shows the O/S prepared date of module.
- (d) Module status: shows the present error code.

Chapter 5 Thermocouple Input Module

5.1 General

Here describes specification, handling, programming of XGB thermocouple input module (XBF-TC04S).

Thermocouple input module is used to convert the temperature data detected from thermocouple to signed 16 bit data.

5.1.1 Characteristic

(1) Module selection according to purpose

XBF-TC04S: 4 channel input (Insulation between channels by photo-moth relay)

(2) Four kinds of thermocouple available (K / J / T / R)

Available to select the different thermocouple according to each channel

(3) Disconnection detection

If thermocouple is disconnected, it is detected and indicated.

(4) Celsius (°C)/ Fahrenheit (°F) type available

Temperature conversion data of **Celsius (°C)/ Fahrenheit (°F)** is indicated down to one decimal place

(5) Temperature data scaling function

(Available to use it as additional data than temperature indication)

Scaling conversion of temperature data is available within -32,768~32,767/0~65,535.

(6) Various additional function

Filter process, Average process (time/count/moving), Max./Min. detection process

(7) Parameter setting / Monitoring by GUI (Graphical user interface) method

It enhanced user-friendly features by changing to I/O parameter settings (intensify user interface) from parameter settings by previous instructions.

By [I/O Parameter], the sequence program can be reduced and by [Special Module Monitoring], it is easy to monitor the temperature conversion value.


5.1.2 Required version

When making the system, the version below is required.

Basic unit type	Classification	Required version
'S', 'H' type	XGB basic unit	Ver 1.8 or above
	XG5000	Ver 2.2 or above
IEC type	XGB basic unit (IEC type)	Ver 1.0 or above
	XG5000	Ver 3.0 or above

5.1.3 Setting sequence before operation

Before using the thermocouple input module, follow steps below.



5.2 Specification

5.2.1 General specification

General specifications are as follows.

No.	Items	Specification				Related standards
1	Operating temp.	0 ~ 55 °C				
2	Storage temp.	-25 ~ +70 °C				
3	Operating humidity	5 ~ 95%RH (Non-condensing)				
4	Storage humidity	5 ~ 95%RH (Non-condensing)				
5	Vibration	For discontinuous vibration			-	IEC61131-2
		Frequency	Acceleration	Amplitude	Number	
		10 ≤ f < 57Hz	-	0.075mm	Each 10 times in X,Y,Z directions	
		57 ≤ f ≤ 150Hz	9.8m/s ² (1G)	-		
		For continuous vibration				
		Frequency	Acceleration	Amplitude		
		10 ≤ f < 57Hz	-	0.035mm		
		57 ≤ f ≤ 150Hz	4.9m/s ² (0.5G)	-		
6	Shocks	<ul style="list-style-type: none">Max. impact acceleration : 147 m/s²(15G)Authorized time : 11msPulse wave : Sign half-wave pulse (Each 3 times in X,Y,Z directions)				IEC61131-2
7	Noise	Square wave impulse noise	±1,500 V			IMO standard
		Electrostatic discharging	Voltage : 4kV(contact discharging)			IEC61131-2 IEC61000-4-2
		Radiated electromagnetic field noise	27 ~ 500 MHz, 10V/m			IEC61131-2, IEC61000-4-3
		Fast Transient /burst noise	Class	Power module	Digital/ Analogue I/O communication interface	IEC61131-2 IEC61000-4-4
			Voltage	2kV	1kV	
8	Ambient conditions	No corrosive gas or dust				
9	Operating height	2000m or less				
10	Pollution degree	2 or less				
11	Cooling type	Natural air cooling				

5.2.2 Performance Specification

Performance specifications are as follows

Items		Specification
Number of input channel		4 channels
Type of input sensor		Thermocouple K / J / T / R type JIS C1602-1995
Range of input temperature	K	-200.0℃ ~ 1300.0℃
	J	-200.0℃ ~ 1200.0℃
	T	-200.0℃ ~ 400.0℃
	R	0.0℃ ~ 1700.0℃
Digital output	Temp. display	Displaying down to one decimal place – note1) K, J, T type: 0.1℃, R type: 0.5℃
	Scaling display (user-defined scaling)	Unsigned scaling (0 ~ 65535) Signed scaling (-32768 ~ 32767)
	Ambient temperature(25℃)	Within ±0.2% – note 2)
Accuracy	Temp. coefficient (range of operating temp)	±100 ppm/℃
	Conversion velocity	50ms / channel
Insulation	Insulation method	Terminal – inner circuit
		Terminal – operating power
		Between channels
	Insulation pressure	
	Insulation resistance	
Standard contact point compensation		Auto compensation by RJC sensing (Thermistor)
		Compensation amount
Warming-up time		15 min or above –note 3)
Terminal block		11 point terminal
I/O occupied points		64 points
Max. number of equipment		7 (when using XBM-DxxxS “S”) 10 (when using XB(E)C-DxxxH “H”)
Additional function	Filter process	
	Average process	Digital filter (200 ~ 64,000ms)
		Time average (400~64,000ms)
		Count average (2~64,000 times)
		Moving average (2~100)
	Alarm	
	Max./Min. display	
Consumption current	Scaling function	
	Inner DC5V	
	External DC24V	
Weight		63g


Chapter 5 Thermocouple Input Module

Note1), Note2) For more detail specification, refer to 5.2.6 accuracy/resolution.

Note 3) Warming-up time: for stability of measured temperature, 15 min is necessary after power is on.

5.2.3 Name of part and function

Respective designations of the parts are as described below




No.	Name	Description
①	RUN LED	<ul style="list-style-type: none"> ► Displays the status of thermocouple input module On: operation normal Flickering: Error occurs (0.2s flickering) Off: power Off or module error
②	ALM LED	<ul style="list-style-type: none"> ► Displays the disconnection status of thermocouple input module (Alarm indication LED) Flickering: Disconnection error occurs (1s flickering) Off: operation normal
③	Terminal block	<ul style="list-style-type: none"> ► Terminal block for wiring to connect the thermocouple (K, J, T, R type)
④	External power supply terminal	<ul style="list-style-type: none"> ► Terminal for supply of external DC24V
⑤	Connector for extension	<ul style="list-style-type: none"> ► Connection connector for connecting the extension module
⑥	Reference junction compensator	<ul style="list-style-type: none"> ► Thermistor for reference junction compensation (RJC)


5.2.4 Characteristic of thermocouple temperature conversion

Thermocouple input module connect 4 kinds of thermocouple directly, input characteristic are as described below.


(1) Thermocouple K (JIS C1602-1995): -200 °C(-5891 μ V) ~ 1300 °C(52410 μ V)




(2) Thermocouple J (JIS C1602-1995): -200 °C(-7890 μ V) ~ 1200 °C(69553 μ V)



(3) Thermocouple T (JIS C1602-1995): -200 °C(-5603 μV) ~ 400 °C(20872 μV)



(4) Thermocouple R (JIS C1602-1995): 0 °C(0 μV) ~ 1700 °C(20222 μV)



Remark

Thermocouple characteristics: thermocouple sensor measures temperature by using fine voltage (electromotive force), which occurs when applying temperature gradient to a junction between two different metals.

The temperature-electromotive force relation specification of normal thermocouple sensor provides the electromotive force, which is measured when a sensor's measuring point is at 0 °C. On that account, when measuring temperature by using thermocouple sensor, cold junction compensation (reference junction compensation, RJC) is used. (built-in function of temperature measuring module).

(5) Temperature conversion characteristic

Thermocouple input module converts the thermocouple input with non-linear characteristics into A/D and outputs the temperature conversion that is linearly treated.

Temperature conversion to thermocouple input has non-linear characteristics.

Remark


Non-linear characteristics: regarding the relation of temperature(°C) and electromotive force(μV) of a thermocouple sensor, electromotive force is different by sections even though temperature changes by a certain amount, which is called 'non-linear characteristics.' As seen in the above graph, it is shown that the relation of temperature and electromotive force is a curve by temperature sections. The module processes the non-linear characteristics table as linear.

5.2.5 Temperature display


- (1) Temperature is displayed down to one decimal place.

In the XG5000, when monitoring the temperature conversion value, select "Signed decimal" According to monitor indication type, temperature is monitored like figure below.

Ex.) if displaying -123.0 by converting, the value stored in the internal memory would be -1230.



Monitor indication type	Indication contents
Unsigned decimal	64306
Signed decimal	-1230 (-123.0°C)
Hexadecimal	hFB32
As instruction	64306



- (2) Temperature display unit

- (a) K, J, T type: 0.1°C
- (b) R type: 0.5°C

- (3) Temperature may be displayed by Celsius or Fahrenheit, depending on the settings.

Ex.) if displaying 100 in Fahrenheit, it would be 212°F by using the following formula.

(a) From Celsius to Fahrenheit degree $F = \frac{9}{5}C + 32$

(b) From Fahrenheit to Celsius degree $C = \frac{5}{9}(F - 32)$

5.2.6 Accuracy / Resolution

Accuracy / Resolution are as follows according to ambient temperature

Thermocouple type	Measurement temperature range	Indication temperature range	Accuracy - note1)		resolution
			Normal temperature (25℃)	Operating temperature - note2) (0℃ ~ 55℃)	
K	-200.0℃ ~ 1300.0℃	-270.0℃ ~ -200.0℃	- note3)		
		-200.0℃ ~ 0.0℃	±3.0℃	±7.5℃	0.2℃
		0.0℃ ~ 1300.0℃	±3.0℃	±7.5℃	0.1℃
		1300.0℃ ~ 1372.0℃	- note3)		
J	-200.0℃ ~ 1200.0℃	-210.0℃ ~ -200.0℃	- note3)		
		-200.0℃ ~ -100.0℃	±2.8℃	±7.0℃	0.2℃
		-100.0℃ ~ 1200.0℃	±2.8℃	±7.0℃	0.1℃
T	-200.0℃ ~ 400.0℃	-270.0℃ ~ -200.0℃	- note3)		
		-200.0℃ ~ 400.0℃	±1.2℃	±3.0℃	0.1℃
R	0.0℃ ~ 1700.0℃	-50.0℃ ~ 0.0℃	- note3)		
		0.0℃ ~ 1700.0℃	±3.5℃	±8.5℃	0.5℃
		1700.0℃ ~ 1768.0℃	- note3)		

Note1) Total accuracy (normal temp.) = accuracy (normal temp.) + cold junction compensation accuracy
= ±(full scale X 0.2% + 1.0℃)

Cold junction compensation accuracy = ±1.0℃

Note2) Temp. coefficient: ±100 ppm/℃

Note3) Measuring the temp. is available, but accuracy and resolution is not guaranteed.

(1) When ambient temp. is normal (25 ± 5℃): within the ±0.2% range of measurement temp.

(2) When ambient temp. is operating temp. (0 ~ 55℃): within the ±0.5% range of measurement temp.

Ex.) When K type thermocouple is used and ambient temperature is normal.

In case of measuring 1000℃ temperature, output range of conversion data is

1000℃ - [(1300 - (-200)) x 0.2 %] - 1 ~ 1000℃ + [(1300 - (-200)) x 0.2 %] + 1

namely, 996.0 ~ 1004.0 [℃].

Note

- (1) For stabilization of measurement temperature, warming-up time more than 15 min. is necessary, after restart.
- (2) If ambient temperature changes rapidly, measurement temperature may change temporally. Keep the ambient temperature steady for stabilization of measuring temperature.
- (3) If wind of the cooling fan contacts with module directly in the panel, accuracy decreases. Do not contact with wind directly.

5.2.7 Conversion velocity


- (1) Conversion velocity per channel: 50ms/channel
- (2) Sequential process method
The next channel is converted after conversion of one channel is completed.
(Run/Stop of the respective channels can be set independently.)
- (3) Concept of conversion time

The conversion velocity of XGF-TC4S module is a cycle that the temperature (electromotive force) entered into terminal strip is converted into digital value and stored in internal memory.

Conversion time increase by a multiple of the no. of used channels

\therefore Conversion time = 50ms X no. of used channels

Ex.) In case 3 channels is used: conversion time = 50ms X 3 = 150ms



5.3 Function

5.3.1 Disconnection detection function

Thermocouple input module has a function to detect the disconnection and display it. That the module detects and displays disconnection means that the following cabling path would have partially bad connection, which requires taking measures

- (1) Disconnection occurs between a sensor used/compensating cable and module, LED(ALM) flickers every second and generates error code.
- (2) Disconnection can be detected by channels. However, it is available for the only channel(s) designated for operation. LED (ALM) is commonly used for every channel. It flickers in case even only one channel is disconnected.

Thermocouple connection status	Channel run	ALM LED status	Disconnection flag
Normal	Run	Off	Off
	Stop	Off	Off
Thermocouple disconnection	Run	Flickering (1s)	On
	Stop	Off	Off

- (3) In case disconnection occurs, disconnection flag of each channel will be turned on and in case disconnection is canceled, it will be turned off.

Disconnection flag	Contents
U0x.01.4	Ch. 0 disconnection
U0x.01.5	Ch. 1 disconnection
U0x.01.6	Ch. 2 disconnection
U0x.01.7	Ch. 3 disconnection

- (4) When disconnection occurs, the min value among range is displayed.

Type	Displayed temperature in case of disconnection
K type	-270.0℃
J type	-210.0℃
T type	-270.0℃
R type	-50.0℃

5.3.2 Scaling function


Thermocouple input module has a function to scale value in user-defined range besides temperature display.

The scope is classified into two types; 16 bits data type, -32768~32767 and 16 bits data type without mark, 0~65535.

If a user selects one of these two types and sets the range, it displays the temperature through scaling operation.

Scaling data type	Scaling min. value	Scaling max. value
Signed value	-32768 ~ [Scaling max. value -1]	[Scaling min. value+1] ~ 32767
Unsigned value	0 ~ [Scaling max. value-1]	[Scaling min. value+1] ~ 65535

The following graph indicates relation between scaled value and temperature input.



$$\text{Scaling operation: } Y = \frac{(Y1 - Y0)}{(X1 - X0)}(X - X0) + Y0$$

X = Temperature value

X0 = Thermocouple measurement min. temperature value

X1 = Thermocouple measurement max. temperature value

Y0 = Scaling min. value

Y1 = Scaling max. value

Y = Scaling

Ex.) If scaling with mark is set with -2000 ~ 13000 and the temperature measured K type sensor is 500.0℃, the value scaled is as follows.


- Scaling conversion value = $\frac{(13000 - (-2000))}{(1300 - (-200))}(500 - (-200)) + (-200) = 5000$

5.3.3 Filter function

By means of filter value (time constant 63.2%) setting temperature conversion of a designated channel, it operates and outputs as follows.

$$\text{Filtered temp. value} = \frac{(\text{previously filtered temp. value} \times \text{filter value}_{\text{ms}}) + (\text{present input temp. value} \times 50_{\text{ms}} \times \text{No. of channel used})}{\text{Filter value}_{\text{ms}} + (50_{\text{ms}} \times \text{No. of channels used})}$$


Filter constant setting range = 200 ~ 64000 [ms]



5.3.4 Average function

(1) Time average

It accumulates temperature conversion values of a selected channel and displays the average of the total sum in digital data.




Setting range of average time = 400 ~ 64000 [ms]

Frequency of average process for a preset time can be calculated as follows.

$$\text{Average Process Frequency [times]} = \frac{\text{Average time}_{ms}}{\text{No. of channel used} \times 50_{ms}}$$

(2) Averaged frequency

It accumulates temperature conversion values of a selected channel as many as frequency and displays the average of the total sum in digital data.



Setting range of average frequency = 2 ~ 64000 [times]


Average process interval of channel used can be calculated as follows

$$\text{Average process interval}[ms] = \text{Average frequency} \times \text{No. of channel used} \times 50[ms]$$

(3) Moving average

It accumulates temperature conversion values of a selected channel as many as set and displays the average of the total sum in digital data. In case of the moving average, it outputs average per scan.

Setting range of average number = 2 ~ 100




Remark

- (1) time/frequency average characteristically does not output temperature data every conversion time and instead, it keeps a feature to maintain the previous status until it reaches time/average frequency.
- (2) In case of moving average, it outputs the converted temperature as taking temperature history and average, which are entered previously, every conversion time, so it can obtain relatively faster data response than time/frequency average.
- (3) Filtering can be processed with one of the foresaid averaging functions simultaneously. If simultaneous process is selected, filtering would be processed first and it averages and output temperature value in digital value. At the moment, the digital data output (temperature) is displayed as the value gained after the final process.

5.3.5 Max./Min. display

It displays maximum/minimum value of temperature conversion value of a selected channel for a selected section (a section allowed for max./min. search)

Status of command allowing/prohibiting max./min. search



5.4 Installation and Wiring

5.4.1 Installation environment

Although the device can be installed with high reliance regardless of installation environment, attention should be paid to the followings in order to secure the reliance and stability of the system.

(1) Environmental Conditions

- (a) Install on a water-proof and dust-proof control board.
- (b) Place free of continuous impact or vibration.
- (c) Place not directly exposed to direct sunrays.
- (d) Place where dew does not form due to rapid temperature change.
- (e) Place where ambient temperature is maintained between 0 - 55℃.

(2) Installation Construction

- (a) In case of screw hole processing or wiring construction, wiring dregs should not go into PLC.
- (b) Install on a position easy to access.
- (c) Should not install on the same panel which high voltage device is installed on.
- (d) It should be 50mm and longer distant from duct and modules.
- (e) Should ground in the environment where is not interrupted from noise.
- (f) Install not to contact with cooling pan in the panel

(3) Cautions in handling

It describes caution in handling from unpacking module to installation.

- (a) Do not fall or apply excessive impact on it.
- (b) Never attempt to separate PCB from the case.
- (c) Make sure that any impurities including wiring dregs should not go into the upper part of module during wiring work.
- (d) Never attempt to attach or detach the module when it is turned on.

5.4.2 Wiring

(1) Cautions in wiring

- (a) Do not place AC power line close to the AUX signal line of the module. To avoid surge or induced noise occurring from AC, make sure to leave a proper space.
- (b) Cable should be selected by considering ambient temperature and allowable current and the specification of cable should be as follows.


Cable specification	
Lower limit	Upper limit
0.18mm ² (AWG24)	1.5 mm ² (AWG16)

- (c) If cable is placed too close to any heating device or materials or if it directly contacts oil and similar materials for a long time, it may cause short-circuit, resulting in breakdown and malfunction.
- (d) Check the polarities during terminal strip wiring
- (e) Wiring with high voltage cable or power line may cause induction problem, causing malfunction or trouble.
- (f) External DC24V power should be same with power of XGB. If external DC24 V power of thermocouple input module is turned on/off while power of XGB main unit is on, temperature input value may have an error.
- (g) Thermocouple input module may use 4 types of thermocouple sensors. (K / J / T / R)

Chapter 5 Thermocouple Input Module

(2) Terminal array


Terminal array of thermocouple input module is as follows.



(3) Wiring example

Thermocouple can be connected with module directly. If point where temperature is measured is far from the module, use the compensating cable to connect

(The compensating cables are different according to thermocouple type. For more information about the compensating cable, contact the producer of thermocouple.)



1) In case sensor and compensating cable are shielded, shield connection is possible to PLC FG terminal.

2) It is necessary to use extension terminal block of which material is kept at uniform temperature in order to reduce error.

3) Compensating cable should use the same type of sensor, which was used for measuring.

5.5 Operation Setting and Monitor

5.5.1 Operation Parameter Setting

Operation parameter of thermocouple input module can be set through [I/O Parameter] of XG5000.

(1) Setting items


For user convenience, parameter setting of thermocouple input module is provided by GUI (Graphical User Interface) method in the XG5000. The items which can be set through [I/O Parameter] in the project window are as follows.

Items	Content
[I/O Parameter]	<p>(a) Sets the following items for operation of module.</p> <ol style="list-style-type: none">1) Channel status (Disable / Enable)2) Sensor status (K / J / T / R)3) Filter constant4) Average processing (Sampling / Time-Avr. / Count-Avr. / Moving-Avr.)5) Scaling data type (Bipolar / Unipolar)6) Scaling min./max. value <p>(b) The parameter set by the user is saved in the flash memory of XGB main unit after download.</p>

(2) How to use [I/O Parameter]


(a) Execute the XG5000 and make the project.
(For how to make the project, refer to the XG5000 user manual)

(b) Double-click [I/O Parameter] on the project window.




Chapter 5 Thermocouple Input Module


(c) If [I/O Parameter Setting] window shows, find slot of base where module is installed and click it.



(d) Register the module on a slot where module is installed on as follows.




(e) Select a module registered and click [Details] or double-click a module




Chapter 5 Thermocouple Input Module

(f) Select the required settings in Parameter Settings and click [OK].




(g) The initial values of each item are as figure shown below

1) Channel status (Disable / Enable)



2) Sensor status (K / J / T / R)



3) Temp. unit (Celsius / Fahrenheit)

XBF-TC04S (TC, 4-CH)

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	Celsius	0	0	0
<input type="checkbox"/> Average processing	Fahrenheit	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

OK Cancel

4) Filter constant (0, 200 ~ 64000)

XBF-TC04S (TC, 4-CH)

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

0, 200~64000 OK Cancel

5) Average processing (Sampling / Time-Avr / Count-Avr / Moving-Avr)

XBF-TC04S (TC, 4-CH)

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	Sampling	0	0	0
<input type="checkbox"/> Scaling data type	Time-Avr	Bipolar	Bipolar	Bipolar
Scaling min. value	Count-Avr	-32768	-32768	-32768
Scaling max. value	Moving-Avr	32767	32767	32767

OK Cancel

6) Scaling data type (Bipolar / Unipolar)

XBF-TC04S (TC, 4-CH)

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	Bipolar	-32768	-32768	-32768
Scaling max. value	Unipolar	32767	32767	32767

OK Cancel

7) Scaling min. value/scaling max. value

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

-32768~32766

OK Cancel

Scaling data type	Scaling min value	Scaling max value
With sign	-32768 ~ [scaling max value -1]	[scaling min value+1] ~ 32767
Without sign	0 ~ [scaling max value -1]	[scaling min value+1] ~ 65535

(h) Constant input

- 1) In case the user inputs numbers directly like filter constant, if the relevant parameter is selected, available range is displayed in the bottom.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

0, 200~64000

OK Cancel


- 2) If the number is out of range, error message is displayed.
(If error information shows, it returns to previous status. Set again.)

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

0, 200~64000

OK Cancel

- 3) If the wrong number is specified, it is displayed with red color.
(When Average value or scaling min./max. value is out of range.)



5.5.2 Special module monitoring function

While XG5000 is connected with PLC, through [Monitor] -> [Special Module Monitoring], the user can test the operation of the analogue output module.


Remark

- 1) If system resource is short, the screen may not be displayed properly. In case of this, shut down other application program and restart the XG5000.
- 2) On the [Special Module Monitoring] status, I/O parameter is set temporarily to execute the test. So if [Special Module Monitoring] status ends, I/O parameter is not saved.
- 3) By test function of [Special Module Monitoring], the user can check if analogue module operates properly or not without any sequence program.

(1) How to use special module monitoring

(a) Start of [Special Module Monitoring]


While XG5000 is connected with PLC, start [Monitor] -> [Special Module Monitoring]. If that is not online status, [Special Module Monitoring] is not activated.




Chapter 5 Thermocouple Input Module

(b) How to use [Special Module Monitoring]


- 1) Click [Monitor] -> [Special Module Monitoring] while XG5000 is connected with PLC basic unit. 'Special Module List' screen is displayed as shown below and displays information of base/slot with special module type. On the list dialog box, The modules currently equipped at the PLC are displayed.



- 2) Clicking [Module Info.] shows the information of special module.



- 3) Clicking [Monitor] shows the following screen.



Chapter 5 Thermocouple Input Module

- 4) [Start Monitoring]: [Start Monitoring] button will show you digital input data of the operating channel. The figure below is monitoring screen when all channels are Run status.

Monitoring screen

Item	CH 0	CH 1
Temperature value	264	263
Scaling value	-22876	-22880
Min. temp value	0	0
Max. temp value	0	0

Item	CH 2	CH 3
Temperature value	271	271
Scaling value	-22846	-22846
Min. temp value	0	0
Max. temp value	0	0

FLAG Monitor

Detail of channel 0

Item	Setting value	Current value
Channel	CH 0	
Channel status	Disable	Enable
Sensor type	K	K
Temp. unit	Celsius	Celsius
Filter constant	0	0
Average processing	Sampling	Sampling
Average value	0	0
Scaling data type	Bipolar	Bipolar
Scaling min. value	-32768	-32768
Scaling max. value	32767	32767

Stop Monitoring Test Close

[Start Monitoring] execution screen

- 5) [Test]: [Test] is used to change the parameters of the Thermocouple input module. You can change the parameters when you click the values at the bottom of the screen. It is only available when XGB CPU unit's status is in [Stop].

Test

Item	CH 0	CH 1
Temperature value	278	0
Scaling value	-22815	0
Min. temp value	0	0
Max. temp value	0	0

Item	CH 2	CH 3
Temperature value	0	0
Scaling value	0	0
Min. temp value	0	0
Max. temp value	0	0


FLAG Monitor

Item	Setting value	Current value
Channel	CH 0	
Channel status	Enable	Enable
Sensor type	K	K
Temp. unit	Celsius	Celsius
Filter constant	0	0
Average processing	Sampling	Sampling
Average value	0	0
Scaling data type	Bipolar	Bipolar
Scaling min. value	-32768	-32768
Scaling max. value	32767	32767

Stop Monitoring Test Close


[Test] execution screen

- 6) If [Flag Monitor] is selected on the [Special Module Monitor] window, [Temp. Measuring Module Command] screen can be monitored.



[Temp. Measuring Module Command] execution screen

- 7) [Temp. Measuring Module Command] screen
On the monitoring screen, Channel status (Run/Stop) and Sensor status (Normal/Disconnection) can be monitored.
On the flag command screen, Max/Min active (ENABLE/DISABLE) and cold junction compensation (ENABLE/DISABLE) can be specified.



- 8) [Close]: [Close] is used to escape from the monitoring/test screen. When the monitoring/test screen is closed, the max. value, the min. value and the present value will not be saved any more.

Remark


[Test] function is only available when XGB CPU unit's status is in [Stop].

5.5.3 Register U devices (Special module variable)


Register the variables for each module referring to the special module information that is set in the I/O parameter. The user can modify the variables and comments.

(1) Procedure

(a) Select the special module type in the [I/O Parameter Setting] window.




(b) Double click 'Variable/Comment' from the project window.




(c) Select [Edit] – [Register U Device].

In case of XEC, select [Edit] - [Register special module variable]




Chapter 5 Thermocouple Input Module

(d) Click 'Yes'. The previous comment will be deleted.



(e) As shown below, the variables are registered.




Chapter 5 Thermocouple Input Module

(2) Save variables


- (a) The contents of 'View Variable' can be saved as a text file.
- (b) Select [Edit] -> [Export to File].
- (c) The contents of 'View variable' are saved as a text file.

(3) View variables


- (a) The example program of XG5000 is as shown below.




- (b) Select [View] -> [Variables]. The devices are changed into variables.



- (c) Select [View] -> [Devices/Variables]. Devices and variables are both displayed.



(d) Select [View] -> [Device/Comments]. Devices and comments are both displayed.



5.6 Configuration and Function of Internal Memory

It describes the configuration and function of internal memory.

5.6.1 Data I/O area (U device)

(1) Data sent from module to XGB main unit (XGB PLC input area, read only)

Device assignment	Type	Comment	Content	R/W	Signal direction
U0x.00.0	BIT	CH 0 offset/gain adjustment error	On: error, Off: normal	R	TC→CPU
U0x.00.1	BIT	CH 1 offset/gain adjustment error		R	
U0x.00.2	BIT	CH 2 offset/gain adjustment error		R	
U0x.00.3	BIT	CH 3 offset/gain adjustment error		R	
U0x.00.D	BIT	Module offset/gain backup error		R	
U0x.00.E	BIT	Module H/W error		R	
U0x.00.F	BIT	Module Ready	On: ready Off: not ready	R	TC→CPU
U0x.01.0	BIT	CH 0 running	Channel running On: run, Off: stop	R	
U0x.01.1	BIT	CH 1 running		R	
U0x.01.2	BIT	CH 2 running		R	
U0x.01.3	BIT	CH 3 running		R	
U0x.01.4	BIT	CH 0 disconnection	Thermocouple sensor On: disconnection, Off: normal	R	
U0x.01.5	BIT	CH 1 disconnection		R	
U0x.01.6	BIT	CH 2 disconnection		R	
U0x.01.7	BIT	CH 3 disconnection		R	
U0x.01.8	BIT	CH 0 setting error	Parameter setting On: setting error Off: setting normal	R	
U0x.01.9	BIT	CH 1 setting error		R	
U0x.01.A	BIT	CH 2 setting error		R	
U0x.01.B	BIT	CH 3 setting error		R	
U0x.04	WORD	CH 0 temp. conversion value	Temp. conversion value (Measured temp.x10)	R	TC→CPU
U0x.05	WORD	CH 1 temp. conversion value		R	
U0x.06	WORD	CH 2 temp. conversion value		R	
U0x.07	WORD	CH 3 temp. conversion value		R	
U0x.08	WORD	CH 0 scaling operation value	Range with sign: -32768~32767 Range without sign: 0~65535	R	TC→CPU
U0x.09	WORD	CH 1 scaling operation value		R	
U0x.10	WORD	CH 2 scaling operation value		R	
U0x.11	WORD	CH 3 scaling operation value		R	
U0x.12	WORD	CH 0 min. temp. conversion value	Temp. conversion min./max. accumulation	R	TC→CPU
U0x.13	WORD	CH 0 max. temp. conversion value		R	
U0x.14	WORD	CH 1 min. temp. conversion value		R	
U0x.15	WORD	CH 1 max. temp. conversion value		R	
U0x.16	WORD	CH 2 min. temp. conversion value		R	
U0x.17	WORD	CH 2 max. temp. conversion value		R	
U0x.18	WORD	CH 3 min. temp. conversion value		R	
U0x.19	WORD	CH 3 max. temp. conversion value		R	

※ 'x' means slot no. where module is installed.

Ex.) U02.04: no.2 slot channel 0 temp. conversion value (word)

Chapter 5 Thermocouple Input Module

(2) Command sent from XGB main unit to module (XGB PLC output area, read/write available)

Device assignment	Type	Comment	Content	R/W	Signal direction
U0x.29.0	BIT	CH 0 max./min. searching Enable/Disable	Min./max. search On: enable Off: disable	R/W	CPU↔TC
U0x.29.1	BIT	CH 1 max./min. searching Enable/Disable		R/W	
U0x.29.2	BIT	CH 2 max./min. searching Enable/Disable		R/W	
U0x.29.3	BIT	CH 3 max./min. searching Enable/Disable		R/W	
U0x.29.8	BIT	CH 0 cold junction compensation Enable/Disable	Cold junction compensation On: enable Off: disable	R/W	
U0x.29.9	BIT	CH 1 cold junction compensation Enable/Disable		R/W	
U0x.29.A	BIT	CH 2 cold junction compensation Enable/Disable		R/W	
U0x.29.B	BIT	CH 3 cold junction compensation Enable/Disable		R/W	

※ 'x' means slot no. where module is installed.

Ex.) U03.29.02: no.3 slot, CH 2 max./min. searching Enable/Disable (bit)

Chapter 5 Thermocouple Input Module

(3) Data sent from module to XGB main unit (IEC type)
(XGB PLC input area, read only)

Device assignment	Type	Comment	Content	R/W	Signal direction
%UX0.x.0	BIT	CH 0 offset/gain adjustment error	On: error Off: normal	R	TC→CPU
%UX0.x.1	BIT	CH 1 offset/gain adjustment error		R	
%UX0.x.2	BIT	CH 2 offset/gain adjustment error		R	
%UX0.x.3	BIT	CH 3 offset/gain adjustment error		R	
%UX0.x.13	BIT	Module offset/gain backup error		R	
%UX0.x.14	BIT	Module H/W error		R	
%UX0.x.15	BIT	Module Ready	On: ready Off: not ready	R	TC→CPU
%UX0.x.16	BIT	CH 0 running	Channel running On: run, Off: stop	R	
%UX0.x.17	BIT	CH 1 running		R	
%UX0.x.18	BIT	CH 2 running		R	
%UX0.x.19	BIT	CH 3 running		R	
%UX0.x.20	BIT	CH 0 disconnection	Thermocouple sensor On: disconnection, Off: normal	R	
%UX0.x.21	BIT	CH 1 disconnection		R	
%UX0.x.22	BIT	CH 2 disconnection		R	
%UX0.x.23	BIT	CH 3 disconnection		R	
%UX0.x.24	BIT	CH 0 setting error	Parameter setting On: setting error Off: setting normal	R	
%UX0.x.25	BIT	CH 1 setting error		R	
%UX0.x.26	BIT	CH 2 setting error		R	
%UX0.x.27	BIT	CH 3 setting error		R	
%UW0.x.4	WORD	CH 0 temp. conversion value	Temp. conversion value (Measured temp.x10)	R	TC→CPU
%UW0.x.5	WORD	CH 1 temp. conversion value		R	
%UW0.x.6	WORD	CH 2 temp. conversion value		R	
%UW0.x.7	WORD	CH 3 temp. conversion value		R	
%UW0.x.8	WORD	CH 0 scaling operation value	Range with sign: -32768~32767 Range without sign: 0~65535	R	TC→CPU
%UW0.x.9	WORD	CH 1 scaling operation value		R	
%UW0.x.10	WORD	CH 2 scaling operation value		R	
%UW0.x.11	WORD	CH 3 scaling operation value		R	
%UW0.x.12	WORD	CH 0 min. temp. conversion value	Temp. conversion min./max. accumulation	R	TC→CPU
%UW0.x.13	WORD	CH 0 max. temp. conversion value		R	
%UW0.x.14	WORD	CH 1 min. temp. conversion value		R	
%UW0.x.15	WORD	CH 1 max. temp. conversion value		R	
%UW0.x.16	WORD	CH 2 min. temp. conversion value		R	
%UW0.x.17	WORD	CH 2 max. temp. conversion value		R	
%UW0.x.18	WORD	CH 3 min. temp. conversion value		R	
%UW0.x.19	WORD	CH 3 max. temp. conversion value		R	

※ 'x' means slot no. where module is installed.

Ex.) %UW0.2.4: no.2 slot channel 0 temp. conversion value (word)

Chapter 5 Thermocouple Input Module

- (4) Command sent from XGB main unit (IEC type) to module
(XGB PLC output area, read/write available)

Device assignment	Type	Comment	Content	R/W	Signal direction
%UX0.x.464	BIT	CH 0 max./min. searching Enable/Disable	Min./max. search On: enable Off: disable	R/W	CPU↔TC
%UX0.x.465	BIT	CH 1 max./min. searching Enable/Disable		R/W	
%UX0.x.466	BIT	CH 2 max./min. searching Enable/Disable		R/W	
%UX0.x.467	BIT	CH 3 max./min. searching Enable/Disable		R/W	
%UX0.x.472	BIT	CH 0 cold junction compensation Enable/Disable	Cold junction compensation On: enable Off: disable	R/W	
%UX0.x.473	BIT	CH 1 cold junction compensation Enable/Disable		R/W	
%UX0.x.474	BIT	CH 2 cold junction compensation Enable/Disable		R/W	
%UX0.x.475	BIT	CH 3 cold junction compensation Enable/Disable		R/W	


※ 'x' means slot no. where module is installed.

Ex.) %UX0.3.466: no.3 slot, CH 2 max./min. searching Enable/Disable (bit)

5.6.2 How to set operation parameter


Operation parameter of thermocouple input module can be set by two methods.

- (1) Setting operation parameters through [I/O parameter setting] window.




Chapter 5 Thermocouple Input Module

(2) Writing operation parameters through program (PUT instruction is used.)



Remark

How to use PUT instruction




[Area setting]

Operand	Description	Data size
sl	Slot no. where special module is mounted	WORD
S1	Internal memory address of special module	WORD
S2	Device to save in special module	WORD
N	The number of data	WORD

Chapter 5 Thermocouple Input Module

- (3) Writing operation parameters at setting area of thermocouple input module through program
(IEC type, PUT function block is used)



5.6.3 Operation parameter setting area

It describes operation parameter setting area of thermocouple input module.

Memory address		Description	Setting value	R/W	Instruction
Hex.	Dec.				
00 _H	0	Designate a channel to use	bit0:bit3, 0: stop, 1: run	R/W	PUT GET
01 _H	1	Set sensor type of CH 0	K:0, J:1, T:2, R:3	R/W	
02 _H	2	Set sensor type of CH 1			
03 _H	3	Set sensor type of CH 2			
04 _H	4	Set sensor type of CH 3			
05 _H	5	Designate temperature metric system	bit0:bit3, 0: Celsius, 1: Fahrenheit	R/W	
06 _H	6	Set CH 0 filter value	0 or 200 ~ 64000	R/W	
07 _H	7	Set CH 1 filter value			
08 _H	8	Set CH 2 filter value			
09 _H	9	Set CH 3 filter value			
0A _H	10	Set averaging method of CH 0	0: sampling 1: time average 2: count average 3: moving average	R/W	
0B _H	11	Set averaging method of CH 1			
0C _H	12	Set averaging method of CH 2			
0D _H	13	Set averaging method of CH 3			
0E _H	14	Set mean value of CH 0	Time average: 400~60000 ms Count average: 2~64000 times Moving average: 2~100	R/W	
0F _H	15	Set mean value of CH 1			
10 _H	16	Set mean value of CH 2			
11 _H	17	Set mean value of CH 3			
12 _H	18	Designate scaling type	bit0:bit3, 0: signed, 1: unsigned	R/W	
13 _H	19	Set min. value of CH 0 scaling range	Min. value signed: -32768~[max.-1] unsigned: 0~[max.-1] Max. value signed: [Min.+1]~32767 Unsigned: [Min.+1]~65535	R/W	
14 _H	20	Set max. value of CH 0 scaling range			
15 _H	21	Set min. value of CH 1 scaling range			
16 _H	22	Set max. value of CH 1 scaling range			
17 _H	23	Set min. value of CH 2 scaling range			
18 _H	24	Set max. value of CH 2 scaling range			
19 _H	25	Set min. value of CH 3 scaling range			

Chapter 5 Thermocouple Input Module

Memory address		Description	Setting value	R/W	Instruction
Hex.	Dec.				
1A _H	26	Set max. value of CH 3 scaling range			
1B _H	27	Set error inf. Of CH0.	Setting error information (Flag)	R	GET
1C _H	28	Set error inf. Of CH1			
1D _H	29	Set error inf. Of CH2			
1E _H	30	Set error inf. Of CH3			
1F _H	31	Cold junction compensation temp. of CH0.	Measured value of cold junction compensation temp.	R	GET
20 _H	32	Cold junction compensation temp. of CH1.			
21 _H	33	Cold junction compensation temp. of CH2.			
22 _H	34	Cold junction compensation temp. of CH3.			
23 _H ~37 _H	35 ~55	System area (Offset gain storage area)	Read/Write unavailable	unavailable	-



Caution

- (1) If input value of memory address 00_H~1A_H(0~26) is out of range of setting value, U0x.01.8~U0x.01.B (setting error representation flag, in case of IEC type, %UX0.x.24~%UX0.x.27) are on and it acts as default setting value. Error information is displayed in 1B_H~1F_H(27~30) area.
- (2) System area (Offset gain storage area) is area where Read/Write is unavailable. If this area changes, malfunction or breakdown may occur.

Chapter 5 Thermocouple Input Module


(1) Designating Channel (Address 0)

- (a) Temperature conversion module Enable/Disable can be set to each channel.
- (b) By prohibiting a channel not to use from conversion, conversion interval by channels can be shortened.
- (c) If channel to use is not designated, every channel can not be used.
- (d) In case of using PUT instruction, temperature conversion module Enable/Disable are as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "0"	—	—	—	—	—	—	—	—	—	—	—	—	C	C	C	C
													H	H	H	H
													3	2	1	0

BIT	Description
0	Stop
1	Operate

- (e) Vales set in B4 ~ B15 are ignored.
- (f) This area shows the same results with operation channel designation in I/O parameter setting window.



(2) Sensor Type Setting Area (Address 1~4)

- (a) Thermocouple sensor type can be set per channel.
- (b) In case of using PUT instruction, Sensor Type Setting Area is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "1"	CH0 sensor type setting															
Address "2"	CH1 sensor type setting															
Address "3"	CH2 sensor type setting															
Address "4"	CH3 sensor type setting															

Word	Description
0	K type
1	J type
2	T type
3	R type

- (c) When input value is larger than 4, 0 (K type) is selected by force.
But, U0x.01.8~ U0x.01.B (setting error representation, in case of IEC type, %UX0.x.24 ~ %UX0.x.27) are on, error information is displayed at bit 0 of address 27~30.

Chapter 5 Thermocouple Input Module

- (d) This area shows the same results with sensor type designation in I/O parameter setting window.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	K	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

- (3) Temp. unit setting area (Address 5)

- (a) Temp. unit (Celsius/ Fahrenheit) of thermocouple input module can be set per channel.
 (b) In case of PUT instruction, Temp. unit setting area is as follows.

Address "5"

Bit	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
	—	—	—	—	—	—	—	—	—	—	—	—	C H 3	C H 2	C H 1	C H 0

Bit	Description
0	Celsius
1	Fahrenheit

- (c) Vales set in B4 ~ B15 are ignored.
 (d) This area shows the same results with temp. unit setting in I/O parameter setting window.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

- (4) Filter constant setting area (Address 6~9)

- (a) Filter constant can be set per channel.
 (b) Filter constant ranges 0 or 200 ~ 64000.
 (c) If filter constant is set as 0, filtering process is not executed.
 (d) When input is 1~199 or larger than 6400, 0 (filter disable) is selected by force.
 But, U0x.01.8~ U0x.01.B (setting error representation, in case of IEC type, %UX0.x.24 ~ %UX0.x.27) are on, error information is displayed at bit 1 of address 27~30.
 (e) In case of PUT instruction, filter constant setting address is as follows.

Chapter 5 Thermocouple Input Module

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "6"	CH0 filter constant setting (0, 200~64000)															
Address "7"	CH1 filter constant setting (0, 200~64000)															
Address "8"	CH2 filter constant setting (0, 200~64000)															
Address "9"	CH3 filter constant setting (0, 200~64000)															

(f) This area shows the same results with filter constant setting in I/O parameter setting window.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	0	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

0, 200~64000

OK Cancel

(5) Average processing setting area (Address 10~13)

(a) Average processing method can be set per channel.

(b) Average processing method (Sampling: 0 / time-avr.: 1 / count-avr.: 2 / moving-avr.: 3)

(c) When input is larger than 4, 0 (sampling) is set by force.

But, U0x.01.8~ U0x.01.B (setting error representation, in case of IEC type, %UX0.x.24~%UX0.x.27) are on, error information is displayed at bit 2 of address 27~30.

(d) In case of PUT instruction, average processing setting method is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "10"	CH# average processing method setting 0: Sampling 1: Time-average 2: Count-average 3: Moving-average															
Address "11"																
Address "12"																
Address "13"																

(e) This area shows the same results with average processing method setting in I/O parameter setting window.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling	Sampling	Sampling
Average value	Sampling	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

OK Cancel

Chapter 5 Thermocouple Input Module

- (6) Average value setting area (Address 14~17)
- (a) Average value can be set per channel.
 - (b) In case average processing method is sampling, values of this area are ignored.
 - (c) In case of using PUT instruction, average value setting address is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "14"	CH# average value setting Time-average: 400 ~ 64000[ms] Count-average: 2 ~ 64000[times] Moving-average: 2 ~ 100															
Address "15"																
Address "16"																
Address "17"																

- (d) When input is out of range, the min. value of each address is selected by force.
 But, U0x.01.8~ U0x.01.B (setting error representation, in case of IEC type, %UX0.x.24 ~ %UX0.x.27) are on, error information is displayed at bit 3~5 of address 27~30.
 (Bit 3: time-average, bit 4: count-average, bit 5: moving-average)
 Ex.) When selecting the Time-average and setting average value as 200, 400ms is selected in address "14" by force.

- (e) This area shows the same results with average value setting in I/O parameter setting window.
 In the I/O parameter setting window, prohibition function is provided not to set value that is out of range. (In case of setting value that is out of range, that values are displayed with red color and error message is displayed.)

1) Time-Avr.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Time-Avr	Sampling	Sampling	Sampling
Average value	500	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

400~64000

2) Count-Avr.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Count-Avr	Sampling	Sampling	Sampling
Average value	500	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

2~64000

3) Moving-Avr.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	Moving-Avr	Sampling	Sampling	Sampling
Average value	50	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

2~100

Chapter 5 Thermocouple Input Module


(7) Scaling data type setting area (address 18)

- (a) Scaling data type can set per channel.
- (b) There are two type of scaling operation output, unsigned 16 bit (0~65535) or signed 16 bit (-32768~32768).
- (c) In case of using PUT instruction, scaling data type setting address is as follows.

Address "0"	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
	—	—	—	—	—	—	—	—	—	—	—	—	C H 3	C H 2	C H 1	C H 0

Bit	Description
0	Signed integer
1	Unsigned integer

- (d) Values set in B4~15 are ignored.
- (e) This area shows the same results with Scaling data type setting in I/O parameter setting window.



(8) Scaling min./max. value setting area (Address 19~26)

- (a) Scaling min./max. value can be set per channel.
- (b) There are two type of scaling operation output, unsigned 16 bit (0~65535) or signed 16 bit (-32768~32767).
- (c) In case of using PUT instruction, scaling min./max. value setting address is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "19"	CH# scaling min./max. value 1) with sign Min.: -32768 ~ [Scaling max. value-1] Max.: [Scaling min. value+1]~32767 2) without sign Min.: 0 ~ [Scaling max. value-1] Max.: [Scaling min.value+1]~65535 CH0: min. address 19 / max. address 20 CH1: min. address 21 / max. address 22 CH2: min. address 23 / max. address 24 CH3: min. address 25 / max. address 26															
Address "20"																
Address "21"																
Address "22"																
Address "23"																
Address "24"																
Address "25"																
Address "26"																

- (d) If input is out of range, it keeps previous value.
 But, U0x.01.8~ U0x.01.B (setting error representation, in case of IEC type, %UX0.x.24~%UX0.x.27) are on, error information is displayed at bit 6 of address 27~30.

Chapter 5 Thermocouple Input Module

- (e) This area shows the same results with Scaling min./max. value setting in I/O parameter setting window.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Enable	Enable	Enable
<input type="checkbox"/> Sensor status	K	K	K	K
<input type="checkbox"/> Temp. unit	Celsius	Celsius	Celsius	Celsius
Filter constant	0	0	0	0
<input type="checkbox"/> Average processing	MovingAve	Sampling	Sampling	Sampling
Average value	50	0	0	0
<input type="checkbox"/> Scaling data type	Bipolar	Bipolar	Bipolar	Bipolar
Scaling min. value	-32768	-32768	-32768	-32768
Scaling max. value	32767	32767	32767	32767

-32768~32766

OK Cancel

Scaling data type	Scaling min. value	Scaling max. value
Signed	-32768 ~ [Scaling max. value -1]	[Scaling min. value+1] ~ 32767
Unsigned	0 ~ [Scaling max. value-1]	[Scaling min. value+1] ~ 65535

- (9) Setting error information area (address 27~30)
- (a) If there is error when setting parameter (address 1~26), error information is displayed at address 27~30 per channel.
- (b) In case of GET instruction, setting error information address is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "27"	CH0 setting error information															
Address "28"	CH1 setting error information															
Address "29"	CH2 setting error information															
Address "30"	CH3 setting error information															

Bit	Description	Related memory address	
		Hex.	Dec.
Bit0	Sensor type (Off: normal, On: error)	01H~04H	1~4
Bit1	Filter constant (Off: normal, On: error)	06H~09H	6~9
Bit2	Average processing method (Off: normal, On: error)	0AH~0DH	10~13
Bit3	Time-average value (Off: normal, On: error)	0EH~11H	14~17
Bit4	Count-average value (Off: normal, On: error)		
Bit5	Moving-average value (Off: normal, On: error)		
Bit6	Scaling range (Off: normal, On: error)	13H~1AH	19~26

- (c) In case there is error, setting error representation flag (U0x.01.8 ~ U0x.01.B, in case of IEC type, %UX0.x.24 ~ %UX0.x.27) will be on, it acts as default value.
- If setting error representation flag (U0x.01.8 ~ U0x.01.B) is on, check error information 1BH ~ 1FH (27~30) area and solve the error.

Chapter 5 Thermocouple Input Module

(10) Cold junction compensation temp. area (Address 31~34)


(a) Cold junction compensation temp. can be seen per channel.

(b) In case of GET instruction, cold junction compensation temp. area is as follows.

	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
Address "31"	CH0 cold junction compensation temp.															
Address "32"	CH1 cold junction compensation temp.															
Address "33"	CH2 cold junction compensation temp.															
Address "34"	CH3 cold junction compensation temp.															

(11) System area (offset gain storage area: address 35~55)

(a) In the system area, Read/Write is unavailable.


	Caution	If the user changes this area, it may cause malfunction or breakdown. So do not handle this area.
---	----------------	--

5.7 Example Program


- (1) It describes how to set operation parameter in the internal memory of thermocouple module.
- (2) Regarding the initial condition, the initial settings are saved in the internal memory of thermocouple module if saved once.
- (3) The following is program example that reads the temp. value of thermocouple input module of slot 1 and check whether disconnection occurs or not.

5.7.1 Example using [I/O Parameter]

(1) I/O parameter setting window




(2) Program example



- (a) If module is under normal operation, M0000 is on.
 U01.00.F(module Ready) = On
 U01.00.0(CH0 offset/gain adjustment error) = Off
 U01.00.E(module H/W error) = Off
 U01.00.E(CH0 running) = On
- (b) If M0000 is on, temp. conversion value (U01.04) of CH0 moves to D0000.
- (c) If disconnection error occurs at CH0, U01.01.4 (CH0 disconnection) is on and M0001 bit is set.

Chapter 5 Thermocouple Input Module


(3) Program example (in case of IEC type)



- (a) If module is running normally, operation start bit is on
 - %UX0.1.15 (Module Ready) = On
 - %UX0.1.0 (CH 0 offset/gain adjustment error) = Off
 - %UX0.1.14 (Module H/W error) = Off
 - %UX0.1.16 (CH 0 running) = On
 - %UX0.1.24 (Setting error) = Off
- (b) If operation start bit is on, it moves CH 0 temp. conversion value (%UW0.1.4) into CH 0 temp. data
- (c) If CH 0 disconnection error occurs, %UX0.1.20 (CH0 disconnection) is on and CH 0 disconnection error bit is set

5.7.2 Program example using PUT/GET instruction


(1) Program example



- It writes `h0001` at address 0 of slot 1 in order to enable CH0.
- If module is under normal operation, `M0000` is on.
`U01.00.F`(module Ready) = On
`U01.00.0`(CH0 offset/gain adjustment error) = Off
`U01.00.E`(module H/W error) = Off
`U01.00.E`(CH0 running) = On
- If `M0000` is on, temp. conversion value of CH0 moves to `D0000`.
 Current temp. conversion value, 278(27.8℃2) is saving in `U01.04`.
- If disconnection error occurs at CH0, `U01.01.4` (CH0 disconnection) is on and `M0001` bit is set.
- If `M0000` is on, setting error (address 27) of CH0 moves to `D0001`. Since setting error (address 27) of CH0 is 0, there is no setting error.

Chapter 5 Thermocouple Input Module


(2) Program example (in case of IEC type)



- Writes 1 at address 0 of slot 1 and operates CH 0 by using PUT_WORD function block.
- If operation start bit is on, reads CH 0 setting error (address 27) and moves it into D0001.
- If module is running normally, operation start bit is on.
 - %UX0.1.15 (module Ready) = On
 - %UX0.1.0 (CH 0 offset/gain adjustment error) = Off
 - %UX0.1.14 (Module H/W error) = Off
 - %UX0.1.16 (CH 0 running) = On
 - %UX0.1.24 (setting error) = Off
- Operation start bit is on, moves CH 0 temp. conversion value (%UW0.1.4) into CH 0 temp. data
- Disconnection error occurs at CH 0, %UX0.1.20 (CH 0 disconnection) is on and CH 0 disconnection error bit is set.

5.7.3 Example when error occurs

(1) Program example



- (a) If disconnection error occurs at CH0, U01.01.4 (CH0 disconnection) is on and M0001 bit is set.
- (b) If disconnection error occurs at CH0, min. value within the range of K type temperature sensor is displayed at U01.04.
- (c) It is monitored as follows according to monitor display type.
When monitoring the temp. conversion value, select "Unsigned Decimal".

Monitor display type	Display content
Unsigned Decimal	62836
Signed Decimal	-2700 (-270.0℃)
Hexadecimal	hF574
As Instruction	62836

5.8 Troubleshooting

The chapter describes diagnostics and measures in case any trouble occurs during use of thermocouple input module.

5.8.1 LED Indication by Errors

Thermocouple input module has two LEDs and it is possible to check whether it had any error with the indication of RUN LED and ALM LED.

Item	Normal	Disconnection	Abnormal module H/W (error)
RUN LED	ON	ON	Flicker every 0.2 second
ALM LED	OFF	Flicker every second	OFF
Operation	Normal operation Every function works	Every function works Min. temp. is displayed	Module function stops
Management	-	Checking sensor wiring	Customer service

5.8.2 Stats check of module through XG5000 system monitor

Module type, module information, O/S version and module status of thermocouple input module can be checked through XG5000 system monitoring function.

(1) Execution sequence

Two routes are available for the execution.


- (a) [Monitor] -> [System Monitoring] -> And on the module screen, click the right mouse button to display [Module Information].
- (b) [Monitor] -> [System Monitoring] -> And Double-click the module screen.

(2) Module information


- (a) Module type: shows the information of the module presently installed.
- (b) Module information: shows the O/S version information of module.
- (c) O/S version: shows the O/S prepared date of module.

5.8.3 Troubleshooting

(1) RUN LED flickers.




(2) RUN LED is off.




Chapter 5 Thermocouple Input Module

(3) ALM LED flickers.



(4) Temperature conversion value is not normal.



5.8.4 Error code and measure

(1) Measure when error flag of data I/O area (U device) occurs.

Device assignment ('S', 'H' type)	Device assignment (IEC type)	Description	Content	Measure
U0x.00.0	%UX0.x.0	CH0 offset/gain adjustment error	On: error Off: normal	If repeated when restarting the power, contact custom service center
U0x.00.1	%UX0.x.1	CH1 offset/gain adjustment error		
U0x.00.2	%UX0.x.2	CH2 offset/gain adjustment error		
U0x.00.3	%UX0.x.3	CH3 offset/gain adjustment error		
U0x.00.D	%UX0.x.13	Module offset/gain backup error		If repeated when restarting the power, contact custom service center
U0x.00.E	%UX0.x.14	Module H/W error		If repeated when restarting the power, contact custom service center
U0x.01.8	%UX0.x.24	CH0 setting error	Parameter setting On: setting error Off: setting normal	Check the parameter setting area (address 27~30) by GET instruction, solve the setting error contents.
U0x.01.9	%UX0.x.25	CH1 setting error		
U0x.01.A	%UX0.x.26	CH2 setting error		
U0x.01.B	%UX0.x.27	CH3 setting error		

(2) Checking error information area (address 27~30) of operation parameter area

(a) Setting error information area (address 27~30)

Bit	Description	Related memory address	
		Hex.	Dec.
Bit0	Sensor type setting (Off: normal, On: error)	01H~04H	1~4
Bit1	Filter constant setting (Off: normal, On: error)	06H~09H	6~9
Bit2	Average processing method setting (Off: normal, On: error)	0AH~0DH	10~13
Bit3	Time average value (Off: normal, On: error)	0EH~11H	14~17
Bit4	Count average value (Off: normal, On: error)		
Bit5	Moving average value (Off: normal, On: error)		
Bit6	Scaling range (Off: normal, On: error)	13H~1AH	19~26


(b) Checking setting error information

Check the setting error information (address 27~30) area by GET instruction.

Ex.1) In case thermocouple input module is mounted at slot 1.

MOD00	GET	1	27	0000	1
	GET	1	28	0001	1
	GET	1	29	0002	1
	GET	1	30	0003	1

Ex.2) In case thermocouple input module is mounted at slot 1. (In case of IEC)




- (c) In case setting error occurs, setting error representation flag (U0x.01.8~ U0x.01.B, in case of IEC type %UX0.x.24 ~ %UX0.x.27) will be on and it will act as default value. If setting error representation flag (U0x.01.8~ U0x.01.B, in case of IEC type, %UX0.x.24 ~ %UX0.x.27) is on, check above setting error information 1B_H ~ 1F_H (address 27~30) area, check related memory address 01_H ~ 1A_H (address 1~26) and cancel error.

Chapter 6 Analogue Combo Module

6.1 Pre-operation Setting Procedure

Please proceed as follows before operating analogue combo module.



6.2 Specification

6.2.1 General Specification

This section describes general specifications of the analogue mix module.

No.	Item	Specification				Applicable Standard
1	Working Temperature	0 ~ 55 °C				
2	Storage Temperature	-25 ~ +70 °C				
3	Working Humidity	5 ~ 95%RH, no condensate				
4	Storage Humidity	5 ~ 95%RH, no condensate				
5	Vibration Resistance	Intermittent Vibration			-	IEC61131-2
		Frequency	Acceleration	Amplitude	Cycle	
		10 ≤ f < 57Hz	-	0.075mm	10 cycles for X, Y, Z each	
		57 ≤ f ≤ 150Hz	9.8m/s ² (1G)	-		
		Continuous Vibration				
		Frequency	Acceleration	Amplitude		
		10 ≤ f < 57Hz	-	0.035mm		
		57 ≤ f ≤ 150Hz	4.9m/s ² (0.5G)	-		
6	Impact Resistance	• Max. impact acceleration: 147 m/s ² (15G) • Duration: 11ms • Pulse Shape: sinusoidal half-wave pulse (3 cycles in X, Y, Z)				IEC61131-2
7	Noise Resistance	Rectangular Impulse Noise	±1,500 V			IMO Self Test Standard
		Static Electricity Discharge	Voltage: 4kV (contact discharge)			IEC61131-2 IEC61000-4-2
		Radiation Electromagnetic Field Noise	27 ~ 500 MHz, 10V/m			IEC61131-2, IEC61000-4-3
		Past Transient /Burst Noise	Classific ation	Power Module	Digital/Analogue I/O, Communication Interface	IEC61131-2 IEC61000-4-4
			Voltage	2kV	1kV	
8	Environment	No corrosive gas or dust				
9	Altitude	2,000m max.				
10	Contaminati on	2 or less				
11	Cooling	Natural air cooling				

6.2.2 Performance Specification

This section specified the performance of analogue mix module.

(1) Input Performance Specification

Classification			Input Performance Specification	
No. input channels			2 channels	
Analogue Input Range	Type		Voltage	Current
	Range		DC 1 ~ 5V	DC 4 ~ 20mA
			DC 0 ~ 5V	DC 0 ~ 20mA
			DC 0 ~ 10V (Input resistance: 1 MΩ min.)	(Input resistance 250 Ω)
		Input range shall be specified in user program or I/O parameters by channel, and selected with external voltage/current switches.		
Digital Output	Type		12-bit binary data	
	Value Range	Unsigned	0 ~ 4000	
		Signed	-2000 ~ 2000	
		Precise Value	100 ~ 500 (DC 1 ~ 5V) 0 ~ 500 (DC 0 ~ 5V) 0 ~ 1000 (DC 0 ~ 10V)	400 ~ 2000 (DC 4 ~ 20mA) 0 ~ 2000 (DC 0 ~ 20mA)
		Percentile Value	0 ~ 1000	
Max. Resolution		1/4000		
		1.25mV (DC 1~5V, 0~5V) 2.5mV (DC 0~10V)	5μA (DC4~20mA, 0~20mA)	
Precision		±0.5% max.		
Max. Conversion Rate		1ms/channel		
Max. Absolute Input		DC ±15V	DC ±25mA	
Additional Functions	Filtration		Digital filter (4 ~ 64,000ms)	
	Averaging	Time average (4~16,000ms)		
		Cycle average (2~64,000 cycles)		
		Moving average (2~100 values)		
	Alarm		Open line detection (DC 1~5V, DC4~20mA)	

(2) Output Performance Specification


Classification			Output Performance Specification	
No. of output channels			2 channels	
Analogue Output Range	Type		Voltage	Current
	Range		DC 1 ~ 5V	DC 4 ~ 20mA
			DC 0 ~ 5V	DC 0 ~ 20mA
			DC 0 ~ 10V	(Load resistance: 510 Ω max.)
			(Load resistance: 2kΩ min.)	
		Output range shall be specified in user program or I/O parameters by channel, and selected with external voltage/current switches.		
Digital Input	Type		12-bit binary data	
	Value Range	Unsigned	0 ~ 4000	
		Signed	-2000 ~ 2000	
		Precise Value	100 ~ 500 (DC 1 ~ 5V) 0 ~ 500 (DC 0 ~ 5V) 0 ~ 1000 (DC 0 ~ 10V)	400 ~ 2000 (DC 4 ~ 20mA) 0 ~ 2000 (DC 0 ~ 20mA)
		Percentile Value	0 ~ 1000	
Max. Resolution		1/4000		
		1.25mV (DC 1~5V, 0~5V)	5μA (DC4~20mA, 0~20mA)	
		2.5mV (DC 0~10V)		
Precision			±0.5% max.	
Max. Conversion Rate			1ms/channel	
Max. Absolute Output			DC ±15V	DC 25mA
Additional Functions			Channel output status setting function (selectable from previous, min., mean, max. value outputs)	

(3) I/O Common Performance Specification

Classification		I/O Common Performance Specification
Insulation Type		Photo-coupler isolation between I/O terminal and PLC power source (no insulation between channels)
I/O Terminals		11 point terminal block
I/O Points		Fixed type: 64 points
Max. No. of Installation		7 units (XBM-DxxxS "S" type) 10 units (XB(E)C-DxxxH "H" type)
Current	Internal (DC 5V)	120mA
	External (DC 24V)	130mA
Weight		73g

6.3 Major Components

Major components are as follows;



No.	Name	Description
①	INPUT LED	► Indicate operation of input part On: normal operation Flashing: in error (1 sec. flashing) Off: power off or module failure
②	OUTPUT LED	► Indicate operation of output part On: normal operation Flashing: in error (1 sec. flashing) Off: power off or module failure
③	Input Volt/Current Select Switch	► Switch for selecting voltage/current input of analogue input Ch 0 and Ch 1
④	Output Volt/Current Select Switch	► Switch for selecting voltage/current output of analogue output Ch 0 and Ch 1
⑤	Input Terminal Block	► Terminal block for analogue input wiring with external devices
⑥	Output Terminal Block	► Terminal block for analogue output wiring with external devices
⑦	Ext. Power Connector	► Connector for DC24V external power supply
⑧	Ext. Connector	► Connector for extension modules


6.4 Conversion Characteristics by I/O Range

The input/output ranges of voltage and current can be set up per channel with user program or I/O parameters. The I/O types of digital data are defined as follows.

- (1) Unsigned Value
- (2) Signed Value
- (3) Precise Value
- (4) Percentile Value

6.4.1 Input Characteristics

The graph below shows the data conversion characteristics by input range.



(1) DC 4 ~ 20mA Range Input

Digital Output Range	Analogue Input Current (mA)						
	3.81	4	8	12	16	20	20.18
Unsigned Value (0 ~ 4000)	-48	0	1000	2000	3000	4000	4047
Signed Value (-2000 ~ 2000)	-2048	-2000	-1000	0	1000	2000	2047
Precise Value (400 ~ 2000)	381	400	800	1200	1600	2000	2018
Percentile Value(0 ~ 1000)	-12	0	250	500	750	1000	1011

Chap. 6 Analogue Combo Module

(2) DC 0 ~ 20mA Range Input

Digital Output Range	Analogue Input Current (mA)						
	-0.24	0	5	10	15	20	20.23
Unsigned Value (0 ~ 4000)	-48	0	1000	2000	3000	4000	4047
Signed Value (-2000 ~ 2000)	-2048	-2000	-1000	0	1000	2000	2047
Precise Value (0 ~ 2000)	-24	0	500	1000	1500	2000	2023
Percentile Value(0 ~ 1000)	-12	0	250	500	750	1000	1011

(3) DC 1 ~ 5V Range Input

Digital Output Range	Analogue Input Voltage (V)						
	0.96	1	2	3	4	5	5.04
Unsigned Value (0 ~ 4000)	-48	0	1000	2000	3000	4000	4047
Signed Value (-2000 ~ 2000)	-2048	-2000	-1000	0	1000	2000	2047
Precise Value (100 ~ 500)	96	100	200	300	400	500	504
Percentile Value(0 ~ 1000)	-12	0	250	500	750	1000	1011

(4) DC 0 ~ 5V Range Input


Digital Output Range	Analogue Input Voltage (V)						
	-0.06	0	1.25	2.5	3.75	5	5.05
Unsigned Value (0 ~ 4000)	-48	0	1000	2000	3000	4000	4047
Signed Value (-2000 ~ 2000)	-2048	-2000	-1000	0	1000	2000	2047
Precise Value (0 ~ 500)	-6	0	125	250	375	500	505
Percentile Value(0 ~ 1000)	-12	0	250	500	750	1000	1011

(5) DC 0 ~ 10V Range Input

Digital Output Range	Analogue Input Voltage (V)						
	-0.12	0	2.5	5	7.5	10	10.11
Unsigned Value (0 ~ 4000)	-48	0	1000	2000	3000	4000	4047
Signed Value (-2000 ~ 2000)	-2048	-2000	-1000	0	1000	2000	2047
Precise Value (0 ~ 1000)	-12	0	250	500	750	1000	1011
Percentile Value(0 ~ 1000)	-12	0	250	500	750	1000	1011

6.4.2 Output Characteristics

The graph below shows the data conversion characteristics by output range.



(1) DC 4 ~ 20mA Range Output

Digital Input Range	Analogue Output Current (mA)						
	4mA less	4	8	12	16	20	20mA over
Unsigned Value (0 ~ 4000)	0 less	0	1000	2000	3000	4000	4000 over
Signed Value (-2000 ~ 2000)	-2000 less	-2000	-1000	0	1000	2000	2000 over
Precise Value (400 ~ 2000)	400 less	400	800	1200	1600	2000	2000 over
Percentile Value(0 ~ 1000)	0 less	0	250	500	750	1000	1000 over

(2) DC 0 ~ 20mA Range Output

Digital Input Range	Analogue Output Current (mA)						
	0mA less	0	5	10	15	20	20mA over
Unsigned Value (0 ~ 4000)	0 less	0	1000	2000	3000	4000	4000 over
Signed Value (-2000 ~ 2000)	-2000 less	-2000	-1000	0	1000	2000	2000 over
Precise Value (0 ~ 2000)	0 less	0	500	1000	1500	2000	2000 over
Percentile Value(0 ~ 1000)	0 less	0	250	500	750	1000	1000 over

Chap. 6 Analogue Combo Module

(3) DC 1 ~ 5V Range Output

Digital Input Range	Analogue Output Voltage (V)						
	1V less	1	2	3	4	5	5V over
Unsigned Value (0 ~ 4000)	0 less	0	1000	2000	3000	4000	4000 over
Signed Value (-2000 ~ 2000)	-2000 less	-2000	-1000	0	1000	2000	2000 over
Precise Value (100 ~ 500)	100 less	100	200	300	400	500	500 over
Percentile Value(0 ~ 1000)	0 less	0	250	500	750	1000	1000 over

(4) DC 0 ~ 5V Range Output

Digital Input Range	Analogue Output Voltage (V)						
	0V less	0	1.25	2.5	3.75	5	5V over
Unsigned Value (0 ~ 4000)	0 less	0	1000	2000	3000	4000	4000 over
Signed Value (-2000 ~ 2000)	-2000 less	-2000	-1000	0	1000	2000	2000 over
Precise Value (0 ~ 500)	0 less	0	125	250	375	500	500 over
Percentile Value(0 ~ 1000)	0 less	0	250	500	750	1000	1000 over

(5) DC 0 ~ 10V Range Output

Digital Input Range	Analogue Output Voltage (V)						
	0V less	0	2.5	5	7.5	10	10V over
Unsigned Value (0 ~ 4000)	0 less	0	1000	2000	3000	4000	4000 over
Signed Value (-2000 ~ 2000)	-2000 less	-2000	-1000	0	1000	2000	2000 over
Precise Value (0 ~ 1000)	0 less	0	250	500	750	1000	1000 over
Percentile Value(0 ~ 1000)	0 less	0	250	500	750	1000	1000 over


6.5 Precision

6.5.1 Input Precision

The precision of digital output is not dependent upon the input range.

The graph below shows the variation of precision when the analogue input range is 0 ~ 10 V for unsigned value for digital output.

The input precision of the XBF-AH04A is $\pm 0.5\%$.



(1) Precision at 5V input;

$$4000 \times 0.5\% = 20$$

Therefore, precision range at 5V input is; $(2000-20) \sim (2000+20) = 1980 \sim 2020$.

(2) Precision at 10V input;

$$4000 \times 0.5\% = 20$$


Therefore, precision range at 10V input is; $(4000-20) \sim (4000+20) = 3980 \sim 4020$.

6.5.2 Output Precision

The precision of analogue output is not dependent upon the output range.

The graph below shows the variation of precision when the analogue output range is 0 ~ 10 V for unsigned value for digital output.

The output precision of the XBF-AH04A is $\pm 0.5\%$



- (1) Precision at 5V output;
 $4000 \times 0.5\% = 20$, therefore,
precision range at 5V output is; $(5V - 20 \times 0.0025V) \sim (5V + 20 \times 0.0025V) = 4.95 \sim 5.05V$.
- (2) Precision at 10V output;
 $4000 \times 0.5\% = 20$, therefore,
precision range at 10V output is; $(10V - 20 \times 0.0025V) \sim (10V + 20 \times 0.0025V) = 9.95 \sim 10.05V$.

6.6 Functions of Analogue Combo Module

The functions of XBF-AH04A Module are as follows.

Function	Description
Channel operation/stop setting	<ul style="list-style-type: none">Specify operation/stop of the channel which will perform A/D and D/A conversion.Specifying unused channels as Stop can shorten overall operation time.
I/O Voltage /current range setting	<ul style="list-style-type: none">Specify desired range of analogue I/O.Select voltage/current with external switch, and set up range with parameter.Analogue Mix Module provides 2 ranges(4~20mA, 0~20mA) of current I/O and 3 ranges (1~5V, 0~5V, 0~10V) of voltage I/O.
I/O data type setting	<ul style="list-style-type: none">Specify digital I/O types.This module provides 4 output data types (Unsigned, Signed, Precision, and Percentile Values)
A/D input conversion method	<ul style="list-style-type: none">Sampling Process<ul style="list-style-type: none">If A/D conversion method has not been specified, the module processes sampling.Filter process<ul style="list-style-type: none">Filters rapid changes in input value by external noise.Averaging process<ul style="list-style-type: none">Outputs A/D converted value averaged by time, cycle, and moving.
D/A output status setting	<ul style="list-style-type: none">Sets up channel output state at transition from run to stop.Provides 4 output selections (Previous, Minimum, Mean, Maximum Values)

6.6.1 Sampling Process

In popular A/D conversion process, analogue input signals are collected at constant time intervals and A/D converted. The time elapsed for the analogue signals converted into digital signals and saved in memory device depends upon the number of channels used.

$$(\text{Process Time}) = (\text{No. of Channels Used}) \times (\text{Conversion Rate})$$

(Ex.) Process time when using 3 of 4 I/O channels;

$$3 \times 1 \text{ ms} = 3.0 \text{ ms}$$


The term 'sampling' means taking analogue signal values at certain time intervals.

6.6.2 Filtering Function

The input value of the designated channel is calculated with previously filtered input value using preset filter constant (time constant 63.2%) by the formula below;

$$\text{PresentlyFilteredInput} = \frac{(\text{PreviouslyFilteredInput} \times \text{FilterConstant}) + (\text{PresentInput} \times 1\text{ms} \times \text{No.ofChannelsUsed})}{\text{FilterConstant} + (1\text{ms} \times \text{No.ofChannelsUsed})}$$

Filter Constant setting range = 4 ~ 64000 [ms]




In the above graph, if the input value changes rapidly from 0 to 100, the input value is filtered. Filter (time) constant is the time required for input values to vary by 63.2% of the actual input value.

6.6.3 Averaging Function

(1) Average by Time

The input values of the designated channel are accumulated for the preset time, and the average value of the total sum is outputted in digital data.




Setting Range = 4 ~ 16000 [ms]

For time averaging, No. of averaging cycles are calculated with the No. of channels used as below;

$$\text{No. Averaging Cycles} = \frac{\text{AverageTime}}{\text{No.ofChannelsUsed} \times 1\text{ms}}$$

(2) Average by Cycles

The input values of the designated channel are accumulated for the preset cycles, and the average value of the total sum is outputted in digital data.




Setting Range = 2 ~ 64000 [Cycle]

For cycle averaging, averaging interval is calculated with the No. of channels used.

$$\text{AveragingInterval [ms]} = \text{AveragingCycle} \times \text{No.ofChannelUsed} \times 1\text{ms}$$

(3) Moving Average

The inputs into the designated channel are accumulated for the presser number, and its average is calculated and outputted in digital data. However, in moving average method, each scan provides its average value.



Note

- (1) In case of time/cycle averages. The input value is not outputted at every conversion, but the previous value is maintained until the average time or cycle is reached.
- (2) In case of moving averages, the converted input is averaged with the previously entered value and the result is outputted at every conversion. Therefore, data response is faster than time/cycle averaging methods.
- (3) The three averaging methods can be processed simultaneously with the filter function described earlier. In such case, the filter function is executed first, and averaging function is processed to output the average value in digital data, which is expressed with the finally-processed value.

6.6.4 Line Open Detection Function

The analogue mix module has a diagnostic function which can detect and indicate open input line, when voltage input range of DC 1~5V or current input range of DC 4~20mA is selected as its analogue input range. If the module indicates open input line, check the wiring.

- (1) If the wiring to the module is open, the Input LED flashes at 1 second intervals and the respective error code is generated.
- (2) Line open detection is available for each channel. However, open indication is provided only for the channel selected for the operation. The Input LED is common for the input channels 0 and 1, and flashes if 1 or more channels are open.

Input Connection	Channel Operation	Input LED State	Open Line Flag
Normal	Working	On	Off
	Stopped	On	Off
Input wire open or disconnected	Working	Flash (1s)	On
	Stopped	On	Off

- (3) At line open, the line open flag of the channel turns On, and turns Off at correction.

Open Flag	Description
U0x.01.4	Ch 0 open
U0x.01.5	Ch 1 open

- (4) At line open, the least of all input values is indicated.

6.6.5 Channel Output Status Setting Function

This function sets up the output in response to PLC shutdown or failure.

(1) Function

This function is used to obtain preset output value of the analogue mix module when the PLC system is transferred from run to stop.

(2) Type

Channel output can be one of the followings;

- (a) Previous value: maintains the last output from normal operation.
- (b) Minimum: outputs the least values of the respective output ranges.
- (c) Median: outputs the median values of the respective output ranges.
- (d) Maximum: outputs the largest values of the respective output ranges.

(3) Example

Assume that the output channel range is set to 4 ~ 20mA and the output level is 10mA. If the PLC system is switched from run to stop status, the output will be one of followings according to the setting;

- (a) Previous value: maintains 10mA which is the previous normal operation value.
- (b) Minimum: outputs 4mA which is the minimum of the output range setting.
- (c) Median: outputs 12mA which is the median of the output range setting.
- (d) Maximum: outputs 20mA which is the maximum of the output range setting.


6.7 Wiring

6.7.1 Precautions for Wiring

- (1) Keep the I/O signal lines of the analogue mix module away from AC power line. Otherwise, the surge or induction noise of the AC line may affect the module.
- (2) The cable should be selected taking ambient temperature and allowable current into consideration. Recommended cable is AWG22 (0.3mm²) or higher grade.
- (3) Keep the cables away from heat source or oil. Otherwise, short-circuit, damage, or malfunction of the module may occur.
- (4) Check polarity at terminal block connection.
- (5) Keep the cables away from high voltage line or power line to avoid malfunction or failure of the module by induction.


6.7.2 Exemplary Analogue Input Wiring

- (1) Input resistance of the current input circuit is 250 Ω (typ.).
- (2) Input resistance of the voltage input circuit is 1 M Ω (min.).
- (3) Set only the channels to be used up for operation.
- (4) Analogue mix module does not provide power supply to external input device. Use external power supply.
- (5) Exemplary analogue input wiring
Same wiring scheme is applied to voltage and current inputs, except that voltage/current setting switch must be set up accordingly.




(6) Exemplary Wiring for Analogue Input 2-Wire Sensor/Transmission

Same wiring scheme is applied to voltage and current inputs, except that voltage/current setting switch must be set up accordingly.




(7) Exemplary Wiring for Analogue Input 4-Wire Sensor/Transmission

Same wiring scheme is applied to voltage and current inputs, except that voltage/current setting switch must be set up accordingly.



(8) Relation between voltage input precision and cable length

In voltage input system, the cable length between the module and transmitter or sensor influences on the converted digital value of the module. The value is as follows.



Where,

R_c : line resistance of the wire,

R_s : internal resistance of the transmitter or sensor,

R_i : internal resistance of voltage input module (1 M Ω)

V_{in} : voltage applied to the analogue input

% V_i : error in the converted value caused by source and cable length in voltage input(%)


$$V_{in} = \frac{R_i \times V_s}{R_s + (2 \times R_c) + R_i}$$

$$\% V_i = \left(1 - \frac{V_{in}}{V_s} \right) \times 100\%$$

6.7.3 Exemplary Analogue Output Wiring


(1) Exemplary analogue voltage output wiring

Same wiring scheme is applied to voltage and current outputs, except that voltage/current setting switch must be set up accordingly.



(2) Exemplary analogue current output wiring

Same wiring scheme is applied to voltage and current outputs, except that voltage/current setting switch must be set up accordingly.



6.8 Operation Parameter Setting

The operation parameters of analogue mix module can be set up with XG5000 [I/O Parameter].

(1) Setting Items


For user convenience, XG5000 provides GUI (graphic user interface) for analogue mix module parameter setting. The items which can be set up in the [I/O Parameter] in the XG5000 project window are as follows.

Item	Description
[I/O Parameter]	<p>(a) Input parameter setting Sets up following items required for module operation.</p> <ol style="list-style-type: none">1) Operation channel (Stop/Run)2) Input voltage (current) range3) Output data type4) Filter constant5) averaging process6) Average value <p>(b) Output parameter setting Sets up following items required for module operation.</p> <ol style="list-style-type: none">1) Operation channel (Stop/Run)2) Output voltage (current) range3) Input data type4) Channel output status <p>(c) The parameters set up in XG5000, when downloaded, are stored in the flash memory of the XGB base unit.</p>

(2) Usage of [I/O Parameter]


(a) Create a project with XG5000. See XG5000 Program Manual for project creation.

(b) In the Project window, double-click [I/O Parameter].




Chap. 6 Analogue Combo Module


- (c) In the [I/O Parameter Setting] window, find out the slot of the base where the analogue mix module is installed, and click it.



- (d) In the above window, click the arrow button to call the window where the module can be selected. Find out the module and select it.



- (e) To set up parameter, double click with the respective slot being selected, or click [Detail] button.



Chap. 6 Analogue Combo Module

- (f) The window below where parameters can be set up by channel appears. Click the item to set up. The parameters which can be set up appear by item.


Input Parameter	CH 0	CH 1
<input type="checkbox"/> Channel status	Disable	Disable
<input type="checkbox"/> Input range	4~20mA	4~20mA
Output type	0~4000	0~4000
Filter constant	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling
Average value	0	0
Output Parameter	Channel 0	Channel 1
<input type="checkbox"/> Channel status	Disable	Disable
<input type="checkbox"/> Output range	4~20mA	4~20mA
Input type	0~4000	0~4000
<input type="checkbox"/> CH. Output type	Former value	Former value

6.9 Special Module Monitor Function

The functions of the special module monitor are as follows.

(1) Start-up of [Special Module Monitor]

Select [Online] -> [Connect], and [Monitor] -> [Special Module Monitor] to start up. [Special Module Monitor] menu is enabled only in the [Online] condition.




Note


- 1) The screen may not function properly if the system resources are not sufficient. In this case, close the screen, exit other applications, and rerun XG5000.
- 2) The I/O parameters set up in [Special Module Monitor] condition are temporarily set up for testing purpose. Therefore, these I/O parameters are deleted after exit from [Special Module Monitor].
- 3) the test function of the [Special Module Monitor] enables testing analogue mix modules without sequence programming.

(2) Usage of [Special Module Monitor]


- (a) With the XG5000 in connection (online) with the base unit of PLC, select [Monitor] -> [Special Module Monitor]. The Select Special Module window shown below will appear showing the type of the special modules and base/slot information. In the list dialog, the modules present in the PLC system are displayed.



- (b) In the above window, select the special module and click [Module Info.] to see the information window below.



- (c) Click the [Monitor] button in the “Special Module” window. The “Special Module Monitor” window will appear as shown below.



- (d) [Start Monitoring]: click [Start Monitoring] to look up the digital input data of the channel currently in operation. The screen shot below is a monitoring window when all the channels are in operation status.

Special Module Monitor

XBF-AH04A (I/O, 2/2 CH)

Input Item	Max/Min value	Current value
CH0 A/D value	0 / 0	0
CH1 A/D value	0 / 0	0

Output Item	Setting value	Current value
CH0 Digital value		0
CH1 Digital value		0

Input Item	Setting Value	Current Value
Channel	CH 0	
Channel status	Disable	Disable
Input range	4~20mA	4~20mA
Output type	0~4000	0~4000
Filter constant	0	0
Average processing	Sampling	Sampling
Average value	0	0

Output Item	Setting Value	Current Value
Channels	CH 0	
Channel status	Disable	Disable
Output range	4~20mA	4~20mA
Input type	0~4000	0~4000
CH Output type	Former value	Former value
D/A Digital value	0	0
Output enable	Disable	Disable

Buttons: Reset max/min value, Stop Monitoring, Test, Close

The screen executing [Start Monitoring]

- (e) [Test]: this function is used to change the current parameter settings of the analogue mix module. Click the settings in the fields in the bottom screen to change the parameters. [Test] can be set up only when the operation status of the XGB base unit is STOP.

Special Module Monitor

XBF-AH04A (I/O, 2/2 CH)

Input Item	Max/Min value	Current value
CH0 A/D value	0 / 0	0
CH1 A/D value	0 / 0	0

Output Item	Setting value	Current value
CH0 Digital value		0
CH1 Digital value		0

Input Item	Setting Value	Current Value
Channel	CH 0	
Channel status	Enable	Enable
Input range	4~20mA	4~20mA
Output type	0~4000	0~4000
Filter constant	0	0
Average processing	Sampling	Sampling
Average value	0	0


Output Item	Setting Value	Current Value
Channels	CH 0	
Channel status	Enable	Enable
Output range	4~20mA	4~20mA
Input type	0~4000	0~4000
CH Output type	Former value	Former value
D/A Digital value	0	0
Output enable	Disable	Disable

Buttons: Reset max/min value, Stop Monitoring, Test, Close

The screen executing [Test]

(f) Minimum/Maximum Value Monitoring

The minimum and maximum values of the input channels in operation can be monitored. However, the Max/Min values in the window are based on the current value. Therefore, the Max/Min values are not saved when exiting from the [Monitoring/Testing Screen].



The screen executing [Max/Min Value Monitoring]

(g) Close


[Close] button is for ending/closing the monitoring/testing screen. Maximum, minimum, and current values are not saved at exit.

6.10 Auto-registration of U-Device (Special Module Variable)


The variables for each module are automatically registered by referring to the information of the special modules set up in the [I/O Parameter]. User can modify variables and descriptions.

(1) Registration Procedure


(a) In [I/O Parameter], set up special module in slot.



(b) Double click [Variables/Comment].



(c) In the 'Edit' menu, select 'U-Device Auto Registration' (special module variable auto registration).



Chap. 6 Analogue Combo Module

(d) Click 'Yes.'



(e) Variables are registered as shown below.

	Variable	Type	Device	Used	Comment
1	_01_ERR	BIT	U01.00.0	<input type="checkbox"/>	Analog I/O Module: Module Error
2	_01_RDY	BIT	U01.00.F	<input type="checkbox"/>	Analog I/O Module: Module Ready
3	_01_ADDO_ACT	BIT	U01.01.0	<input type="checkbox"/>	Analog I/O Module: Input CH0 Active
4	_01_AD1_ACT	BIT	U01.01.1	<input type="checkbox"/>	Analog I/O Module: Input CH1 Active
5	_01_DAO_ACT	BIT	U01.01.2	<input type="checkbox"/>	Analog I/O Module: Output CH0 Active
6	_01_DA1_ACT	BIT	U01.01.3	<input type="checkbox"/>	Analog I/O Module: Output CH1 Active
7	_01_ADDO_IDO	BIT	U01.01.4	<input type="checkbox"/>	Analog I/O Module: Input CH0 Disconnection Flag
8	_01_AD1_IDO	BIT	U01.01.5	<input type="checkbox"/>	Analog I/O Module: Input CH1 Disconnection Flag
9	_01_ADDO_ERR	BIT	U01.01.8	<input type="checkbox"/>	Analog I/O Module: Input CH0 Error
10	_01_AD1_ERR	BIT	U01.01.9	<input type="checkbox"/>	Analog I/O Module: Input CH1 Error
11	_01_DAO_ERR	BIT	U01.01.A	<input type="checkbox"/>	Analog I/O Module: Output CH0 Error
12	_01_DA1_ERR	BIT	U01.01.B	<input type="checkbox"/>	Analog I/O Module: Output CH1 Error
13	_01_DAO_OUTEN	BIT	U01.06.0	<input type="checkbox"/>	Analog I/O Module: Output CH0 Status Setting
14	_01_DA1_OUTEN	BIT	U01.06.1	<input type="checkbox"/>	Analog I/O Module: Output CH1 Status Setting
15	_01_ADDO_DATA	WORD	U01.04	<input type="checkbox"/>	Analog I/O Module: Input CH0 Data
16	_01_AD1_DATA	WORD	U01.05	<input type="checkbox"/>	Analog I/O Module: Input CH1 Data
17	_01_DAO_DATA	WORD	U01.07	<input type="checkbox"/>	Analog I/O Module: Output CH0 DATA
18	_01_DA1_DATA	WORD	U01.08	<input type="checkbox"/>	Analog I/O Module: Output CH1 DATA

(f) In IEC types, the variables are registered as shown below.

	Variable Kind	Variable	Type	Address	Initial	Retain	Used	Comment
2	VAR_GLOBAL	_01_ADDO_DATA	WORD	XUW0.1.4		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH0 Data
3	VAR_GLOBAL	_01_ADDO_ERR	BOOL	XUX0.1.24		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH0 Error
4	VAR_GLOBAL	_01_ADDO_IDO	BOOL	XUX0.1.20		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH0 Disconnection
5	VAR_GLOBAL	_01_AD1_ACT	BOOL	XUX0.1.17		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH1 Active
6	VAR_GLOBAL	_01_AD1_DATA	WORD	XUW0.1.5		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH1 Data
7	VAR_GLOBAL	_01_AD1_ERR	BOOL	XUX0.1.25		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH1 Error
8	VAR_GLOBAL	_01_AD1_IDO	BOOL	XUX0.1.21		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Input CH1 Disconnection
9	VAR_GLOBAL	_01_DAO_ACT	BOOL	XUX0.1.18		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH0 Active
10	VAR_GLOBAL	_01_DAO_DATA	WORD	XUW0.1.7		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH0 DATA
11	VAR_GLOBAL	_01_DAO_ERR	BOOL	XUX0.1.26		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH0 Error
12	VAR_GLOBAL	_01_DAO_OUTEN	BOOL	XUX0.1.96		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH0 Status Setti
13	VAR_GLOBAL	_01_DA1_ACT	BOOL	XUX0.1.19		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH1 Active
14	VAR_GLOBAL	_01_DA1_DATA	WORD	XUW0.1.8		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH1 DATA
15	VAR_GLOBAL	_01_DA1_ERR	BOOL	XUX0.1.27		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH1 Error
16	VAR_GLOBAL	_01_DA1_OUTEN	BOOL	XUX0.1.97		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Output CH1 Status Setti
17	VAR_GLOBAL	_01_ERR	BOOL	XUX0.1.0		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Module Error
18	VAR_GLOBAL	_01_RDY	BOOL	XUX0.1.15		<input type="checkbox"/>	<input type="checkbox"/>	Analog I/O Module: Module Ready
19						<input type="checkbox"/>	<input type="checkbox"/>	


(2) Saving Variables

- The contents in the 'View Variables' tab can be saved in a text file.
- In the 'Edit' menu, select 'Save as Text File.'
- The contents in the 'View Variables' tab are saved in a text file.


(3) Viewing Variables in Program

The figures below present examples of use in XGB “S” and “H” types.


(a) Below is an exemplary program for XG5000.




(b) In the 'View' menu, click 'View Variables.' The devices are changed into variables.




(c) In the 'View' menu, click 'View Device/Variables' to look up the devices and variables at the same time.



(d) In the 'View' menu, click 'View Device/Description' to look up the devices and descriptions at the same time.



(e) For IEC type also, as shown in Fig. (a) ~ (d), you can look up variables with diversified options in the 'View' menu. The figure below is the case of an IEC type with which the 'View Variables/Descriptions' option.



6.11 Constitution and Function of Internal Memory

An analogue mix module has internal memory for data communication with XGB base unit.

6.11.1 Analogue Data I/O Area


The table below presents the analogue data I/O area.

Variable	Type	Device Allocation		Description	Read/Write	Signal Direction
		"S" or "H" Type	IEC Type			
_0y_ERR	BIT	U0y.00.0	%UX0.y.0	Module error	Read	AH04A CPU →
_0y_RDY	BIT	U0y.00.F	%UX0.y.15	Module ready		
_0y_AD0_ACT	BIT	U0y.01.0	%UX0.y.16	Input Ch 0 operating	Read	AH04A CPU →
_0y_AD1_ACT	BIT	U0y.01.1	%UX0.y.17	Input Ch 1 operating		
_0y_DA0_ACT	BIT	U0y.01.2	%UX0.y.18	Output Ch 0 operating		
_0y_DA1_ACT	BIT	U0y.01.3	%UX0.y.19	Output Ch 1 operating		
_0y_AD0_IDD	BIT	U0y.01.4	%UX0.y.20	Input Ch 0 open wire detected	Read	AH04A CPU →
_0y_AD1_IDD	BIT	U0y.01.5	%UX0.y.21	Input Ch 1 open wire detected		
_0y_AD0_ERR	BIT	U0y.01.8	%UX0.y.24	Input Ch 0 error	Read	AH04A CPU →
_0y_AD1_ERR	BIT	U0y.01.9	%UX0.y.25	Input Ch 1 error		
_0y_DA0_ERR	BIT	U0y.01.A	%UX0.y.26	Output Ch 0 error		
_0y_DA1_ERR	BIT	U0y.01.B	%UX0.y.27	Output Ch 1 error		
_0y_AD0_DATA	WORD	U0y.04	%UW0.y.4	Input Ch 0 converted value	Read	AH04A CPU →
_0y_AD1_DATA	WORD	U0y.05	%UW0.y.5	Input Ch 1 converted value	Read	AH04A CPU →
_0y_DA0_OUTEN	BIT	U0y.06.0	%UX0.y.96	Ch 0 output state setting	Write	AH04A CPU ↔
_0y_DA1_OUTEN	BIT	U0y.06.1	%UX0.y.97	Ch 1 output state setting		
_0y_DA0_DATA	WORD	U0y.07	%UW0.y.7	Output Ch 0 input value	Write	AH04A CPU ↔
_0y_DA1_DATA	WORD	U0y.08	%UW0.y.8	Output Ch 1 input value	Write	AH04A CPU ↔

- In the device allocation, the small letter 'y' is the No. of the slot where the module is installed.
- For example, to read the 'Input Ch 1 Converted Value' of the analogue mix module installed in the 4th slot, write in U04.05. (%UW0.4.5 for IEC types)




- To read the 'Output Ch 1 Output Status Setting' of the analogue mix module installed in the 5th slot, write in U05.06.1 (%UX0.5.97 for IEC types)



(1) Module Ready/Error Flag () is for IEC types, x: slot No.)


- (a) U0x.00.F(%UX0.x.15): at power on or reset of PLC CPU, turns on when the analogue I/O conversion is ready, and analogue conversion is performed.
- (b) U0x.00.0(%UX0.x.0): the flag indicating the error status of A/D conversion module.



(2) Operation channel information/ open-wire detection information/ channel error information flags () is for IEC types, x: slot No.)

This is the area for storing the operation information, input wire open detection, and channel error information by channel.


- The base No. of the XGB PLC is 0.



(3) Digital Output Values () is for IEC types, x: slot No.)

- (a) A/D converted digital values are outputted to buffer memory address U0x.04 ~ U0x.05 (%UW0.x.4 ~ %UW0.x.5) by channel-basis.
- (b) Digital output values are saved in 16-bit binary figures.

- The base No. of the XGB PLC is 0.



(4) Output Permit Setting () is for IEC types, x: slot No.)

(a) Output permit/prohibit can be set up for each channel.

(b) The default setting is 'Output Prohibited.'

☐ The base No. of the XGB PLC is 0.

	Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
U0x.06 (%UW0.x.6)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Output CH.1	Output CH.0

Output status setting
 BitOn (1): Output permitted
 BitOff (0): Output prohibited

(5) Digital Input Values () is for IEC types, x: slot No.)

(a) Digital inputs can be set up as unsigned (-48~4047), signed (-2048~2047), precision, or percentile (-12~1011) values.

(b) When digital input value is not set up, they are processed as zero.

☐ The base No. of the XGB PLC is 0.

	Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
U0x.07 (%UW0.x.7)	Output channel 0 input value															
U0x.08 (%UW0.x.8)	Output channel 1 input value															

6.11.2 Operation Parameter Setting Area

The operation parameter setting area of the analogue mix module is as follows.

Memory Add.	Description	Setting	R/W	Command
0	Appoint operating channel	Bit Off (0): stop, Bit ON (1): run	R/W	PUT GET
1	I/O range setting	I/O range setting (4 bit per Ch.) 0: 4 ~ 20 mA 1: 0 ~ 20 mA 2: 1 ~ 5 V 3: 0 ~ 5 V 4: 0 ~ 10 V	R/W	
2	I/O data type setting	I/O data type setting (4 bit per Ch.) 0: 0 ~ 4000 1: -2000 ~ 2000 2: Precision value 3: 0 ~ 1000 - for precision values; 4 ~ 20 mA: 400 ~ 2000 0 ~ 20 mA: 0 ~ 2000 1 ~ 5 V: 100 ~ 500 0 ~ 5 V: 0 ~ 500 0 ~ 10 V: 0 ~ 1000	R/W	
3	Input Ch 0 filter value setting	0 or 4 ~ 64000	R/W	
4	Input Ch 1 filter value setting		R/W	
5	Averaging method setting	Averaging method setting (4 bit per Ch.) 0: Sampling 1: Time average 2: Cycle average 3: Moving average	R/W	
6	Input Ch 0 average value setting	Time average: 4 ~ 16000 [ms] Cycle average: 2 ~ 64000 [cycles] Moving average: 2 ~ 100 [samples]	R/W	
7	Input Ch 1 average value setting		R/W	
8	Channel output status setting	0: previous value 1: min. value 2: median 3: max.	R/W	GET
9	Set-up error information output area	10#: Input Ch range setting error 20#: Input Ch data type setting error 30#: Input Ch filter value setting error 40#: Input Ch averaging setting error 50#: Input Ch average value setting error 60#: Output Ch range setting error 70#: Output Ch data type setting error 80#: Ch output status setting error 90#: Output Ch input value range-over error (#: channel number)	R	

Note

(1) If the memory address 0~8 area is entered with values different from the setting. U0x.01.8~U0x.01.B (setting error representative flag, for IEC type, %UX0.x.24~%UX0.x.27) is ON and runs with default values. The error information is displayed in the setting error information are (No. 9).




CAUTION

(2) System areas (after No. 10) are read/write protected. Changing these areas may cause malfunction or failure of the product.

(1) Operating Channel Setting


The default setting for operating channel is 'Stop.'



(2) I/O Range Setting

(a) The analogue I/O voltage range is DC 1~5V, DC 0~5V, DC 0~10V, and analogue current I/O range is DC 4~20mA, DC 0~20mA.


(b) Default range is DC 4~20mA.



(3) I/O Data Type Setting

(a) I/O data type can be set up for each channel.

(b) If the I/O data type is not set up, all the channels are processed in 0~4000 range.



Chap. 6 Analogue Combo Module

(4) Filter Constant Setting

- (a) If set to 0, no filtration is processed.
- (b) Default setting is 0 – no filtration process.

	Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Address3	Input channel 0 filter constant (0 or 4 ~ 64000 ms)															
Address4	Input channel 1 filter constant (0 or 4 ~ 64000 ms)															

(5) Averaging Method Setting

- (a) Averaging method can be one of; time average, cycle average, moving average.
- (b) Default setting is no averaging throughout the channels.

	Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Address5	—	—	—	—	—	—	—	—	Input CH.1				Input CH.0			

Set-up averaging method (4bit per Ch)
 0 : Sampling
 1 : Time average
 2 : Cycle average
 3 : Moving average

(6) Average Value Setting

- (a) Set up average values in accordance with the setting area of the averaging method.
- (b) If the average value is out of setting range, averaging is not applied.


	비트15	비트14	비트13	비트12	비트11	비트10	비트9	비트8	비트7	비트6	비트5	비트4	비트3	비트2	비트1	비트0
Address6	Input channel 0 average value															
Address7	Input channel 1 average value															

Input channel# average value setting
 Time average : 4 ~ 16000 [ms]
 Cycle average : 2 ~ 64000 [Cycle]
 Moving average : 2 ~ 100 [samples]

Chap. 6 Analogue Combo Module


(7) Output Status Setting

- (a) This sets up the analogue output status when the XGB base unit is changed from run to stop.
 (b) Default setting is the Previous Value output.



(8) Error Code (Address 9)

- (a) Saves the error code detected by the analogue mix module.
 (b) The types and descriptions of the error are as follows.




Type	Error Code	LED Lamp	Description	Priority Order	Remark
Input Error	10#	INPUT LED 1s flash	Input Ch range setting error	2	#: Ch No. Input Ch. 0,1 Output Ch. 0,1
	20#		Input Ch data type setting error	3	
	30#		Input Ch filter cons. Setting error	4	
	40#		Input Ch averaging setting error	5	
	50#		Input Ch average value setting error	6	
Output Error	60#	OUTPUT LED 1s flash	Output Ch range setting error	7	
	70#		Output Ch data type setting error	8	
	80#		Output Ch status setting error	9	
	90#		Output Ch input value range-over error	1	

- (c) In case of plural errors, the code with higher priority order will be saved.

(9) System Area (after Address 10)

- (a) System area (after address 10) is read/write protected.

	Caution	Modifying this area can cause malfunction or failure of product.
---	----------------	--

6.12 Example Program

- (1) This sample program sets up operating parameters of analogue mix module.
- (2) Initial settings are saved in the internal memory of the module by input by once.
- (3) The sample program below controls the I/O data of the analogue mix module at slot #1 and check open wire.

6.12.1 Example of [I/O Parameter] Usage

(1) I/O Parameter Setting Window

Slot	Module	Comment	Input Filter	Emergency Out	Allocation
0(main)	DC 24V INPUT/RELA		3 Standard [ms]	Default	
1	XBF-AH04A (I/O, 2/2)				
2					
3					
4					
5					
6					
7					
8					
9					
10					


Input Parameter	CH 0	CH 1
<input type="checkbox"/> Channel status	Enable	Disable
<input type="checkbox"/> Input range	4~20mA	0~10V
Output type	0~4000	0~4000
Filter constant	0	0
<input type="checkbox"/> Average processing	Sampling	Sampling
Average value	0	0
Output Parameter	Channel 0	Channel 1
<input type="checkbox"/> Channel status	Enable	Disable
<input type="checkbox"/> Output range	4~20mA	0~10V
Input type	0~4000	0~4000
<input type="checkbox"/> CH. Output type	Former value	Former value

- (a) Input Channel 0 is set to operating channel and input range is set to 4~20mA.
- (b) Output Channel 0 is set to operating channel and output range is set to 4~20mA.

Chap. 6 Analogue Combo Module

(2) Sample Input Program


Input CH0 program



- (a) When the module is in normal operation, M0000 is turned On.
 U01.00.0(Module Error) = Off
 U01.00.F(Module Ready) = On
 U01.01.0(Input Channel 0 in-operation) = On
 U01.01.8(Input Channel 0 Error) = Off
- (b) When M0000 is ON, Input Channel 0 Converted Value(U01.04) is moved to D00100.
- (c) If open-wire error occurs in channel 0, U01.01.4(channel 0 open-wire) is ON, and M0001 bit is set.


(3) Sample Output Program

Output CH0 program




- (a) When the module is in normal operation, M00010 is turned ON.
 U01.00.0(Module Error) = Off
 U01.00.F(Module Ready) = On
 U01.01.2(Output Channel 0 in-operation) = On
 U01.01.A(Output Channel 0 Error) = Off
- (b) When M00010 is On, channel 0 output status setting (U01.06.0) is turned ON and output is permitted.
- (c) When M00010 is On, the data in D00200 is transmitted to Output Channel 0 input value (U01.07) and outputted.

(4) Sample Input Program (for IEC type)



- When the module is in normal operation, %MX0 is turned ON.
 %UX0.1.0(Module Error) = Off
 %UX0.1.15(Module Ready) = On
 %UX0.1.16(Input Channel 0 in-operation) = On
 %UX0.1.24(Input Channel 0 Error) = Off
- When %MX0 is ON, Input Channel 0 Converted Value(%UW0.1.4) is transferred to "Channel 0Input" variable.
- If open-wire error occurs at Channel 0, %UX0.1.20(Channel0open) turns ON and %MX1 bit is set.


(5) Sample Output Program (for IEC type)



- When the module is in normal operation, %MX10 is turned ON.
 %UX0.1.0(Module Error) = Off
 %UX0.1.15(Module Ready) = On
 %UX0.1.18(Output Channel 0 in-operation) = On
 %UX0.1.26(Output Channel 0 Error) = Off
- When %MX10 is ON, Channel0 output status setting (%UX0.1.96) is turned ON and output is permitted
- When %MX10 is ON, the data of the 'Channel 0output' variable is transferred to Output Channel 0 Input Value (%UW0.1.7) and outputted.


6.12.2 Exemplary Usage of PUT/GET Command

(1) Sample Input Program Input CH0 Program




- Using PUT command to write h0005 in the address 0, slot 1 to operate Input Channel 0 and Output Channel 0.
- Using PUT command to write h0000 in the address 1, slot 1 to set the input range of Input Channel 0 to DC 4 ~ 20mA and the output range of the Output Channel 0 to DC 4 ~ 20mA.
- When the module is in normal operation, M0000 is turned ON.
U01.00.0(Module Error) = Off, U01.00.F(Module Ready) = On
U01.01.0(Input Channel 0 in-operation) = ON, U01.01.8(Input Channel 0 Error) = Off
- When M0000 is ON, Input Channel 0 Converted Value(U01.04) is transferred to D00100.
- If open-wire error occurs at Channel 0, U01.01.4(ChannelOpen) is ON, and M0001 bit is set.

(2) Sample Output Program Output CH0 Program




- Using PUT command to write h0005 in the address 0, slot 1 to operate Input Channel 0 and Output Channel 0.
- Using PUT command to write h0000 in the address 1, slot 1 to set the input range of Input Channel 0 to DC 4 ~ 20mA and the output range of the Output Channel 0 to DC 4 ~ 20mA.
- When the module is in normal operation, M00010 is turned ON.
U01.00.0(Module Error) = Off, U01.00.F(Module Ready) = On
U01.01.2(Output Channel 0 in-operation) = ON, U01.01.A(Output Channel 0 Error) = Off
- When M00010 is ON, Channel 0 Output Status setting (U01.06.0) is turned ON and output is permitted.
- When M00010 is ON, data of D00200 is transferred to Output Channel 0 Input Value (U01.07) and outputted.

(3) Sample Input Program (for IEC type)



- Using PUT command to write h0005 in the address 0, slot 1 to operate Input Channel 0 and Output Channel 0.
- Using PUT command to write h0000 in the address 1, slot 1 to set the input range of Input Channel 0 to DC 4 ~ 20mA and the output range of the Output Channel 0 to DC 4 ~ 20mA.
- When the module is in normal operation, %MX0 is turned on.
 %UX0.1.0(Module Error) = Off
 %UX0.1.15(Module Ready) = On
 %UX0.1.16(Input Channel 0 in-operation) = On
 %UX0.1.24(Input Channel 0 Error) = Off
- When %MX0 is on, Input Channel 0 Converted Value (%UW0.1.4) is transferred to "Channel 0Input" variable.
- If open-wire error occurs at Channel 0, %UX0.1.20(Channel0open) is turned on and %MX1 bit is set.

(4) Sample Output Program (for IEC type)



- Using PUT command to write h0005 in the address 0, slot 1 to operate Input Channel 0 and Output Channel 0.
- Using PUT command to write h0000 in the address 1, slot 1 to set the input range of Input Channel 0 to DC 4 ~ 20mA and the output range of the Output Channel 0 to DC 4 ~ 20mA.
- When the module is in normal operation, %MX10 is turned on.
 %UX0.1.0(Module Error) = Off
 %UX0.1.15(Module Ready) = On
 %UX0.1.18(Output Channel 0 in-operation) = On
 %UX0.1.26(Output Channel 0 Error) = Off
- When %MX10 is on, Channel 0 Output Status setting (%UX0.1.96) is turned on and output is permitted.
- When %MX10 is on, data of the 'Channel 0output' variable is transferred to Output Channel 0 Input Value (%UW0.1.7) and outputted.

6.13 Troubleshooting

This section describes methods for identifying the troubles which may occur during the operation of analogue mix module, and their solutions.

6.13.1 LED Indication for Error

An analogue mix module has INPUT LED and OUTPUT LED to indicate error status of the module.

Classification	Normal State	Channel Open (Input)	Parameter Setting Error	Module H/W Failure (Serious Failure)
INPUT LED	On	Flash at 1s intervals	Flash at 1s intervals (input parameter setting error)	Flash at 0.2s intervals
OUTPUT LED	On	N/A	Flash at 1s intervals (output parameter setting error)	Flash at 0.2s intervals
Module Behavior	All functions are normal	All functions are performed. Indicates min. input value	All functions work at default parameter setting	Module cannot function
Action	-	Check input wire	Check parameter setting	Request for A/S

6.13.2 Checking Module Condition

XG5000's system monitor enables verification of the analogue mix module conditions (module type, module information, OS version).

(1) Procedure

The verification can be done in 2 ways;


- (a) [Monitor] -> [System Monitor] -> mouse right click on module icon -> [Module Information]
- (b) [Monitor] -> [System Monitor] -> double click module icon.

(2) Module Information


- (a) Module type: shows the information on the present module.
- (b) Module information: shows the OS version of the module.
- (c) OS version: shows release date of Module OS.

6.13.3 Troubleshooting


(1) INPUT LED or OUTPUT LED is off.




(2) INPUT LED flashes.



(3) OUTPUT LED flashes.



(4) Analogue I/O value is abnormal.



7.1.2 Features

The built-in PID control functions of XGB series feature as follows.

- (1) Since operations are executed within CPU part, it can be controlled by PID parameters and PLC program without PID module.
- (2) A variety of controls can be selected
 - That is, a user can easily select P operation, PI operation and PID operation.
- (3) Precise control operation
 - It can make precise PID control operations possible through floating point operations.
- (4) PWM (Pulse Width Modulation) output available.
 - It outputs control operation results to the output contact point designated by a user through PWM.
- (5) Improving convenience of control settings and monitoring
 - Through parameter setting method and K area flag, it maximizes control parameter settings during operation and convenience of monitoring
- (6) Freely selectable operation direction
 - Forward, reverse and mixed forward/reverse operations are available
- (7) Cascade operation realizing quick and precise PID control
 - It can increase quickness of response to disturbance through cascade loop.
- (8) Various additional functions
 - PID control can be achieved by various methods a user wishes because set value ramp, the present value follow-up, limiting change of values and types of alarm functions are provided.

7.2 PID Control

7.2.1 Basic theory of PID control

Here describes basic theory of PID control and how to configure PID control.

(1) Terms

Terms used in this user manual are as follows.

- PV: status of plant detected by sensor (Process value)
- SV: Target value (Set Value) to control plant, if control is done normally, PV should follow the SV.
- E: error between SV and PV. It can be expressed as (SV-PV).
- K_p: proportional coefficient
- T_i: Integral time constant. Sometimes called integral time
- T_d: Derivative time constant. Sometimes called derivative time
- MV: Control input or control device output. The input to plant to make PV follow the V
- T_s: Sampling time, a cycle of operation to execute PID control

(2) PID operation expression

Basic PID operation expressions are as follows.

$$E = SV - PV \quad (7.2.1)$$

$$MV_P = K_P E \quad (7.2.2)$$

$$MV_i = \frac{K_P}{T_i} \int E dt \quad (7.2.3)$$

$$MV_d = K_P T_d \frac{dE}{dt} \quad (7.2.4)$$

$$MV = MV_P + MV_i + MV_d \quad (7.2.5)$$

PID control operation expressions of XGB series are more complicate than expression (7.2.1) ~ (7.2.5) mathematically but those are base on the above expression. The followings describe the characteristics of control process with an example that controls the output temperature of heating system in figure 7.1. At this example, the system and PID parameters imaginary to help the comprehension and those may be different with real heating system. If the heating system in figure 7.1 is expressed as second order system with transfer function like expression (7.2.6) in frequency domain, it is expressed as differential equation like expression (7.2.7) in the time domain.

$$\text{Transfer function} = \frac{32}{(2s + 1)(3s + 5)} \quad (7.2.6)$$

$$\frac{6}{32} \frac{d^2 y(t)}{dt^2} + \frac{13}{32} \frac{dy(t)}{dt} + 5y(t) = x(t) \quad (7.2.7)$$

That is, x(t) is Manipulated value and y(t) is Process value.

Chapter 7 PID Function (Built-in function)

At this system, we assume that the PID parameter is specified as shown below to describe the PID control operation.

Items	Value	Items	Value
Output temperature of heating system (PV)	0℃	Proportional coefficient (K_P)	5
Target temperature (SV)	50℃	Integral time (T_i)	3s
Cycle of operation	0.01s	Derivative time (T_d)	0.19s

<Table 7.1 example of control of heating system>

At this system, if we assume that target value of output temperature is 50℃ and initial value of output temperature is 0℃, SV and PV becomes 50 and 0 respectively. In case of this, PID controller acts as follows.

(3) Proportional control (P control)

In the proportional control, the controller yields output that is proportional to error. Manipulated value of controller by Proportional control is as follows.

$$MV_P = E \times K_P \quad (7.2.8)$$


(a) If P control starts, output of controller by initial P operation is as follows.

$$MV_0 = 50 \times 4 = 200$$

If P control is executed for 10 seconds, output temperature will be as table 7.2. If this is expressed with graph, it will be as figure 7.2.

Time	Target temp.	Proportional coefficient	Output temp.	Error
0	50	5	0	50
1	50	5	44.98	5.02
2	50	5	53.08	-3.08
3	50	5	50.15	-0.15
4	50	5	48.42	1.58
5	50	5	48.28	1.72
6	50	5	48.44	1.56
7	50	5	48.49	1.51
8	50	5	48.49	1.51
9	50	5	48.49	1.51

< Table 7.2 example of Proportional control >




< Figure 7.2 simulation of proportional control >

- (b) Concerning the result of simulation, it has the maximum overshoot of about 23.4°C at 0.62s and after 7s, it converges at 48.49°C with offset of 1.51°C (about 3%).
- (c) Offset is an unavoidable error when only P control is executed. Offset decreases proportional to P coefficient but overshoot increases proportional to P coefficient. Table 6.3 and figure 6.3 is simulation of offset and overshoot according to P coefficient.

Time	Target temperature	Kp = 5	Kp = 2.5	Kp = 1
0	50	0	0	0
1	50	45.02	63.46	46.67
2	50	53.11	42.52	46.77
3	50	50.15	47.93	41.38
4	50	50.22	47.25	41.60
5	50	48.27	46.96	43.30
6	50	48.35	46.92	43.25
7	50	48.44	46.90	43.21
8	50	48.53	46.90	43.18
9	50	48.53	46.90	43.18

<Table 7.3 Temperature- time table according to P coefficient>



< Figure 7.3 Temperature- time graph according to P coefficient >

(c) Considering table 7.3, as P coefficient decreases, offset increases but overshoot decreases.

(d) Generally, offset can't be solved with only P control. In order to remove the offset, P control and I control is used together.

(4) Proportional Integral Control (PI Control)

In I control, it yields the output proportional to error accumulated according to time. And the expression is as follows.

$$MV_i = \frac{K_P}{T_i} \int E dt \quad (7.2.9)$$

(a) In the expression 7.2.9, T_i means the time takes for MV_i output by I control, to be added into real output.

(b) Generally, I control is used with P control. So the expression of PI control is as follows.

$$MV = MV_P + MV_i = E \times K_P + \frac{K_P}{T_i} \int E dt \quad (7.2.10)$$

(c) In the above heating system, the simulation results are as shown in the table 6.4 when proportional coefficient is 2.5 and integral time is 1.5s.


Time	Target temp.	Proportional coefficient	Integral time	P Control	PI Control
0	50	2.5	1.5	0	0
1	50	2.5	1.5	63.46	74.41
2	50	2.5	1.5	42.52	40.63
3	50	2.5	1.5	47.93	52.99
4	50	2.5	1.5	47.05	49.67

Chapter 7 PID Function (Built-in function)


Time	Target temp.	Proportional coefficient	Integral time	P Control	PI Control
5	50	2.5	1.5	46.96	49.70
6	50	2.5	1.5	47.12	50.38
7	50	2.5	1.5	47.03	49.76
8	50	2.5	1.5	47.07	50.14
9	50	2.5	1.5	47.06	49.94
10	50	2.5	1.5	47.06	50.02
11	50	2.5	1.5	47.06	49.99
12	50	2.5	1.5	47.06	50.00
13	50	2.5	1.5	47.06	50.00
14	50	2.5	1.5	47.06	50.00
15	50	2.5	1.5	47.06	50.00

< Table 7.4 Temp.- time table >

- (d) Considering table 7.4 and figure 7.4, if P and I control is used together, offset is removed and temp. converges at 50°C, target temp. after 12s
- (e) But in this case, convergence time is longer than that of P control and overshoot is larger. Generally, as integral time increases, overshoot decrease. About this, refer to the figure 7.5.



< Figure 7.4 Temp.- time graph >



< Figure 7.5 overshoot according to integral time >

(f) Like this, if I control is used, overshoot is larger. According to system, large overshoot can be problem. In order to solve this, PID control is used.

(5) Proportional integral derivative control (PID control)

In D control, when status of system changes rapidly, D control yields the output to reduce the error. Namely, D control yields the output proportional to change velocity of current status. So if D control is used, response speed of controller about status change of system increases, and overshoot decreases. Output of controller by D control is as shown in expression 7.2.11.

$$MV_d = K_p T_d \frac{dE}{dt} \quad (7.2.11)$$

(a) In the expression 7.2.11, T_d means the time takes for MV_d output by I control, to be added into real output.

(b) Generally, D control is not used solely but with PD control. So PID control is expressed as expression 7.2.12.


$$MV = MV_p + MV_i + MV_d = E \times K_p + \frac{K_p}{T_i} \int E dt + K_p T_d \frac{dE}{dt} \quad (7.2.12)$$

(c) The figure 7.6 is simulation result when PID control is applied to above heating system.

Chapter 7 PID Function (Built-in function)

Time	Target temp.	Proportional coefficient	Integral time	Derivative time	PI Control	PID Control
0	50	2.5	1.5	0.3	0	0
1	50	2.5	1.5	0.3	74.41	55.50
2	50	2.5	1.5	0.3	40.63	56.33
3	50	2.5	1.5	0.3	52.99	52.50
4	50	2.5	1.5	0.3	49.67	50.92
5	50	2.5	1.5	0.3	49.70	50.34
6	50	2.5	1.5	0.3	50.38	50.12
7	50	2.5	1.5	0.3	49.76	50.05
8	50	2.5	1.5	0.3	50.14	50.02
9	50	2.5	1.5	0.3	49.94	50.01
10	50	2.5	1.5	0.3	50.02	50.00
11	50	2.5	1.5	0.3	49.99	50.00
12	50	2.5	1.5	0.3	50.00	50.00
13	50	2.5	1.5	0.3	50.00	50.00

< Table 7.5 comparison of PI control and PID control >



< Figure 7.6 comparison of PI control and PID control >

- (d) Considering table 7.5, in case PID control is used, max. overshoot decreases from 16.5°C to 8.5°C. At this time, P coefficient, integral time, derivative time are not optimal values, just one of the examples. Actually, P coefficient, integral time, derivative time values vary according to PID control system.

7.2.2 Functional specifications of PID control

(1) Functional Specifications

The performance specifications of the built-in PID control function in XGB series are summarized in the below table.

Item		Specifications
No. of loops		16 Loop
Scope of setting PID constants	Proportional constant(P)	Real number (0 ~ 3.40282347e+38)
	Integral constant(I)	Real number (0 ~ 3.40282347e+38), unit: second
	Differential constant(D)	Real number (0 ~ 3.40282347e+38), unit: second
Scope of set value		INT (-32,768 ~ 32,767)
Scope of present value		INT (-32,768 ~ 32,767)
Scope of maneuver value		INT (-32,768 ~ 32,767)
Scope of manual maneuver value		INT (-32,768 ~ 32,767)
Indication	RUN/STOP	Operation: PID RUN Flag On (by loops) Stop: PID RUN Flag Off (by loops)
	Error	Normal: PID Error Flag Off (by loops) Error: PID Error Flag On, Error code occurrence (by loops)
	Warning	Normal: PID Warning Flag Off (by loops) Error: PID Warning Flag On, Warnig code occurrence (by loops)
Control operation		Control of P,PI,PD and PID, control of forward/reverse operation
Control interval		10.0ms ~ 6,553.6ms (0.1msUnit)
Additional functions	PWM output	Supportable
	Mixed forward/reverse output	Supportable
	Limiting change of present value	INT (-32,768 ~ 32,767)
	Limiting change of maneuver value	INT (-32,768 ~ 32,767)
	Equally dividing set value	0 ~ 65,536 (frequency of control cycle time)
	Present value follow-up	0 ~ 65,536 (frequency of control cycle time)
	Cascade control	Supportable.
	Min./max. present value	-32,768 ~ 32,767
	Differential filter	0.01 ~ 655.35 (x 100 Scaled Up)
	Dead band setting	0 ~ 65,535
	Prevention of dual integral accumulation	Supportable
	PID operation pause	Supportable

< Table 7.6 built-in PID control performance specification >


7.2.3 PID control parameter setting

To use the built-in PID control function of XGB series, it is necessary to set PID control parameters by loops in the parameter window and operate it through the commands. Here, it explains parameters to use PID control functions and how to set them.

(1) PID parameter settings


Follow the steps below to set the PID control function parameters of XGB series.

- (a) If selecting the built-in parameters in Parameter of the project window, it shows the built-in parameter setting window as in below figure.



< Figure 7.7 Parameters setting window >

- (b) If selecting PID Control, it shows the PID control parameter setting window as in below figure.



[Figure 7.8 Built-in PID function parameters setting window]

Chapter 7 PID Function (Built-in function)

(c) Input items

The items to set in the built-in PID function parameter window and the available scope of them are summarized in below table.

Items	Description	Scope
RUN mode	Set the operation mode of PID control.	Auto/manual operation
RUN direction	Set the operation direction of PID control.	Forward/reverse
Prevention of dual integral accumulation	Set whether to allow dual integral accumulation.	Disabled/enabled
PWM output	Set whether to allow PWM output of maneuver value.	Disabled/enabled
Operation cycle time	Set the operation cycle time of PID control cycle.	100 ~ 65535
Set value	Set target control value.	-32,768 ~ 32,767
Proportional gain	Set proportional gain.	Real number
Integral time	Set integral time.	Real number
Differential time	Set differential time.	Real number
Limiting change of present value	Set the limited change of present value per operation cycle.	-32,768 ~ 32,767
Limiting change of maneuver value	Set the limited change of maneuver value per operation cycle.	-32,768 ~ 32,767
Max. maneuver value	Set the max. maneuver value for control.	-32,768 ~ 32,767
Min. maneuver value	Set the min. maneuver value for control.	-32,768 ~ 32,767
Manual maneuver value	Set the manual maneuver value for control.	-32,768 ~ 32,767
DeadBand setting	Set the deadband width of the set value.	0 ~ 65,535
Differential filter value	Set the filter coefficient of differential operation.	0 ~ 65,535
PWM junction	Set the junction to which PWM output is out.	P20 ~ P3F (%QX0.0.0~%QX0.0.31)
PWM output cycle	Set the output cycle of PWM output.	100 ~ 65,535
Set value ramp	Set the frequency of set value ramp.	0 ~ 65,535
Present value follow-up	Set the follow-up frequency of the present value follow-up function.	0 ~ 65,535
Min. present value	Set the min. value of the input present value.	-32,768 ~ 32,767
Max. present value	Set the max. value of input present value.	-32,768 ~ 32,767

< Table 7.7 PID function parameter setting items >

(2) Description of Setting of PID Parameters

(a) Operation mode

It is the mode to set the operation for PID control of a loop in question.

The available scope is automatic operation or manual operation.

If automatic operation is selected, it outputs the PID control result internally operated by the input PID control parameter as the maneuver value while if manual operation is selected, it outputs the value input to the manual maneuver value parameter without PID operation modified. The default is automatic operation.


(b) Operation direction

It is designed to set the operation direction for PID control of a loop in question. The available scope is forward or reverse direction. At the moment, forward direction means increase of PV when MV increases; reverse direction means decrease PV when MV increases. For instance, a heater is a kind of forward direction system because PV(temperature) increases when output(heating) increases. A refrigerator is a kind of reverse direction system in which PV(temperature) decreases when output increases.

(c) Prevention of dual integral accumulation

It makes dual integral accumulation function enabled/disabled. To understand integral accumulation prevention function, it is necessary to explain the phenomenon of integral accumulation first of all. Every drive has a limit. That is, a motor is limited to the speed and a valve can become status overcoming the complete open/close. If it happens that MV output from a control is beyond the output limit of a drive, its output is maintained as saturated, which may deteriorate the control performance of a system and shorten the life of a drive. Formula (7.2.3) shows that the integral control among PID control output components accumulates errors as time goes on, from which it may take more time to return the normal status after the actuator is saturated in a system of which response characteristically is slow. It is so called integral accumulation phenomenon as illustrated in Fig. 7.9, which shows that if the initial error is very large, the error is continuously accumulated by integral control. Accordingly, a drive is saturated within its output upper limit while the control signal is getting larger, keeping being saturated for a long while until the drift becomes negative and the integral term turns small enough. Due to the operation, the PV may have a large over-shoot as seen in the figure. Such a wind-up phenomenon may occur if the initial drift is large or by a large disturbance or due to malfunction of a device.

The PID function of XGB series is basically with the integral accumulation prevention function, cutting off any integral accumulation phenomenon. In addition, it can detect a time when SV is suddenly decreased, providing a more strong dual integral accumulation prevention function.



< Figure 7.9 Integral accumulation phenomenon >


Chapter 7 PID Function (Built-in function)

(d) PWM Output Enabled

PWM output means an output method to turn a junction on – off with a duty proportional to control output calculated by a uniform output cycle. If PWM output is enabled, it realizes PWM output in accordance with PWM output cycle set in the parameter of PWM output junction(P20 ~ P3F) designated in the parameter. At the moment, the PWM output cycle follows the PWM output cycle separately set in PID operation cycle. figure shows the relation between PID control output and PWM output.

i.e.) if PWM output cycle: 1 second, PWM output junction: P20, max. output: 10000, min. output: 0

Time	Output	P40 junction operation
0 sec	5000	0.5 sec On, 0.5 sec Off
1 sec	3000	0.3 sec On, 0.7 sec Off



[Figure 7.10 Relation between PWM output cycle and MV]

(e) Set value

It sets the target of a loop in question, that is, the target status a user wishes to control. In case of the PID control built in XGB, physical values (temperature, flow rate, pressure and etc) of an object to control is not meaningful and instead, it should use the physical amount of an object to control after converting them into numerals. For instance, in order to control a system using a sensor that the output is 0V when its heating device temperature is 0°C while it is 10V when the temperature is 100°C as much as 50°C, it is necessary to set SV as 2000 (as long as it uses AD input module XBE-AD04A).

(f) Operation cycle

It sets the cycle to yield control output by executing the built-in PID operation. The setting cycle is 0.1ms and available between 10ms ~ 6553.5ms (setting value: 100 ~ 65,535) while it is set at a unit of integer per 0.1ms. For instance, to set PID operation per 100ms, set the operation cycle as 1000.

(g) Proportional gain

It is intended to set the proportional coefficient of a PID loop in question (K_p). As larger K_p , the proportional control operation is getting stronger. The scope is real number.

(h) Integral time

It sets the integral time of PID loop in question (T_i). As larger the integral time, the integral operation is getting weaker. The scope is real number at the unit of second.

(i) Differential time

It sets the differential time of PID loop in question (T_d). As larger the differential time, the differential operation is getting stronger. The scope is real number at the unit of second.

(j) Limiting change of present value

It sets the limit of change in present value of PID loop in question. If PV suddenly changes due to signal components such as sensor's malfunction, noise or disturbance during control of PID, it may cause sudden change of PID control output. To prevent the phenomenon, a user can set the max. limit of change in present value that is allowed per PID operation cycle. If the change of present value is limited accordingly, it may calculate the present value as much as the limit although the present value is changed more than the limit once the limit of change in present value is set. If using the PV change limit function, it may prevent against sudden change of control output owing to noise or etc. If it is, however, set too small, it may reduce the response speed to the PV change of an actual system, not to sudden change by noise or etc, so it is necessary to set the value appropriately according to the environment of a system to control in order that the PV toward the set value does not take a longer time. The available scope is between -32,768 ~ 32,767. If setting the PV change limit as 0, the function is not available.

(k) Limiting change of MV (ΔMV function)

It limits the max. size that control output, which is output by PID operation is changed at a time. The output MV in this operation cycle is not changed more than the max. change limit set in the previous operation cycle. The function has an effect to prevent a drive from operating excessively due to sudden change of output by preventing sudden change of output resulting from instantaneous change of set value. If it is, however, set too small, it may cause taking a longer time until PV reaches to its target, so it is necessary to adjust it appropriately. The available scope is between -32,768 ~ 32,767. If setting it as 0, the function does not work.

(l) Max. MV

It sets the max. value of control output that may be output by the result of PID operation. The available scope is between -32,768 ~ 32,767. If it exceeds the max. output designated by PID operation result, it outputs the set max. output and alerts the max. output excess warning. For the types and description of warnings, refer to Error/Warning Codes.

(m) Min. MV


It sets the min. value of control output that may be output by the result of PID operation. The available scope is between -32,768 ~ 32,767. If it is smaller than the min. output value designated by PID operation result, it outputs the set min. MV and alerts the min. output shortage warning. For the types and description of warnings, refer to Error/Warning Codes.

(n) Manual MV

It sets the output when the operation mode is manual. The available scope is between -32,768 ~ 32,767.

(o) DeadBand setting

It sets the deadband between set value and present value. Although it may be important to reduce normal status reply of PV for its set value even when MV fluctuates heavily, depending on control system, it may be more important to reduce the frequent change of MV although the normal status reply is somewhat getting larger. DeadBand may be useful in the case. Below figure shows an example of DeadBand setting.



[Figure 7.11 Example of DeadBand setting]

If setting deadband as in the figure, the PID control built in XGB may regard the error between PV and set value as 0 as long as PV is within the available scope of deadband from set value.


That is, in this case, the change of MV is reduced. The available scope of setting is between 0 ~ 65,535 and if it is set as 0, it does not work.

(p) Differential Filter Value Setting

It sets the coefficient of differential filter. Since differential control outputs in proportion to gradient of error and gradient of PV change, it may suddenly change MV as it generates a large response to instantaneous noise or disturbance. To prevent it, XGB series uses a value to which PV is filtered mathematically for differential control. Differential filter value is the coefficient to determine the filter degree for differential control. As smaller differential value set, as stronger differential operation is. The available scope is between 0 ~ 65,535 and if it is set as 0, the differential filter does not work.

(q) Setting set value ramp

Since the drift is suddenly large if SV is heavily changed during PID control, MV is also changed heavily to correct it. Such an operation may cause excessive operation of a system to control and a drive. To prevent it, SV ramp is used, changing SV gradually step by step when modifying SV during operation. If using the function, SV is gradually changed by SV ramp when SV is changed during PID control. At the moment, SV ramp setting represents the frequency of PID operation cycle taken from when SV starts changing to when it reaches to the final SV. For instance, if SV is to be changed from 1000 to 2000 during operation as PID operation cycle is 10ms and its SV ramp is 500, SV may reach to 2000 after $500 \times 10\text{ms} = 5$ seconds, that is, as it increases each 2 per operation cycle and after the 500th operation scans. The available scope of setting is between 0 ~ 65,535 and it is set as 0, it does not work.



[Figure 7.12 SV Ramp function]

Chapter 7 PID Function (Built-in function)

(r) PV Follow-up setting

It is intended to prevent any excessive operation of a drive resulting from sudden change of output at the initial control and changes SV gradually from PV at the time when PID operation starts, not directly to SV in case control just turns from stop to operation mode or it changes from manual to automatic operation. At the moment, SV represents the frequency of PID operation cycles taken from when control starts to when it reaches to the set SV (other operations are same as SV ramp function). The available scope is between 0 ~ 65,535. If SV is changed again while PV follow-up is in operation, the SV would be also changed according to SV ramp.

(s) Min./max. PV

It sets the min./max. value entered as the present value of PID control. The available scope is between -32,768 ~ 32,767.

Chapter 7 PID Function (Built-in function)

7.2.4 PID flag

The parameter set by the XGB series built-in PID control function is saved into the flash memory of the basic unit. Such parameters are moved to K area for the built-in PID function as soon as PLC turns from STOP to RUN mode. PID control operation by PID control command is executed through K area data for PID functions. Therefore, if a user changes the value in the trend monitor window or variable monitor window during operation, PID operation is executed by the changed value. At the moment, if PLC is changed to RUN again after being changed to STOP, it loads the parameters in flash memory to K area, so the data changed in K area is lost. Thus, to keep applying the parameters adjusted in K area, it is necessary to write the parameter set in K area to flash memory by using WRT command. (In case of IEC, APM_WRT)

(1) PID Flag Configuration

K area flags for XGB series built-in PID control function are summarized in the below table.

Loop	K area	IEC type	Symbol	Data type	Default	Description
Common	K12000~F	%KX19200~15	_PID_MAN	Bit	Auto	PID output designation(0:auto, 1:manual)
	K12010~F	%KX19216~31	_PID_PAUSE	Bit	RUN	PID pause (0:RUN, 1:pause)
	K12020~F	%KX19232~47	_PID_REV	Bit	Forward	Control direction(0:forward, 1:reverse) operation control
	K12030~F	%KX19248~63	_PID_AW2D	Bit	Disabled	Dual integral accumulation prevention(0:enabled, 1:disabled)
	K12040~F	%KX19264~79	_PID_REM_RUN	Bit	Disabled	PID remote operation(0:disabled, 1:enabled)
	K1205~K1207	%KW1205~%KW1207	Reserved	WORD	-	Reserved area
	K12080~F	%KX19328~43	_PID_PWM_EN	Bit	Disabled	PWM output enable(0:disabled, 1:enabled)
	K12090~F	%KX19344~59	_PID_STD	Bit	-	PID operation indication(0:stop, 1:run)
	K12100~F	%KX19360~75	_PID_ALARM	Bit	-	PID warning(0:normal, 1:warning)
	K12110~F	%KX19376~91	_PID_ERROR	Bit	-	PID error(0:normal, 1:error)
	K1212~K1215	%KW1212~%KW1215	Reserved	WORD	-	Reserved
Loop 0	K1216	%KW1216	_PID00_SV	INT	0	PID SV
	K1217	%KW1217	_PID00_T_s	WORD	100	PID operation cycle[0.1ms]
	K1218	%KD609	_PID00_K_p	REAL	1	PID proportional constant
	K1220	%KD610	_PID00_T_i	REAL	0	PID integral time[sec]
	K1222	%KD611	_PID00_T_d	REAL	0	PID differential time[sec]
	K1224	%KW1224	_PID00_d_PV_max	WORD	0	PID PV change limit
	K1225	%KW1225	_PID00_d_MV_max	WORD	0	PID MV change limit
	K1226	%KW1226	_PID00_MV_max	INT	4000	PID MV max. value limit
	K1227	%KW1227	_PID00_MV_min	INT	0	PID MV min. value limit
	K1228	%KW1228	_PID00_MV_man	INT	0	PID manual output
	K1229	%KW1229	_PID00_PV	INT	-	PID PV

< Table 7.8 K area flags for PID control >

Chapter 7 PID Function (Built-in function)

Loop	K area	IEC type	Symbol	Data type	Default	Description
Loop 0	K1230	%KW1230	_PID00_PV_old	INT	-	PID PV of previous cycle
	K1231	%KW1231	_PID00_MV	INT	0	PID MV
	K1232	%KD616	_PID00_ERR	DINT	-	PID control error
	K1234	%KD617	_PID00_MV_p	REAL	0	PID MV proportional value component
	K1236	%KD618	_PID00_Mv_i	REAL	0	PID MV integral control component
	K1238	%KD619	_PID00_MV_d	REAL	0	PID MV differential control component
	K1240	%KW1240	_PID00_DB_W	WORD	0	PID deadband setting
	K1241	%KW1241	_PID00_Td_lag	WORD	0	PID differential filter coefficient
	K1242	%KW1242	_PID00_PWM	WORD	H'20	PID PWM junction setting
	K1243	%KW1243	_PID00_PWM_Prd	WORD	100	PID PWM output cycle
	K1244	%KW1244	_PID00_SV_RAMP	WORD	0	PID SV Ramp value
	K1245	%KW1245	_PID00_PV_Track	WORD	0	PID PV follow-up setting
	K1246	%KW1246	_PID00_PV_MIN	INT	0	PID PV min. value limit
	K1247	%KW1247	_PID00_PV_MAX	INT	4000	PID PV max. value limit
	K1248	%KW1248	_PID00_ALM_CODE	Word	0	PID warning code
	K1249	%KW1249	_PID00_ERR_CODE	Word	0	PID error code
	K1250	%KW1250	_PID00_CUR_SV	INT	0	PID SV of current cycle
	K1251-1255	%KW1251-1255	Reserved	WORD	-	Reserved area
Loop 1	K1256~K1295 ¹	%KW1256~%KW1295	-	-	-	PID Loop1 control parameter
~						
Loop16	K1816~K1855	%KW1816~%KW1855	-	-	-	PID Loop16 control parameter

< Table 7.8 K area flags for PID control (continued) >

K1200 ~ K1211 areas are the common bit areas of PID loops while each bit represents the status of each PID control loop. Therefore, each 16 bits, the max number of loops of XGB PID control represents loop status and setting respectively. K1216 ~ K1255 areas are K areas for PID control loop 0 and save the loop 0 setting and status. It also contains parameters such as SV, operation cycle, proportional coefficient, integral time and differential time set in the built-in parameter window and the XGB built-in PID function executes PID control by each device value in question. In addition, the output data such as MV calculated and output while PID control is executed is also saved into the K areas. By changing the values in K areas, control setting may be changed any time during PID control.

Remark

By changing value of area, you can change control setting whenever you want during the PID control

1) PID control flag expression : _PID[n]_xxx

→ [n] : loop number

→ xxx : flag function

i.e.) _PID10_K_p : means K_p of loop 10.

¹ Occupies 40 words per loop.

Chapter 7 PID Function (Built-in function)

2) PID flag function

Each function of K area flags for XGB series built-in PID control function is summarized as follows.

(a) Common bit area

The area is a flag collecting operation setting and information consisting of bits to each 16 loop. Each bit of each word device represents the information of each loop. That is, 'n' th bit represents the information about PID loop n.

1) _PID_MAN (PID RUN mode setting)

Flag name	address	IEC type address	Unit	Setting
_PID_MAN (PID RUN mode setting)	K1200n	%KX19200 + n	BIT	Available

It determines whether to operate the PID control of n loop automatically or manually. For more information about RUN mode, refer to 6.2.3 PID control parameter setting. If the bit is off, it operates automatically; if on, it runs manually.

2) _PID_PAUSE (PID Pause setting)

Flag name	Address	IEC type address	Unit	Setting
_PID_PAUSE (PID pause setting)	K1201n	%KX19216 + n	BIT	Available

It changes PID control of n loop to pause status. If PID control is paused, the control MV is fixed as the output at the time of pause. At the moment, PID operation is continued internally with output fixed. If changing pause status to operation status again, it resumes control, so it may take a longer time until the PV is going to SV once system status is largely changed during pause. If the bit is off, it cancels pause; if on, it operates as paused.

3) _PID_REV (PID RUN direction setting)

Flag name	Address	IEC type address	Unit	Setting
_PID_REV (PID RUN direction setting)	K1202n	%KX19232 + n	BIT	Available

It sets the RUN direction of PID control of 'n'th loop. For more information about run direction, refer to 7.2.3 PID control parameter setting. If the bit is off, it operates normally; if on, it operates reversely.

4) _PID_AW2D (Dual Integral accumulation prevention setting)

Flag name	Address	IEC type address	Unit	Setting
_PID_AW2D (dual integral accumulation prevention setting)	K1203n	%KX19248 + n	BIT	Available

It sets enable/disable of dual integral accumulation prevention of 'n'th loop. For more information about dual integral accumulation prevention, refer to 7.2.3 PID control parameter setting. If the bit is off, it is enabled; if on, it is disabled.

Chapter 7 PID Function (Built-in function)

5) _PID_REM_RUN (PID remote operation setting)

Flag name	Address	IEC type address	Unit	Setting
_PID_REM_RUN (PID remote run setting)	K1204n	%KX19264 + n	BIT	Available

X

GB series built-in PID function can be started by both run from command's start junction and remote run bit setting. That is, XGB starts PID control if PIDRUN command's start junction is on or remote run setting bit is on. Namely, if one of them is on, it executed PID control.

6) _PID_PWM_EN (PWM output enable)

Flag name	Address	IEC type address	Unit	Setting
_PID_PWM_EN (PWM output enable)	K1208n	%KX19328 + n	BIT	Available

t determines whether to output the MV of PID control of 'n'th loop as PWM output. For more information about PWM output, refer to 7.2.3 PID control parameter setting. If the bit is off, it is disabled; if on, it is enabled.

7) _PID_STD (PID RUN status indication)

Flag name	Address	IEC type address	Unit	Setting
_PID_STD (PID RUN status indication)	K1209n	%KX19344 + n	BIT	Unavailable

t indicates the PID control RUN status of 'n' th loop. If a loop is running or paused, it is on while if it stops or has an error during RUN, it is off. In the area as monitoring area, it is changed to the current run status by PLC although a user enters any value temporarily.

8) _PID_ALARM (PID Warning occurrence)

Flag name	Address	IEC type address	Unit	Setting
_PID_ALARM (PID Warning occurrence)	K1210n	%KX19360 + n	BIT	Unavailable

t indicates warning if any warning occurs during PID control of 'n'th loop. Once a warning occurs during PID control operation of a loop, it is on while if it is normal, it is off. At the moment, despite of warning, PID control continues without interruption, but it is desirable to check warning information and take a proper measure. Once a warning occurs, the warning code is also indicated in warning code area of a loop. For more information about the types of warning codes and measures, refer to 7.5. In the area as monitoring area, it is changed to the current run status by PLC although a user enters any value temporarily.

9) _PID_ERROR (PID Error occurrence)

Flag name	Address	IEC type address	Unit	Setting
_PID_ERROR (PID error occurrence)	K1211n	%KX19376 + n	BIT	Unavailable

f an error that discontinues running during PID control of 'n' th loop occurs, it indicates the error's occurrence. If an error generates warning, it is on; if normal, it is off. When an error occurs, PID control stops and MV is output as the min. output set in parameter. Also, if an error

Chapter 7 PID Function (Built-in function)

occurs, the error code is indicated in the error code area of a loop. For more information about type of error codes and measures, refer to 7.5. In the area as monitoring area, it is changed to the current run status by PLC although a user enters any value temporarily.

(b) PID Flag area by loops

PID flag areas by loops are allocated between K1216 ~ K1855 and for totally 16 loops, each 40 words is allocated per loop. Therefore, the individual data areas of 'n' th loop are between K (1216+16*n) ~ K (1255+16*n). Every setting of the PID flag areas by loops may be changed during PID control operation. Once the settings are changed, they are applied from the next PID control cycle.

1) _PIDxx_SV (PID xx Loop SV setting)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_SV (PID xx Loop SV setting)	K1216+16*xx	%KW1216+16*xx	INT	-32,768 ~ 32,767

It sets/indicates the SV of PID control of 'xx' th loop. For more information about SV, refer to 7.2.3 PID control parameter setting. The available scope is between -32,768 ~ 32,767.

2) _PIDxx_T_s (PID xx Loop operation cycle)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_T_s (PID xx Loop operation cycle)	K1217+16*xx	%KW1217+16*xx	WORD	100 ~ 65,535

It sets/indicates the operation cycle of PID control of 'xx' th loop. For more information about operation cycle, refer to 7.2.3 PID control parameter setting. The available scope is between 100 ~ 65,535.

3) _PIDxx_K_p (PID xx Loop proportional constant)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_K_p (PID xx Loop proportional constant)	K1218+16*xx	%KD609+20*xx	REAL	Real number

It sets/indicates the proportional constant of PID control of 'xx' th loop. For more information about proportional constant, refer to 7.2.3 PID Control Parameter Setting. The available scope is real number (-3.40282347e+38 ~ -1.17549435e-38, 0, 1.17549435e-38 ~ 3.40282347e+38). If it is, however, set as 0 and lower, the PID control of a loop generates an error and does not work.

4) _PIDxx_T_i (PID xx Loop Integral time)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_T_i (PID xx Loop integral time)	K1220+16*xx	%KD610+ 20*xx	REAL	Real number

It sets/indicates integral time of PID control of 'xx' th loop. The available scope is real number. If it is set as 0 and lower, it does not execute integral control.

Chapter 7 PID Function (Built-in function)

5) _PIDxx_T_d (PID xx Loop differential time)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_T_d (PID xx Loop differential time)	K1222+16*xx	%KD611+20*xx	REAL	Real number

It sets/indicates differential time of PID control of 'xx' th loop. The available scope is real number. If it is set as 0 and lower, it does not execute differential control.

6) _PIDxx_d_PV_max (PV change limit)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_d_PV_max (PV change limit)	K1224+16*xx	%KD612+20*xx	WORD	0 ~ 65,535

It sets the PV change limit of 'xx' th loop.
For more information about PV change limit, refer to 7.2.3 PID control parameter setting. If it is set as 0, the PV change limit function does not work.

7) _PIDxx_d_MV_max (MV change limit)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_d_MV_max (MV change limit)	K1225+16*xx	%KD610+20*xx	WORD	0 ~ 65,535

It sets the MV change limit of 'xx' th loop. For more information about MV change limit, refer to 7.2.3 PID control parameter setting. If it is set as 0, the MV change limit function does not work.

8) _PIDxx_MV_max, _PIDxx_MV_min, _PIDxx_MV_man (max. MV, min. MV, manual MV)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_MV_max (max. MV)	K1226+16*xx	%KW1226+16*xx	INT	-32,768 ~ 32,767
_PIDxx_MV_min (min. MV)	K1227+16*xx	%KW K1227+16*xx		
_PIDxx_MV_man (manual MV)	K1228+16*xx	%KW K1228+16*xx		

It sets the max. MV, min. MV and manual MV of 'xx' th loop. For more information about max. MV, min. MV and manual MV, refer to 7.2.3 PID control parameter setting. If the max. MV is set lower than the min. MV, the PID control loop generates an error and does not work.

9) _PIDxx_PV (prevent value)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_PV (present value)	K1229+16*xx	%KW1229+16*xx	INT	-32,768 ~ 32,767

It is the area that receives the present value of 'xx' th PID control loop. PV is the present status of the system to control and is normally saved into U device via input devices such as A/D input module if it is entered from a sensor. The value is used to execute PID operation by moving to _PIDxx_PV by means of commands like MOV.

10) _PIDxx_PV_OLD (PV of previous control cycle)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_PV_OLD (PV of previous control cycle)	K1230+16*xx	%KW1230+16*xx	INT	Unavailable

The area indicates the PV just before the xx th PID control loop. The flag, as a dedicated monitoring flag, would be updated by PLC although a user directly enters it.

Chapter 7 PID Function (Built-in function)

11) _PIDxx_MV (Control MV)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_MV (control MV)	K1231+16*xx	%KW1231+16*xx	INT	Unavailable

The area shows the MV of 'xx' th PID control loop. As the area in which XGB built-in PID operation result is output every PID control cycle, it delivers the value in the area to U device every scanning by using commands like MOV in the program and outputs to D/A output module, operating a drive.

12) _PID00_ERR (Present error)

Flag name	Address	IEC type address	Unit	Scope
_PID00_ERR (present error)	K1232+16*xx	%KW1232+16*xx	DINT	Unavailable

The areas shows the current error of 'xx' th PID control loop. It is also used as an indicator about how much gap the present status has with a desired status and if an error is 0, it means the control system reaches a desired status exactly. Therefore, if control starts, error is quickly reduced at transient state and it reaches normal state, maintaining remaining drift as 0, it could be an ideal control system. The flag, as a dedicated monitoring, is updated although a user directly enters it.

13) _PIDxx_MV_p, _PIDxx_MV_i, _PIDxx_MV_d (P/I/D control components of MV)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_MV_p (MV proportional control component)	K1234+16*xx	%KD616+20*xx	REAL	Unavailable
_PIDxx_MV_i (MV integral control component)	K1236+16*xx	%KD617+20*xx		
_PIDxx_MV_d (MV differential control component)	K1238+16*xx	%KD618+20*xx		

It indicates 'n' th loop MV by classifying proportional control MV, integral control max. MV and differential control MV. The entire MV consists of the sum of these three components. The flag, as a dedicated monitoring, is updated although a user directly enters it.

14) _PIDxx_DB_W (DeadBand setting)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_DB_W (DeadBand setting)	K1240+16*xx	%KW1232+16*xx	WORD	0 ~ 65,535

It sets the deadband of 'xx' th loop. For more information about Deadband function, refer to 7.2.3 PID control parameter setting. If it is set as 0, the function does not work.

15) _PIDxx_Td_lag (Differential filter coefficient)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_Td_lag (differential filter coefficient)	K1241+16*xx	%KW1241+16*xx	WORD	0 ~ 65,535

It sets the differential filter coefficient of 'xx' th loop. For more information about differential filter coefficient, refer to 7.2.3 PID control parameter setting. If it is set as 0, the function does not work.

Chapter 7 PID Function (Built-in function)

16) _PIDxx_PWM (PWM output junction setting)

Flag name	Address	IEC type address	Unit	Scope
_PID00_PWM (PWM output junction setting)	K1242+16*xx	%KW1242+16*xx	WORD	H'20 ~ H'3F

It sets the junction to which PWM output of 'xx' th loop is output. PWM output junction is valid only between H'20 ~ H'3F. If any other value is entered, PWM output does not work.

17) _PIDxx_PWM_Prd (PWM Output cycle setting)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_PWM_Prd (PWM output cycle setting)	K1243+16*xx	%KW1243+16*xx	WORD	100 ~ 65,535

It sets the PWM output cycle of 'xx' th loop. The available scope is between 100 ~ 65,535 at the unit of 0.1ms.

18) _PIDxx_SV_RAMP (SV ramp setting)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_SV_RAMP (SV ramp setting)	K1244+16*xx	%KW1244+16*xx	WORD	0 ~ 65,535

It sets the SV ramp value of 'xx' th loop. For more information about SV ramp of PV, refer to 7.2.3 PID control parameter setting. If it is set as 0, the function does not work.

19) _PIDxx_PV_Track (PV follow-up setting)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_PV_Track (PV follow-up setting)	K1245+16*xx	%KW1245+16*xx	WORD	0 ~ 65,535

It sets the PV follow-up SV of 'xx' th loop. For more information about PV follow-up, refer to 7.2.3 PID control parameter setting. If it is set as 0, the function does not work.

20) _PIDxx_PV_MIN, _PIDxx_PV_MAX (Min. PV input, Max. PV input)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_MV_p (MV proportional control component)	K1246+16*xx	%KW1246+16*xx	INT	-32,768 ~ 32,767
_PIDxx_MV_i (MV integral control component)	K1247+16*xx	%KW1247+16*xx		

It sets the min./max. PV of 'xx' th loop.

21) _PIDxx_ALM_CODE (Warning code)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_ALM_CODE (Warning code)	K1248+16*xx	%KW1248+16*xx	WORD	Unavailable

It indicates warning code if a warning occurs during 'xx' th loop run. The flag, as a dedicated monitoring, is updated although a user directly enters it. For more information about warning code, refer to 7.5.

Chapter 7 PID Function (Built-in function)

22) _PIDxx_ERR_CODE (Error code)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_ERR_CODE (error code)	K1249+16*xx	%KW1249+16*xx	WORD	Unavailable

It indicates error code if an error occurs during 'xx' th loop run. The flag, as a dedicated monitoring, is updated although a user directly enters it. For more information about warning code, refer to 7.5.

23) _PIDxx_CUR_SV (SV of the present cycle)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_CUR_SV (SV of the present cycle)	K1250+16*xx	%KW1250+16*xx	INT	Unavailable


It indicates SV currently running of 'xx' th loop. If SV is changing due to SV ramp or PV follow-up function, it shows the currently changing PV. The flag, as a dedicated monitoring, is updated although a user directly enters it.

7.3 PID Instructions


It describes PID control commands used in XGB series. The command type of PID control used in XGB series built-in PID control is 4.

(1) PIDRUN

PIDRUN is used to execute PID control by loops.



- Operand S means the loop no. to execute PID control and available only for constant(0~15).
- If start signal is on, the PID control of a loop starts.
- In case of IEC type, PID control is conducted by PIDRUN function block.
- In case of XGB IEC type, inputs '0' at BLOCK



- PID_STAT, only supported on IEC type, indicates status of PID operation. For meaning of indication data, refer to indication contents of PID STATE.

Chapter 7 PID Function (Built-in function)


Indication contents of PID STATE

Item	Indication	Flag name	Contents
ALARM	16#0001	PV_MIN_MAX_ALM	Current value exceeds range of maximum, minimum value
	16#0002	PID_SCANTIME_ALM	Operation cycle is too short.
	16#0003	PID_dPV_WARN	Variation of current value of this PID cycle exceeds the current value variation limit.
	16#0004	PID_dMV_WARN	Variation of manipulated value of this PID cycle exceeds the manipulated value variation limit.
	16#0005	PID_MV_MAX_WARN	Manipulated value of this PID cycle exceeds maximum manipulated value.
	16#0006	PID_MV_MIN_WARN	Manipulated value of this PID cycle is smaller than minimum manipulated value.
ERROR	16#0100	MV_MIN_MAX_ERR	Maximum manipulated value is set to be smaller than minimum manipulated value.
	16#0200	PV_MIN_MAX_ERR	Maximum current value is set to be smaller than current manipulated value.
	16#0300	PWM_PERIOD_ERR	PWM output cycle is set to be smaller than 100(10ms).
	16#0400	SV_RANGE_ERR	In case of forward operation, set value at start of auto-tuning is smaller than current value. In case of reverse operation, set value at start of auto-tuning is larger than current value.
	16#0500	PWM_ADDRESS_ERR	PWM output is set as contact point other than %QX0.0.0~0.0.31.
	16#0600	P_GAIN_SET_ERR	Proportional constant is set to be smaller than 0.
	16#0700	I_TIME_SET_ERR	Integral constant is set to be smaller than 0
	16#0800	D_TIME_SET_ERR	Differential constant is set to be smaller than 0
	16#0900	CONTROL_MODE_ERR	Control mode is other than P, PI, PD and PID.
	16#0B00	PID_PERIOD_ERR;	PIC operation cycle is set to be smaller than 100(10ms)
	16#0C00	HBD_WRONG_DIR	In combined operation, directional parameter of forward operation loop is set as reverse operation or directional parameter of reverse operation loop is set as forward operation
	16#0D00	HBD_SV_NOT_MATCH	In combined operation, set values of two loops are different
	16#0E00	LOOP_EXCEED	PID LOOP number is larger 15


Chapter 7 PID Function (Built-in function)

(2) PIDCAS


PIDCAS is a command to execute CASCADE control.



- Operand M and S mean master loop and slave loop respectively and available only for constant(0~15).
- If start junction is on, cascade control is executed through master loop and slave loop.
- In case of IEC type, PIDCAS function block is used for cascade control.




Cascade control is called a control method which is intended to increase control stability through quick removal of disturbance by connecting two PID control loops in series and is structured as follows.



[Figure 7.13 Comparison of single loop control and cascade control]


Looking at the figure, it is found that cascade control contains slave loop control within external control loop. That is, the control output of external loop PID control is entered as SV of the internal loop control. Therefore, if steam valve suffers from disturbance in the figure, single loop PID control may not be modified until PV, $y(s)$ appears while cascade control is structured to remove any disturbance by the internal PID loop control before any disturbance that occurs in its internal loop affects the PV, $y(s)$, so it can early remove the influence from disturbance. XGB internal PID control connects two PID control loops each other, making cascade control possible. At the moment, MV of external loop is automatically entered as the SV of internal loop, so it is not necessary to enter it through program.

PIDHBD is a command to execute the mixed forward/reverse E control.



If PIDHBC command starts first, it starts reverse run when PV is higher than SV; it starts

The conversion of run direction is executed according to the following principles. In case of




[Figure 7.14 Conversion of RUN direction in the mixed forward/reverse control]

- (c) At the moment, every control parameter uses the parameter of a loop set for forward operation while MV is output to MV output area of a loop of forward operation. Reversely, every control parameter uses the parameter of a loop set for reverse operation during reverse operation run while MV is also output to MV output area of reverse operation loop.

(d) WRT


WRT is a command to save K area flags changed during operation to the internal flash memory of PLC.



- Once start junction is on, it writes K area values to flash memory.
- Each operand description is summarized as follows.

Operand	Item designated	Available device	Remark
OP1	Slot	Constant	Designating basic unit as 0
OP2	N/A	P,M,L,K,D,Z,R, constant	Not used
OP3	Parameter type	P,M,L,K,D,Z,R,constant	0 : positioning X axis
			1 : positioning Y axis
			2 : HS counter
			3 : PID parameter
			4 : PID auto-tuning parameter

- In case of IEC type, APM_WRT function block is used.



7.4 PID Auto-tuning


7.4.1 Basic theory of PID auto-tuning

It describes the function of PID auto-tuning.

The performance of PID controller is very different according to P, I, D coefficient. Generally, It is very difficult and takes long time to predict the system and set P, I, D coefficient because of non-periodical disturbance, interference of other control loop, dynamic characteristic of control system though the engineer is good at handling the PID controller. So auto-tuning that sets the PID coefficient automatically is very useful. Generally, there are many methods in setting the PID coefficient. Here, it will describe Relay Auto-tuning.

(1) PID coefficient setting by Relay auto-tuning

It makes critical oscillation by force and uses the width and period of oscillation to specify the PID coefficient. It applies max. output and min. output to control system for auto-tuning. Then, oscillation with steady period and steady width occurs around the Set value like figure 6.15, and it can calculate the boundary gain by using it like expression (7.3.1).



< Figure 7.15 Relay auto-tuning >

$$K_u = \frac{4 \times (\text{Max.output} - \text{Min.output})}{\pi \times \text{width}} \quad (7.3.1)$$

At this time, oscillation period is called boundary period. If boundary gain and period is specified, use table 7.9, Ziegler & Nichols tuning table to specify the PID coefficient. This Relay tuning is relatively simple to configure and easy to know the boundary gain and period so it is used frequently and XGB built-in PID auto-tuning uses this method.

Controller	Proportional gain (Kp)	Integral time(Ti)	Differential time(Td)
P	$0.5K_u$	-	-
PI	$0.45K_u$	$P_u / 1.2$	-
PID	$0.6K_u$	$P_u / 2$	$P_u / 8$

< Table 7.9 Ziegler & Nichols tuning table >

7.4.2 PID Auto-Tuning function specifications

The specifications of the XGB series built-in PID auto-tuning function are summarized as in Table.

Item		Specifications
Scope of SV		INT (-32,768 ~ 32,767)
Scope of PV		INT (-32,768 ~ 32,767)
Scope of MV		INT (-32,768 ~ 32,767)
	Error indication	Normal: error flag off Error: error flag off, error code occurs
AT direction setting		Forward/reverse
Control cycle		100 ~ 65,536 (0.1msUnit)
Additional function	PWM output	Supportable
	Hysteresis	Supportable

[Table 7.10 Spec. of built-in PID auto-tuning function]


7.4.3 Auto-tuning parameter setting

To use the XGB series auto-tuning function, it is necessary to start it by using a command after setting auto-tuning parameters by loops in the parameter window. It explains the parameters to use auto-tuning function and how to set them.

(1) Auto-tuning parameter setting

To set the parameters of XGB series auto-tuning function, follow the steps.


- (a) If selecting parameter in project window and the built-in parameter, it shows the built-in parameter setting window as seen in below figure.



< Figure 7.16 Built-in parameter setting window >

Chapter 7 PID Function (Built-in function)

(b) If selecting auto-tuning, it shows the parameter setting window as seen in figure 7.17.



<Figure 7.17 Built-in auto-tuning function parameter setting window>

(c) Input items

Table shows the items to set in auto-tuning parameter window and the available scopes.

Items	Description	Scope
RUN direction	Set the run direction of auto-tuning.	Forward/reverse
PWM output enable	Set whether to set PWM output of MV enabled/disabled.	Disable/enable
SV	Set SV.	-32,768 ~ 32,767
Operation time	Set auto-tuning operation time.	100 ~ 65535
Max. MV	Set the max. MV in control.	-32,768 ~ 32,767
Min. mV	Set the min. MV in control.	-32,768 ~ 32,767
PWM junction designation	Designate the junction to which PWM output is output.	P20 ~ P3F
PWM output cycle	Set the output cycle of PWM output.	100 ~ 65,535
Hysteresis setting	Set the hysteresis of auto-tuning MV.	0 ~ 65,535

< Table 7.11 Auto-tuning function parameter setting items>

(2) Description of auto-tuning parameters and how to set them

(a) RUN direction

RUN direction is to set the direction of auto-tuning run of a loop. The available option is forward or reverse. The former (forward) means that PV increase when MV increases while the latter (reverse) means PV decreases when MV increases. For instance, a heater is a kind of forward direction system because PV (temperature) increases when output (heating) increases. A refrigerator is a kind of reverse direction system in which PV (temperature) decreases when output increases.

(b) PWM output enable

PWM output means an output method to turn a junction on – off with a duty proportional to control

Chapter 7 PID Function (Built-in function)

output calculated by a uniform output cycle. If PWM output is enabled, it realizes PWM output in accordance with PWM output cycle set in the parameter of PWM output junction (P20 ~ P3F, in case of IEC type, %QX0.0.0~%QX0.0.15) designated in the parameter. At the moment, the PWM output cycle follows the PWM output cycle separately set in auto-tuning operation cycle.

(c) SV

It sets the auto-tuning SV of a loop in question. Similar to PID control, physical values (temperature, flow rate, pressure and etc) of an object to control is not meaningful and instead, it should use the physical amount of an object to control after converting them into numerals. For instance, in order to control a system using a sensor that the output is 0V when its heating device temperature is 0°C while it is 10V when the temperature is 100°C as much as 50°C, it is necessary to set SV as 2000(as long as it uses AD input module XBE-AD04A).

(d) Operation time


It sets the cycle to execute operation for auto-tuning. The setting cycle is 0.1ms and available between 10ms ~ 6553.5ms (setting value: 100 ~ 65,535) while it is set at a unit of integer per 0.1ms.

(e) Max./min. MV

It sets the max./min. value of output for auto-tuning. The available scope is between -32,768 ~ 32,767. If the max. MV is set lower than min. MV, the auto-tuning function of a loop generates an error and does not work.

(f) Hysterisis setting

Looking at relay tuning in figure 7.15, it shows it outputs the max. MV as auto-tuning starts but it converts to min. output as PV is over SV and then, it converts to the max. output as PV is lower than SV. However, if input PV contains noise components or reply components, auto-tuning ends by a slight vibration of PV around SV, yielding incorrect tuning result. To prevent it, hysteresis may be set. XGB auto-tuning converts output at SV + Hysteresis when PV increases or at SV - Hysteresis when it decreases once hysteresis is set. With it, it may prevent incorrect tuning by a slight vibration around SV.



[Figure 7.16 Example of Hysteresis setting]

7.4.4 Auto-tuning flag

The parameters set in the XGB series auto-tuning function are saved to the flash memory of basic unit. Such parameters are moved to K area for auto-tuning function as soon as PLC enters to RUN mode from STOP. Auto-tuning operation using auto-tuning command is achieved by data in K area. At the moment, if PLC is changed to RUN again after being changed to STOP, it takes the parameters in flash memory to K area, so the data changed in K area is lost. Therefore, to continuously apply the parameters adjusted in K area, it is necessary to write the parameters set in K area into flash memory by using WRT command. (In case of IEC type, APM_WRT function block)

(1) Auto-tuning flag configuration

The K area flags of XGB series auto-tuning function are summarized in Table 7.12.

Loops	K area	IEC type	Symbol	Data type	Default	Description
Common	K18560~F	%KX29696 ~%KX29711	_AT_REV	Bit	Forward	Auto-tuning direction(0:forward, 1:reverse)
	K18570~F	%KX29712 ~%KX29727	_AT_PWM_EN	Bit	Disable	PWM output enable(0:disable, 1:enable)
	K18580~F	%KX29728 ~%KX29743	_AT_ERROR	Bit	-	Auto-tuning error(0:normal, 1:error)
	K1859	%KW1859	Reserved	WORD	-	Reserved area
Loop0	K1860	%KW1860	_AT00_SV	INT	0	AT SV – loop 00
	K1861	%KW1861	_AT00_T_s	WORD	100	AT operation cycle (T_s)[0.1msec]
	K1862	%KW1862	_AT00_MV_max	INT	4000	AT MV max. value limit
	K1863	%KW1863	_AT00_MV_min	INT	0	AT MV min. value limit
	K1864	%KW1864	_AT00_PWM	WORD	0	AT PWM junction setting
	K1865	%KW1865	_AT00_PWM_Prd	WORD	0	AT PWM output cycle
	K1866	%KW1866	_AT00_HYS_val	WORD	0	AT hysteresis setting
	K1867	%KW1867	_AT00_STATUS	WORD	0	AT auto-tuning status indication
	K1868	%KW1868	_AT00_ERR_CODE	WORD	0	AT error code
	K1869	%KD	_AT00_K_p	REAL	0	AT result proportional coefficient
	K1871		_AT00_T_i	REAL	0	AT result integral time
	K1873		_AT00_T_d	REAL	0	AT result differential time
	K1875		_AT00_PV	INT	0	AT PV
	K1876		_AT00_MV	INT	0	AT MV
	K1877~1879	%KW1877 ~%KW1879	Reserved	Word	0	Reserved area

[Table 7.12 K area flags for auto-tuning]

K1856 ~ K1859 areas (In case of IEC type, %KW1856~%KW1859) are the common bit areas for auto-tuning and each bit represents auto-tuning loop status respectively. K1860~K1879 areas save the setting and status of loop 0 as the K area for auto-tuning loop 0. In the area, the parameters such as PV, operation cycle and etc set in the built-in parameter window are saved and the XGB built-in auto-tuning function executes auto-tuning by the device values and saves the results into the K areas.

Chapter 7 PID Function (Built-in function)

(2) Auto-tuning flag function

Each function of K area flags for XGB series auto-tuning is summarized as follows.

A) Common bit area

The area is a flag collecting operation setting and information consisting of bits to each 16 loop. Each bit of each word device represents the information of each loop.

1) _AT_REV (auto-tuning run direction setting)

Flag name	Address	IEC type address	Unit	Setting
_AT_REV (PID RUN direction setting)	K1856n	%KX29696 + n	BIT	Available

It determines the run direction of auto-tuning of 'n' th loop. If the bit is off, it is forward operation; if on, it is reverse operation.

2) _AT_PWM_EN (PWM output enable)

Flag name	Address	IEC type address	Unit	Setting
_AT_PWM_EN (PWM output enable)	K857n	%KX29713 + n	BIT	Available

It sets whether to output the auto-tuning MV of 'n' th loop as PWM output. If the bit is off, it is disabled; if on, it is enabled.

3) _AT_ERROR (Auto-tuning error occurrence)

Flag name	Address	IEC type address	Unit	Setting
_PID_ERROR (PID error occurrence)	K1858n	%KX29728 + n	BIT	Unavailable

It indicates the error in case an error that discontinues operation during auto-tuning of 'n' th loop occurs. If an error occurs, it is on; if normal, it is off. Once an error occurs, auto-tuning stops and the MV is output as the min. output set in the parameter. Also, if an error occurs, it indicates the error code in the error code area of a loop. For more information about error code types and measures, refer to 7.5. The area, as a dedicated monitor area, is updated although a user directly enters it.

B) Auto-tuning flag area by loops

The auto-tuning flag areas by loops are K1860 ~ K2179 and each 20 words per loop are allocated to totally 16 loops. Therefore, individual data area of 'n' th loop is between K (1860+16*n) ~ K (1879+16*n).

1) _ATxx_SV (auto-tuning xx Loop SV setting)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_SV (AT xx Loop SV setting)	K1860+16*xx	%KW1860+16*xx	INT	-32,768 ~ 32,767

It sets/indicates the auto-tuning SV of 'xx' th loop.
The available scope is between -32,768 ~ 32,767.

Chapter 7 PID Function (Built-in function)

2) _ATxx_T_s (Auto-tuning xx Loop operation cycle)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_T_s (Auto-tuning xx Loop operation cycle)	K1861+16*xx	%KW1861+16*xx	WORD	100 ~ 65,535

It sets/indicates the operation cycle of 'xx' th loop auto-tuning. The available scope is 100 ~ 65,535.

3) _ATxx_MV_max, _ATxx_MV_min(max. MV, min. MV)

Flag name	Address	IEC type address	Unit	Scope
_PIDxx_MV_max (Max. MV)	K1862+16*xx	%KW1862+16*xx	INT	-32,768 ~ 32,767
_PIDxx_MV_min (Min. MV)	K1863+16*xx	%KW1863+16*xx		

It sets max. MV and min. MV of 'xx' th loop respectively. If the max. MV is set lower than min. MV, the auto-tuning loop generates an error and does not work.

4) _ATxx_PWM (AT output junction setting)

Flag name	Address	IEC type address	Unit	Scope
_AT00_PWM (AT output junction setting)	K1864+16*xx	%KW1864+16*xx	WORD	H'20 ~ H'3F

It sets the junction that PWM output of 'xx' th loop is output. The PWM output junction is valid only between H'20 ~ H'3F (hex). If any other value is entered, PWM output does not work.

5) _ATxx_PWM_Prd (PWM output cycle setting)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_PWM_Prd (PWM output cycle setting)	K1865+16*xx	%KW1865+16*xx	WORD	100 ~ 65,535

It sets the PWM output cycle of 'xx' th loop. The available scope is between 100 ~ 65,535 at the unit of 0.1ms.

6) _ATxx_HYS_val (Hysterisis setting)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_HYS_val (Hysterisis setting)	K1866+16*xx	%KW1866+16*xx	WORD	0 ~ 65,535

It sets the hysteresis of 'xx' th loop. For more information about hysteresis function, refer to 6.3.3 Auto-Tuning Parameter Setting. If it is set as 0, it does not work.

7) _ATxx_STATUS (Auto-tuning status)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_STATUS (Auto-tuning status)	K1867+16*xx	%KW1867+16*xx	WORD	Unavailable

It indicates the auto-tuning status of 'xx' th loop. If auto-tuning is in operation, it is 1; if completed, it is 128. In any other cases, it shows 0.

Chapter 7 PID Function (Built-in function)

8) _ATxx_ERR_CODE (Error code)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_ERR_CODE (Error code)	K1868+16*xx	%KW1868+16*xx	WORD	Unavailable

It indicates error code in case an error occurs during the auto-tuning of 'xx'th loop. The flag, as a dedicated monitor, is updated although a user directly enters it. For more information about error code, refer to 7.5.

9) _ATxx_K_p, _ATxx_T_i, _ATxx_T_d (AT result proportional coefficient, integral time, differential time)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_K_p (proportional coefficient)	K1869+16*xx	%KD934+20*xx	Real	Unavailable
_ATxx_T_i (integral time)	K1871+16*xx	%KD1004+20*xx		
_ATxx_T_d (differential time)	K1873+16*xx	%K1005+20*xx		

The area indicates proportional coefficient, integral time and differential time calculated after the auto-tuning of 'xx' th loop is normally completed. The flag, as a dedicated monitoring, updated although a user directly enters it.

10) _ATxx_PV (PV)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_PV (PV)	K1875+16*xx	%KW1875+16*xx	INT	-32,768 ~ 32,767

It is the area to receive PV of 'xx' th auto-tuning loop. PV is the present status of a system to control and in case of PID control, the entry from a sensor is saved into U device through input devices such as A/D input module and it moves the value to _ATxx_PV by using commands such as MOV every scanning, executing auto-tuning.

11) _ATxx_MV (Auto-tuning MV)

Flag name	Address	IEC type address	Unit	Scope
_ATxx_MV (auto-tuning MV)	K1876+16*xx	%KW1876+16*xx	INT	Unavailable


It is the area to output MV of 'xx' th auto-tuning loop. Every auto-tuning cycle, it saves XGB auto-tuning and it delivers the value in the area by using commands like MOV in a program and operates a drive every scanning.

7.4.5 Auto-tuning instructions


The commands used in XGB series auto-tuning are as follows.

1) PIDAT

PIDAT is a command to execute auto-tuning by loops.




- Operand S means the loop no. to execute auto-tuning and available only for constant(0~15).
- If start junction is on, the PID control of a loop starts.
- In case of IEC type, the following PIDAT function block is used for start of auto-tuning



7.5 Example Programs

The paragraph explains example programs regarding the directions of XGB built-in PID function. The example programs are explained with water level system as illustrated in 7.17.



[Figure 7.17 Example of water level control system]

7.5.1 System structure

The example system in figure is an example of a system to control a pail's water level to a desired level. The pail's water level is sensed by a water level sensor and entered to A/D input module while PID control operation result, MV is output to a pump through D/A output module, controlling a pump's rotation velocity, regulating the water amount flowing into a pail and regulating the water level as desired. Each mechanism is explained as follows.

(1) XGB basic unit

The XGB basic unit operates by PID control operating PID control operation. It receives PV from A/D input module (XBF-AD04A), executes the built-in PID control operation, output the MV to D/A (XBF-DV04A) and executes PID control.

(2) A/D input module (XBF-AD04A)

It functions as receiving PV of an object to control from a water level sensor and delivering it to basic unit. XBF-AD04A is a 4CH analog input module and settings of analog input types and scopes can be changed in the I/O parameter setting window appeared when selecting I/O parameter in the parameter item of project window. For more information, refer to Analog I/O Module.

(3) D/A output module (XBF-DV04A)

It functions as delivering control MV from basic unit to a drive (pump). XBF-DV04A is a 4CH analog voltage output module and ranges 0 ~ 10V. For detail setting, refer to Analog I/O Module.

Chapter 7 PID Function (Built-in function)

(4) Water Level Sensor

A water level sensor plays a role to deliver the PV of an object to control to XGB by measuring the water level of a pail and outputting it within 0 ~ 10V. Since the types and output scope of water level sensors varies, the output scope of a sensor should be identical with that of A/D input module's input scope. The example uses a water level sensor outputting between 0 ~ 10V.

(5) Drive (pump)

A drive uses a pump that receives control output of XGF-DV04A and of which rotation velocity is variable. For accurate PID control, the output scope of XBF-DV04A (0~10V) should be same with that of a pump's control input. The example uses a pump that receives its control input between 0 ~ 10V.

7.5.2. Example of PID Auto-tuning

Here, with examples, it explains how to calculate proportional constant, integral time and differential time by using PID auto-tuning function

(1) PID auto-tuning parameter setting

- (a) If double-clicking Parameter – Built-in Parameter – PID – Auto-tuning parameter in the project window, it opens up the auto-tuning parameter setting window as illustrated in figure 6.18.

Parameter	LOOP 0	LOOP 1	LOOP 2	LOOP 3
Operational Direction	Forward	Forward	Forward	Forward
Enable PWM Output	Disable	Disable	Disable	Disable
Set Value	0	0	0	0
Scan Period	100	100	100	100
Max. MV	4000	4000	4000	4000
Min. MV	0	0	0	0
PWM Contact	P20	P20	P20	P20
PWM Output Period	100	100	100	100
Hysteresis Band	10	10	10	10

[Figure 7.18 Auto-tuning parameter setting window]

- (b) Set each parameter and click OK.

In the example, Loop 0 is set as follows.


- RUN direction: forward
 - Since in the system, water level is going up as MV increases and pump's rotation velocity increases, it should be set as forward operation.
- PWM output: disabled
 - In the example, auto-tuning using PWM is not executed. Therefore, PWM output is set as disabled.
- SV: 1000(2.5V)
 - It shows an example in which XBF-AD04A is set as the voltage input of 0~10V.

Chapter 7 PID Function (Built-in function)

- Max. MV: 4000
 - Max. MV is set as 4000. If MV is 4000, XBF-DV04A outputs 10V.
- Min. MV: 0
 - Min. MV is set as 0. If MV is 0, XBF-DV04A outputs 0V.
- PWM junction, PWM output cycle
 - It is not necessary to set it because the example does not use PWM output.
- Hysterisis setting: 10


(2) A/D input module parameter setting

- (a) If double-clicking Parameter – I/O parameter, it opens up the setting window as illustrated in figure 7.19.



[Figure 7.19 I/O parameter setting window]

- (b) If selecting A/D module for a slot in A/D input module, it opens up the setting window as illustrated in figure 7.20.



[Figure 7.20 A/D input mode setting window]

- (c) Check A/D Module operation parameter and click OK. The example is set as follows.

- RUN CH: CH0 RUN
 - The example receives the water level sensor input as CH0.

Chapter 7 PID Function (Built-in function)

- Input scope: 0 ~ 10V
 - Set XBF-AD04A input scope as 0 ~ 10V so that it should be identical with the output scope of water level sensor.
- Output data type: 0 ~ 4000
 - It converts the input 0 ~ 10V to digital value from 0 ~ 4000 and delivers it to basic unit.
 - In the case, the resolving power of digital value 1 is $10/4000 = 2.5\text{mV}$
- Filter process, averaging: disabled
 - The example sets the input values in order that filter process and averaging are not available.
 - For more information about each function, refer to 12 Analog I/O Module.

(3) D/A Output Module Parameter setting

- (a) Set the parameter of D/A output module(XBF-DV04A) that output MV to a drive.
How to set them is as same as A/D input module. In the example, it is set as follows.

Parameter	CH 0	CH 1	CH 2	CH 3
<input type="checkbox"/> Channel status	Disable	Disable	Disable	Disable
<input type="checkbox"/> Output range	0~10V	0~10V	0~10V	0~10V
Input type	0~4000	0~4000	0~4000	0~4000
<input type="checkbox"/> CH. Output type	Former value	Former value	Former value	Former value


OK Cancel

- RUN CH: CH0 RUN
 - In the example, MV is output as CH0 of D/A output module.
- Output scope : 0 ~ 10V
- Input data type: 0 ~ 4000

Chapter 7 PID Function (Built-in function)

4) Example of PID Auto-tuning program

The example of PID auto-tuning program is illustrated as figure 7.21.



< Figure 7.21 Auto-tuning example program >

(a) Devices used

Device	Data type	Application
F0099	BIT	It is always on, so it readily operates once PLC is RUN.
U01.01.0	BIT	It starts operation of CH0 of Slot 1 A/D input module.
U02.02.0	BIT	It starts operation of CH0 of Slot 2 D/A output module.
U01.02	INT	PV entered to A/D input module.
U02.03	INT	MV entered to D/A output module.
K1875	INT	Device to which PV is entered for LOOP 0 auto-tuning
K1876	INT	Device to which auto-tuning MV of LOOP 0 is output.
K1867	BIT	Junction that is on once auto-tuning is complete.
K18580	BIT	Junction that is on once auto-tuning has an error.
K1863	INT	Min. MV of auto-tuning designated in parameter.

(b) Program explanation


- 1) Since F0099(always on) is ON if PLC is converted from STOP to RUN, CH0 of A/D and D/A starts operating.
- 2) At the moment, PV entered to CH0 is moved to K1875, the input device of PV and saved accordingly.
- 3) Once M0000 junction is on, the auto-tuning of loop 0 starts.

Chapter 7 PID Function (Built-in function)

- 4) The auto-tuning MV of loop 0 that is output by PIDAT command is output to D/A output module by line 14 MOV command.
 - 5) If auto-tuning is complete or there is any error during auto-tuning, M0001 junction is set, blocking operation of PIDAT command and it outputs min. MV set in parameter to D/A output module.
- (c) Monitoring and changing PID control variables using K area
- In XGB series built-in auto-tuning, it can monitor and change RUN status of auto-tuning by using K area allocated as fixed area by loops.

1) Variable registration

If selecting "Register in Variable/Description" by right clicking in the variable monitor window, "Variable/Device Selection" window appears. Select "Item" as PID, deselect "View All" and enter 0(means loop number) in "Parameter No", K area device list to save every setting and status of loop 0 appears as shown figure 7.22. Then, if selecting a variable to monitor and clicking "OK", a selected device is registered to variable monitor window as illustrated in figure 7.23. Through the monitor window, a user can monitor auto-tuning run status or change the settings.



[Figure 7.22 Variable registration window]

	PLC	Type	Device	Value	Variable	Comment
1	NewPLC	BIT	K12000	10	_PID00_MAN	PID Output Se (0:Auto, 1:Man - Loop00
2	NewPLC	BIT	K12010	10	_PID00_PAUSE	PID PAUSE (0:STOP or RL 1:Pause) - Loo
3	NewPLC	BIT	K12020	10	_PID00_REV	PID Operate Direction (0:Forward, 1:Reverse) - Loop00
4	NewPLC	BIT	K12030	10	_PID00_AW2D	PID Anti Wind-up2 (0:Enable, 1:Disable) -


Variable Monitoring Window

Monitor 1 | Monitor 2 | Monitor 3 | Monitor 4

[Figure 7.23 Auto-tuning variables registered]

Chapter 7 PID Function (Built-in function)

(d) In case of IEC type, example program
In case of IEC type, the following program is used.




Chapter 7 PID Function (Built-in function)

(5) Observing RUN status by using trend monitor function

Since it is possible to monitor the operation status of XGB series built-in auto-tuning graphically, it is useful to monitor the operation status of auto-tuning clearly.

- (a) If selecting Monitor – Trend monitor menu, it shows the trend monitor window as illustrated in figure 7.24.



[Figure 7.24 Trend Monitor window]

- (b) If right-clicking trend setting, a user can select a variable to monitor as illustrated in figure 7.25.

ID	Device	Variable Name	Type
1			

[Figure 7.25 window to register trend monitor variable]

- (c) For more information about trend monitor, refer to “XG5000 Use’s Manual.”

7.5.3. Stand-alone operation after PID Auto-Tuning

Here, with example, it explains how to execute PID control followed by PID auto-tuning.

(1) PID auto-tuning parameter setting

- PID auto-tuning parameters are set as same as examples of 7.4.2 Example of PID Auto-tuning.

(2) Setting parameters of A/D input module and D/A output module

- Set the parameters of A/D input module and D/A output module as same as the example in 7.4.2 Example of PID Auto-tuning.

(3) PID parameter setting

- (a) If double-clicking Parameter – Built-in Parameter – PID – PID Parameter, it shows the built-in PID parameter setting window as seen in figure 7.26.

Parameter	LOOP 0	LOOP 1	LOOP 2	LOOP 3
Operational Mode	Auto Opr	Auto Opr	Auto Opr	Auto Opr
Operational Direction	Forward	Forward	Forward	Forward
Secondary Anti windup	Disable	Disable	Disable	Disable
Derivative term Cal. Method	By Error	By Error	By Error	By Error
Enable PwM Output	Disable	Disable	Disable	Disable
Set Value	0	0	0	0
Scan Period	100	100	100	100
Proportional Gain	1	1	1	1
Integral Time	0	0	0	0
Derivative Time	0	0	0	0
Delta PV Limit	0	0	0	0
Delta MV Limit	0	0	0	0
Max. MV	4000	4000	4000	4000
Min. MV	0	0	0	0
Manual MV	0	0	0	0
DeadBand Setting Value	0	0	0	0
Set filtering coefficient	0	0	0	0
PwM Contact	P20	P20	P20	P20
PwM Output Period	100	100	100	100
Set SV Ramp	0	0	0	0
Set PV Tracking	0	0	0	0
Min PV	0	0	0	0
Max PV	4000	4000	4000	4000

[Figure 7.26 Auto-tuning parameter setting window]

- (b) Set each parameter and click OK.

In the example, Loop 0 is set as follows.

- RUN mode: automatic
 - Set as automatic in order that PID control is executed as the built-in PID operation outputs MV.
- RUN direction: forward
 - Since in the system, water level is going up as MV increases and pump's rotation velocity increases, it should be set as forward operation.


Chapter 7 PID Function (Built-in function)

- PWM Output: disabled
 - In the example, auto-tuning using PWM is not executed. Therefore, PWM output is set as disabled.
- SV: 1000(2.5V)
 - It shows an example in which XBF-AD04A is set as the voltage input of 0~10V
- Operation cycle: 1000
 - In the example, it is set that PID control is executed every 100ms.
- Proportional gain, integral time and differential time
 - It should be initially set as 1,0,0 because PID auto-tuning results is used with PID constant.
- Max. MV: 4000
 - Max. MV is set as 4000. If MV is 4000, XBF-DV04A outputs 10V.
- DeadBand: 0
 - It is set as 0 because the example does not use DeadBand function.
- Differential filter setting: 0
 - it is also set as 0 because the example does not use differential filter.
- Min. MV: 0
 - Min. MV is set as 0. If MV is 0, XBF-DV04A outputs 0V.
- PWM junction, PWM output cycle
 - It is not necessary to set them because the example does not use PWM output.
- SV ramp, PV follow-up: 0
 - It is not necessary to set SV ramp and PV follow-up because the example does not use them.
- Min. PV, Max. PV: 0
 - Set them as 0 and 4000 respectively so that it could be identical with A/D input module's input scope.

Chapter 7 PID Function (Built-in function)

(c) Example of PID control program after PID auto-tuning

The program example for PID auto-tuning is illustrated as figure 7.27.



[Figure 7.27 Example program of PID control after auto-tuning]

1) Devices used


Device	Data type	Application
F0099	BIT	It is always on, so it readily operates once PLC is RUN.
U01.01.0	BIT	It starts operation of CH0 of Slot 1 A/D input module.
U02.02.0	BIT	It starts operation of CH0 of Slot 2 D/A output module.
U01.02	INT	PV entered to A/D input module.
U02.03	INT	MV entered to D/A output module.
K1875	INT	Device to which PV is entered for LOOP 0 auto-tuning
K1876	INT	Device to which auto-tuning MV of LOOP 0 is output.
K18677	BIT	Junction that is on once auto-tuning is complete.
K18580	BIT	Junction that is on once auto-tuning has an error.
K1863	INT	Min. MV of auto-tuning designated in parameter.
K1229	INT	Device to which PV is entered for Loop 0 PID control
K1876	INT	Device to which MV of loop 0 PID control is output.

Chapter 7 PID Function (Built-in function)

2) Program explanation

- Since F0099 (always on) is ON if PLC is converted from STOP to RUN, CH0 of A/D and D/A starts operating.
- Once M0000 junction is on, the auto-tuning of loop 0 starts. At the moment, PV entered to CH0 is moved to K1875, the PV input device of loop 0 and saved accordingly.
- The auto-tuning MV of Loop 0 output by PIDAT command is output to D/A output module by line 11, MOV command.
- Once auto-tuning is complete, it moves P, I, D coefficients generated from auto-tuning to the input devices of P, I and D, K1218, K1220 and K1222, sets M001 and starts the operation of PID loop 0.

3) In case of IEC type, program example is as shown below.



7.6 Error/Warning Codes

It describes error codes and warning codes of the XGB built-in PID function. The error codes and warning codes that may occur during use of the XGB built-in PID function are summarized as table. If any error or warning occurs, remove potential causes of the error by referring to the tables.

7.6.1. Error codes

Error codes	Indications	Measures
H'0001	MV_MIN_MAX_ERR	It occurs when max. MV is set lower than min. MV. Make sure to set max. MV larger than min. MV.
H'0002	PV_MIN_MAX_ERR	It occurs when max. PV is set lower min. Pv. Make sure to set max. PV larger than min. PV.
H'0003	PWM_PERIOD_ERR	It occurs when the period of auto tuning or PID operation loop is set under 100(10ms). Make sure to set output period more than 100.
H'0004	SV_RANGE_ERR	It occurs when SV is larger than PV at the start time of auto-tuning if auto-tuning is forward or when SV is larger than PV at the start time of auto-tuning if auto-tuning is reverse.
H'0005	PWM_ADDRESS_ERR	It occurs when the junction designated as PWM output junction is beyond between P20 ~ P3F.
H'0006	P_GAIN_SET_ERR	It occurs when proportional constant is set lower than 0.
H'0007	I_TIME_SET_ERR	It occurs when integral time is set lower than 0.
H'0008	D_TIME_SET_ERR	It occurs when differential time is set lower than 0.
H'0009	CONTROL_MODE_ERR	It occurs when control mode is not P, PI, PD or PID.
H'000A	TUNE_DIR_CHG_ERR	It occurs when operation direction is changed during auto-tuning. Never attempt to change operation direction during auto-tuning.
H000B	PID_PERIOD_ERR	It occurs when period of operation is smaller than 100 (10ms) at Auto-tuning or PID operation. Make sure to set period of operation larger than 100.
H000C	HBD_WRONG_DIR	In mixed operation, It occurs when the direction parameter of forward operation set to reverse operation or the direction parameter of reverse operation set to forward operation. Make sure set to appropriate direction each loop.
H000D	HBD_SV_NOT_MATCH	In mixed operation, it occurs when the Set value of each loop is not concurrent. Make sure set to Set value concurrently.

[Table 7.13 : PID error codes]

7.6.2. Warning codes

Error codes	Indications	Measures
H'0001	PV_MIN_MAX_ALM	It occurs when the set PV is beyond the min./max. PV.
H'0002	PID_SCANTIME_ALM	It occurs when PID operation cycle is too short. It is desirable to set PID operation cycle longer than PLC scan time.
H'0003	PID_dPV_WARN	It occurs when the PV change of PID cycle exceeds PV change limit.
H'0004	PID_dMV_WARN	It occurs when the PV cycle MV change exceeds MV change limit.
H'0005	PID_MV_MAX_WARN	It occurs when the calculated MV of PID cycle exceeds the max. MV.
H'0006	PID_MV_MIN_WARN	It occurs when the calculated MV of PID cycle is smaller than the min. MV

[Table 7.14 : PID error codes]

Appendix 1

Appendix 1 Standard Resistor of Pt RTD

Pt100Ω										
-200	18.52									
-100	60.26	56.19	52.11	48.00	43.88	39.72	35.54	31.34	27.10	22.83
0	100.00	96.09	92.55	88.22	84.27	80.31	76.33	72.33	68.33	64.30
Temp.(℃)	0	10	20	30	40	50	60	70	80	90
0	100.00	103.90	107.79	111.67	115.54	119.40	123.24	127.08	130.90	134.71
100	138.51	142.29	146.07	149.83	153.58	157.33	161.05	164.77	168.48	172.17
200	175.86	179.53	183.19	186.84	190.47	194.10	197.71	201.31	204.90	208.48
300	212.05	215.61	219.86	222.68	226.21	229.72	233.21	236.70	240.18	243.64
400	247.09	250.53	253.96	257.38	260.78	264.18	267.56	270.93	274.29	277.64
500	280.98	284.30	287.62	290.92	294.21	297.49	300.75	304.01	307.25	310.49
600	313.71									
JPt100Ω										
-200	17.14									
-100	59.57	55.44	51.29	47.11	42.91	38.68	34.42	30.12	25.80	21.46
0	100.00	96.02	92.02	88.01	83.99	79.96	75.91	71.85	67.77	63.68
Temp.(℃)	0	10	20	30	40	50	60	70	80	90
0	100.00	103.97	107.93	111.88	115.81	119.73	123.64	127.54	131.42	135.3
100	139.16	143.01	146.85	150.67	154.49	158.29	162.08	165.86	169.63	173.38
200	177.13	180.86	184.58	188.29	191.99	195.67	199.35	203.01	206.66	210.3
300	213.93	217.51	221.15	224.74	228.32	231.89	235.45	238.99	242.53	246.05
400	249.56	253.06	256.55	260.02	263.49	266.94	270.38	273.8	277.22	280.63
500	284.02	287.4	290.77	294.12	297.47	300.8	304.12	307.43	310.72	314.01
600	317.28									

Appendix 2 Thermo Electromotive Force and Compensating Cable

2.1 Table of Thermo Electromotive Force

► Type K

unit: μ v

-200	-100	-0	Temp. (°C)	Temp. (°C)	0	100	200	300	400	500	600	700	800	900	1000	1100	1200
-5891	-3553	-0	-0	0	0	4095	8137	12207	16395	20640	24902	29128	33277	37325	41269	45108	48828
	-3852	-392	-10	10	397	4508	8537	12623	16818	21066	25327	29547	33686	37724	41657	45486	
	-4138	-777	-20	20	798	4919	8938	13039	17241	21493	25751	29965	34095	38122	42045	45863	
	-4410	-1156	-30	30	1203	5327	9341	13456	17664	21919	26176	30383	34502	38519	42432	46238	
	-4669	-1527	-40	40	1611	5733	9745	13874	18088	22346	26599	30799	34909	38915	42817	46612	
	-4912	-1889	-50	50	2022	6137	10151	14292	18513	22772	27022	31214	35314	39310	43202	46985	
	-5141	-2243	-60	60	2436	6539	10560	14712	18938	23198	27445	31629	35718	39703	43585	47356	
	-5354	-2586	-70	70	2850	6939	10969	15132	19363	23624	27867	32042	36121	40096	43968	47726	
	-5550	-2920	-80	80	3266	7338	11381	15552	19788	24050	28288	32455	36524	40488	44349	48095	
	-5730	-3242	-90	90	3681	7737	11793	15974	20214	24476	28709	32866	36925	40879	44729	48462	

► Type J

unit: μ v

-200	-100	-0	Temp. (°C)	Temp. (°C)	0	100	200	300	400	500	600	700	800
-7890	-4632	0	-0	0	0	5268	10777	16325	21846	27388	33096	39130	45498
	-5036	-501	-10	10	507	5812	11332	16879	22397	27949	33683	39754	
	-5426	-995	-20	20	1019	6359	11887	17432	22949	28511	34273	40382	
	-5801	-1481	-30	30	1536	6907	12442	17984	23501	29075	34867	41013	
	-6159	-1960	-40	40	2058	7457	12998	18537	24054	29642	35464	41647	
	-6499	-2431	-50	50	2585	8008	13553	19089	24607	30210	36066	42283	
	-6821	-2892	-60	60	3115	8560	14108	19640	25161	30782	36671	42922	
	-7122	-3344	-70	70	3649	9113	14663	20192	25716	31356	37280	43563	
	-7402	-3785	-80	80	4186	9667	15217	20743	26272	31933	37893	44207	
	-7659	-4215	-90	90	4725	10222	15771	21295	26829	32513	38510	44852	

Appendix 2 Thermo electromotive force and compensating force

► Type T

unit: μV

-200	-100	-0	($^{\circ}\text{C}$)	($^{\circ}\text{C}$)	0	100	200	300	400
-5603	-3378	0	-0	0	0	4277	9286	14860	20869
	-3656	-383	-10	10	391	4749	9820	15443	
	-3923	-757	-20	20	789	5227	10360	16030	
	-4177	-1121	-30	30	1196	5712	10905	16621	
	-4419	-1475	-40	40	1611	6204	11456	17217	
	-4648	-1819	-50	50	2035	6702	12011	17816	
	-4865	-2152	-60	60	2467	7207	12572	18420	
	-5069	-2475	-70	70	2908	7718	13137	19027	
	-5261	-2788	-80	80	3357	8235	13707	19638	
	-5439	-3089	-90	90	3813	8757	14281	20252	

► Type R

unit : μV

($^{\circ}\text{C}$)	0	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700
0	0	647	1468	2400	3407	4471	5582	6741	7949	9203	10503	11846	13224	14624	16035	17445	18842	20215
10	54	723	1557	2498	3511	4580	5696	6860	8072	9331	10636	11983	13363	14765	16176	17585	18981	20350
20	111	800	1647	2596	3616	4689	5810	6979	8196	9460	10768	12119	13502	14906	16317	17726	19119	20483
30	171	879	1738	2695	3721	4799	5925	7098	8320	9589	10902	12257	13642	15047	16458	17866	19257	20616
40	232	959	1830	2795	3826	4910	6040	7218	8445	9718	11035	12394	13782	15188	16599	18006	19395	20748
50	296	1041	1923	2896	3933	5021	6155	7339	8570	9848	11170	12532	13922	15329	16741	18146	19533	20878
60	363	1124	2017	2997	4039	5132	6272	7460	8696	9978	11304	12669	14062	15470	16882	18286	19670	21006
70	431	1208	2111	3099	4146	5244	6388	7582	8822	10109	11439	12808	14202	15611	17022	18425	19807	
80	501	1294	2207	3201	4254	5356	6505	7704	8949	10240	11574	12946	14343	15752	17163	18564	19944	
90	573	1380	2303	3304	4362	5469	6623	7826	9076	10371	11710	13085	14483	15893	17304	18703	20080	

2.2 Thermocouple

2.2.1 Common limit and overheat limit

Symbol of materials	Former symbols (cf)	Nominal diameter (mm)	Common limit (1) °C	Overheat limit (2) °C
K	CA	0.65	650	850
		1.00	750	950
		1.60	850	1050
		2.30	900	1100
		3.20	1000	1200
J	IC	0.65	400	500
		1.00	450	550
		1.60	500	650
		2.30	550	750
		3.20	600	750
T	CC	0.32	200	250
		0.65	200	250
		1.00	250	300
		1.60	300	300
R	-	0.50	1400	1600

Remarks

- (1): common limit refers to the temperature limit that continuously use in the air.
 (2): overheat limit refers to the temperature limit that may inevitably use for a short time.

2.2.2 Allowance by temperature

Symbol of materials	Former symbols (cf)	Temperature	Grade	Allowance
K	CA	0 °C ~ lower than 1000°C	0.4	±1.5°C or ±0.4% of temperature measured
		0°C ~ lower than 1200°C	0.75	±2.5°C or ±0.75% of temperature measured
		-200°C~ lower than 0°C	1.5	±2.5°C or ±1.5% of temperature measured
J	IC	0°C~ lower than 750°C	0.4	±1.5 °C or ±0.4% of temperature measured
		0°C~ lower than 750°C	0.75	±2.5°C or ±0.75% of temperature measured
T	CC	0°C~ lower than 350°C	0.4	±0.5°C or ±0.4% of temperature measured
		0°C~ lower than 350°C	0.75	±1°C or ±0.75% of temperature measured
		-200°C~ lower than 0°C	1.5	±1°C or ± 1.5% of temperature measured
R	-	0 °C ~ lower than 1600°C	0.25	±1.5 °C or ±0.25% of temperature measured

Remark

Allowance refers to the allowable max. limit subtracting the actual temperature of junction from the converted temperature, based on thermo electromotive force table. In addition, the allowance will be bigger one of °C or %.

2.3 Compensating Cable

2.3.1 Type and specifications of compensating cable

Type of compound thermocouple		Type of compensating type		Sectional ratio by application and allowance	Materials		Operating temp. range (°C)	Temp. of thermo. and junction (°C)	Electric resistance of compensating cable (Ω) ⁽²⁾	Electric resistance of return cable (Ω) ⁽²⁾	Sheath colors	Core cable's color		Remarks
Symbol	Former symbol	symbol	Former symbol		+ point	- point						+	-	
K	CA	KX-G	WCA-G	Common for general use	Alloy of nickel and chrome	Alloy of nickel	-20~90	-20~150	±2.5	1.5	Blue	Red	White	
		KX-GS	WCA-GS	Common for general use			±1.5							
		KX-H	WCA-H	Common for heat-resistance			0~150		±2.5					
		KX-HS	WCA-HS	Common for heat-resistance					±1.5					
		WX-G	WCA-G	Common for general use	Iron	Alloy of copper and nickel	-20~90	±3.0	0.5					
		WX-H	WCA-H	Common for heat-resistance			0~150							
		VX-G	WCA-G	Common for general use	Copper	Alloy of copper and nickel	-20~90	-20~100	0.8					
J	IC	JX-G	WIC-G	Common for general use	Iron	Alloy of copper and nickel	-20~90	±2.5	0.8	Yellow	Red	White		
		JX-H	WIC-H	Common for heat-resistance			0~150							
T	CC	TX-G	WCC-C	Common for general use	Copper	Alloy of copper and nickel	-20~90	-20~150	±2.0	0.8	Brown	Red	White	
		TX-GS	-	Precise for general use					±1.0					
		TX-H	WCC-H	Common for heat-resistance			0~150		±2.0					
		TX-HS	-	Precise for heat-resistance					±1.0					
R	-	Rx-G	-	Common for general use	Copper	Alloy of copper and nickel	0~90	0~150	+3 ⁽¹⁾	0.1	Black	Red	White	
		RX-H	-	Common for heat-resistance			0~150		- 7					


Remark

- (1): The thermocouple electromotive force of thermocouple R and S is non-linear, so it does not indicate the actual temperature measurement error.
- (2): applicable to nominal cross-sectional area of 1.25mm² and more.

Appendix 3 Dimension


1) Dimension of XBF-AD04A

Unit: mm



2) Dimension of XBF-DV04A

Unit: mm




Unit: mm

Unit: mm




5) Dimension of XBF-TC04S

Unit: mm



6) Dimensions of XBF-AH04A



Warranty

1. Warranty Period

The product you purchased will be guaranteed for 36 months from the date of purchase.

2. Scope of Warranty

Any trouble or defect occurring for the above-mentioned period will be partially replaced or repaired. However, please note the following cases will be excluded from the scope of warranty.

- (1) Any trouble attributable to unreasonable condition, environment or handling otherwise specified in the manual,
- (2) Any trouble attributable to others' products,
- (3) If the product is modified or repaired in any other place not designated by the company,
- (4) Due to unintended purposes
- (5) Owing to the reasons unexpected at the level of the contemporary science and technology when delivered.
- (6) Not attributable to the company; for instance, natural disasters or fire

3. Since the above warranty is limited to PLC unit only, make sure to use the product considering the safety for system configuration or applications.

Environmental Policy

IMO Precision Controls Ltd supports environmental policy according to the details on the website.

IMO Precision Controls Limited
1000 North Circular Road
Staples Corner
London NW2 7JP
United Kingdom

Tel: +44 (0)20 8452 6444
Fax: +44 (0)20 8450 2274
Email: imo@imopc.com
Web: www.imopc.com

IMO Jeambrun Automation SAS
Centre D'Affaires Rocroy
30, Rue de Rocroy
94100 Saint-Maur-Des-Fosses
France

Tel: +8000 452 6444
Fax: +8000 452 6445
Email: info@imopc.fr
Web: www.imopc.fr

IMO Automazione
Viale A. Volta 127/a
50131 Firenze
Italia

Tel: +39 800 783281
Fax: +39 800 783282
Email: info@imopc.it
Web: www.imopc.it

IMO Canada
Unit 10, 1 Whitmore Road
Woodbridge
Ontario L4L 8G4
Canada

Tel: +1 905 265 9844
Fax: +1 905 265 1749
Email: imocanada@imopc.com
Web: www.imopc.com